



Aluminium 4-Wheeled Rollator/ Occasional Transport Chair



VP184 Range

Usage and Maintenance Instructions



This file is available to view and download as a PDF at www.aidapt.co.uk. Sight impaired customers can use a free PDF Reader (such as adobe.com/reader) to zoom in and increase the text size for improved readability.

N.B. This equipment must be installed by a competent person.

VP184	White Aluminium Rollator	120kg weight limit
VP184RED	Red Aluminium Rollator	120kg weight limit
VP184BLUE	Blue Aluminium Rollator	120kg weight limit

Do not exceed the weight limit stated - doing so could put the user at risk.

BEFORE USE

- Carefully remove all packaging. Avoid using any knives or other sharp instruments as this may damage the surface of the product.
- Check the product for any visible damage. If you see any damage or suspect a fault, do not use your product, but contact your supplier for support.

INTENDED USE

Your Aidapt Rollator/Occasional Transport Chair has been designed to assist you when walking and carrying small items of shopping using the bag provided. The bag was designed specifically to fit your rollator, please only use the bag supplied for your Aidapt Rollator. Do not use or combine bags and/ or baskets from other manufacturers. The item can also be used as a travel chair.

When not in use, you can simply fold the Aidapt Rollator/Occasional Transport Chair and store away until you require it next. The Aidapt range of tri-walkers and rollators are designed to be used both inside and outside the home.

FEATURES

- User friendly loop brakes with lock
- Simple brake cable adjustment
- Soft plastic solid wheels
- Swivelling front wheels
- Folding locking mechanism
- Height adjustable
- Ergonomic handgrips to reduce pressure
- Walking Stick holder
- Adjustable footrests

SPECIFICATION

Overall Depth (mm).....	840
Width Unfolded (mm)	660
Width Folded (mm).....	290
Handle Height (mm).....	870-960
Seat WxD (mm)	460x250
Front Wheel (mm)	203
Rear Wheel (mm)	178
Net Weight (kg)	9.3 (inc. footrests)

IMPORTANT INFORMATION

The information given in this instruction booklet must not be taken as forming part of or establishing any contractual or other commitment by Aidapt Bathrooms Limited, Aidapt (Wales) Ltd or its agents or its subsidiaries and no warranty or representation concerning the information is given. Please exercise common sense and do not take any unnecessary risks when using this product; as the user you must accept liability for safety when using the product. Please do not hesitate to contact the person who issued this product to you or the manufacturer (detailed below) if you have any queries concerning the assembly/use of your product.

ASSEMBLY INSTRUCTIONS

Carefully remove all packaging, including the cardboard tubes covering the knurled tube part of the brake assembly. Check the product thoroughly for damage or obvious faults.



If you suspect the unit to faulty, please do not use, but contact your supplier immediately for service.



ASSEMBLY INSTRUCTIONS (continued)



fig. 1




fig. 2

Step 1:

Install front wheel into receptacle located on the front of the frame (see fig. 1)

Thread bolt through holes on rollator frame, attach star head clamp knob and tighten (see fig. 2) Repeat step 1 to attach the second front wheel




fig. 3




fig. 4

Step 2:

Install rear wheel into receptacle located on the rear of the frame whilst pressing the locking pin (see fig. 3) The locking pin will pop up when the wheel is securely in place (see fig. 4) Repeat step 2 to attach second rear wheel.

When attaching the rear wheels make sure that the wheels are on the outside of the frame and that the brake linkage is on the underside.




fig. 5

Step 3:

Attach the handles by depressing the locking pin on the base of the handle assembly and sliding into the receptacle on the main frame. Repeat on the other side.

When attaching the handle assembly make sure that the handle is facing towards the rear wheels. The ergonomic fin on the handgrip should be facing in.

Adjust the height level of the handles to suit different users. Press the locking pin on the main frame and pull the handgrip upwards or downwards. As the handle moves, release the buttons. This automatically locks in the next possible height. Repeat this process until the desired height is reached. Make sure both handles are locked at the same level (see fig. 5)

ASSEMBLY INSTRUCTIONS (continued)



Step 4:

Slide the canvas tabs of the shopping bag onto the hooks located on the sides of the chair (see fig. 6) Use the longer 'hook and loop' canvas straps to attach the bag to the uprights of the main frame (see fig. 7)




Step 5:

Unfold the rollator by pressing down on both sides of the seat frame (see fig. 8)



Step 6:

To fold, pull the seat upwards via the black handle on the seat plate (see fig. 9) The Rollator can now be folded (see fig. 10)



IMPORTANT

Before use ensure all locking pins are fully engaged as per fig. 11 & 12

ASSEMBLY INSTRUCTIONS (continued)

Step 7:

To fit the footrests align the holes in the footrest brackets with the lugs on the front legs and lower into position (see fig. 13) Swing the footrests inward to lock them (see fig. 14)

When you hear the spring loaded catch click, the footrests are locked (see fig.15)

Step 8:

To adjust the height of the footrests, loosen the nut on the base of the footrests, set required height and re-tighten the nut (see fig. 16)



OPERATING THE BRAKES



1. To stop, gently apply a gripping pressure to both brakes simultaneously (see fig. 17), this will slow down and stop your Rollator.



2. The brakes on your Rollator have a park option (see fig. 18). To operate the park option, push downwards on both brakes simultaneously. You will feel the brake make a very slight click. Your brakes are now in the 'lock' position.

3. To unlock, simply pull up the brake again, you will hear a slight click as the 'park' disengages.

See next page for Brake Adjustment

BRAKE ADJUSTMENT

Your Aidapt Rollator brake system will require periodic adjustment.

To adjust the brakes loosen Nut B and then screw/unscrew Nut A. When adjusted re-tighten Nut B. If further adjustment is required then loosen the Locking Screw and then using a pair of pliers pull the cable down by approximately a millimetre. Re-tighten Locking Screw. The brakes can then be adjusted further by loosening Nut B and screwing/unscrewing Nut A as before (see fig. 19)

BRAKE CABLES

It is important that when the walker is assembled the cable ties provided are used to fasten the brake cables to the frame so that they do not obstruct the user or get caught in other parts of the walker.

REISSUE

If you reissue or are about to reissue this product, please thoroughly check all components for their safety.


This includes:

- Bent or damaged tubes or cracks at the tube joints.
- Loose or worn horseshoe clips
- Elongated adjustment holes.
- Loose handles.
- Loose or worn Wheels and wheel fasteners (where fitted)
- Smooth, worn or split ferrules (rubber tips).

Replace all worn, missing or damaged parts where necessary. If in any doubt, please do not issue or use, but immediately contact your supplier for service support.

CARE AND MAINTENANCE & YOUR OBLIGATION

1. Only use your Aidapt Rollator for the purpose for which it intended, which is as an aid to walking. It is intended your rollator is only used on standard pavements or at home. It should not be used on rough terrain or pot-holed surfaces. The use of your rollator on these surfaces can seriously compromise your safety and may damage your rollator beyond repair.



CARE AND MAINTENANCE & YOUR OBLIGATION (continued)

2. Keep your Aidapt Rollator clean by wiping down with a damp cloth with a mild detergent. Do not under any circumstances use an abrasive or solvent based cleaner, as this will seriously damage the rollator and void your warranty.
3. Wipe off all surfaces with a dry cloth and use a water dispersing agent such as WD40 on all metal joints.
4. Check that all wheels and the folding mechanism function correctly and that all wheels move freely. Pay particular attention to the front wheels, ensuring that they rotate freely and without obstruction and that they are attached securely to the frame.



Withdraw your Aidapt Rollator immediately if any of the wheels become difficult to turn or do not feel securely attached to the frame or if you suspect damage or any other fault.

5. Monthly Checks - check that all locking pins are properly secure (fig 11 & 12). Check that no components are loose. Check the adjustment to your brakes (fig 19). Check castors.
6. Do not fit any parts or accessories to your Aidapt Rollator manufactured by another company. To do so will annul your warranty and may seriously compromise your safety.
7. We suggest that you check your Aidapt Rollator visually every day. However we recommend that you should have your rollator serviced every three months or less if used by, or issued to, various users.

CLEANING

Clean your Rollator using a non-abrasive cleaner or mild detergent with a soft cloth. Abrasive cleaners e.g. AJAX and/ or abrasive cleaning pads may seriously damage the product beyond repair and should not be used. Always ensure that you wipe dry the equipment after cleaning.

MAINTENANCE

Please make a safety check of the product at regular intervals or if you have any concerns.

WARRANTY

This product carries a 12 month warranty from the date of purchase against manufacturing defects. Misuse or Damage is not covered. This warranty does not affect your statutory rights.

Aidapt Bathrooms Ltd, Lancots Lane, Sutton Oak, St Helens, WA9 3EX
Telephone: +44 (0) 1744 745 020 • Fax: +44 (0) 1744 745 001 • Web:
www.aidapt.com Email: sales@aidapt.co.uk