

Hot & Cold Deep Tissue Massager Gun



ENGLISH

Warnings

- **Read all instructions thoroughly and retain for future reference.**
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and maintenance shall not be made by children without supervision.
- Do not immerse product in water.
- For external use only.
- This device must only be used for its intended purpose as described in this user guide.
- Do not use on areas that have had cosmetic surgery.
- If you suffer from a skin condition, consult your dermatologist before use
- This appliance must only be supplied at safety extra low voltage corresponding to the marking on the appliance
- Do not use on cuts or broken skin.
- Do not use this appliance on loose skinned parts of your body or any areas showing signs of: varicose veins, skin diseases (for example eczema, psoriasis, dermatitis), cuts and abrasions, irritation, warts, moles, skin tags, skin rash, hypersensitivity or sunburn, phlebitis, recent scar tissue, other skin conditions. We recommend you consult your physician before treatment if you suffer from any of the above conditions.
- Do not use immediately around the eyes.
- If the power lead is damaged, it must be replaced by the manufacturer or its service agent or similarly qualified person in order to avoid a hazard.
- For hygiene reasons we recommend for single person use only.

Know your unit

- | | |
|------------------------------|--------------------------------|
| 1 Massage Gun | 6 Cold Indication Light (Blue) |
| 2 USB Charging Cable | 7 Temperature |
| 3 Battery Charging Light | 8 USB Charging Socket |
| 4 On/Off & Intensity | 9 Protective Carry Case |
| 5 Hot Indication Light (Red) | |

Massage Heads

- 10 Hot & Cold:
Hot & Cold functions can be used separately and can also be used in conjunction with massage. The flat head is ideal to use for increased intensity and depth in more sensitive areas. Ideal for all over body massage.
- 11 Fork:
The perfect choice to loosen stiff neck, back and shoulder muscles. Also great for use on the Achilles.
- 12 Finger Point:
For working on knots and specific areas of tension. Can also be used for acupoint and trigger point massage.
- 13 Large Round:
For general full body use on large muscle groups, like glutes, quads and hamstrings. Ideal for beginner use.

Fitting the massage heads:

- Ensure the unit is switched off.
- Select the massage head and turn clockwise to secure in place.
- To remove, turn anti clockwise.

Charging:

- Connect to a USB port using the USB Charging Cable. (included)
- The Battery Charging Light will show Blue when charging. All four lights will remain Blue once fully charged.
- Battery charging time: 5 hours
- Run time when fully charged: 1-3 hours.
Using Hot / Cold 2-2.5 hours
High speed 2.5-3 hours

How to use

- Press and hold the On/Off to turn on.
- To start the massager press the On/Off again. Pressing the On/Off will increase the intensity. There are 4 intensity levels.
- Hot & Cold with massage: To activate Cold press the temperature button once, press twice to activate Hot and three times to return to massage only. The indicator lights will show which setting has been selected.

Note: The Hot & Cold function can only be used with the Hot & Cold massage head and can be used separately or simultaneously.

Hot & Cold only: Press and hold the On/Off button. To activate Cold press the temperature button once, Press twice to activate Hot. To restart massage press one more time then press the On/Off button.

Note: The massager will run for 10 minutes and then automatically switch off.

Do not apply excessive force or pressure – simply glide the head over the area. Move slowly using circular motions.

If you feel a knot or area of muscle tension, allow the massage head to remain on that spot for a few moments.

Note: To minimise soreness it is better to build up to higher intensity levels slowly as your muscles warm up.

Important: Do not use directly over bones or joints.

After Use:

- The skin may appear red and slightly irritated after use. This should subside quickly.
- Your muscles may also feel a little sore. This is normal and will lessen with regular use.
- **Tip:** Ensure you stay hydrated to help flush out any toxins and improve muscle recovery time.

Cleaning & Maintenance:

- Switch off and clean using a soft damp cloth.
- Do not immerse the device/unit in water or other liquids.
- Dry thoroughly before storing.

Disposal

The Waste of Electrical and Electronic Equipment (WEEE) Directive (2012/19/EU) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increasing landfill. This product is classed as Electrical or Electronic Equipment so please ensure that at the end of the life of this product it is disposed of in the correct manner in accordance with local authority requirements. It must NOT be disposed of with household waste.

Recycle Responsibly:

1. Check your local municipal guidelines
2. Separate the components and dispose of them correctly

Specifications

Model: BT-MAHC
Input: 5V 1200mA 6.0W
Battery: Li-Ion 7.4V 2600mAh

Read these instructions carefully before use and then retain for future use.

This unit complies with current EU product legislation.

This product is for indoor use only.

UK CA

Guarantee

To register your two year guarantee online, visit: www.bodi-tek.com/warranty

Customer Care

If you have any questions, please contact us at:
customerservice@bodi-tek.com

© The Dezac Group Ltd 2022, PO Box 17, Cheltenham Spa, England GL53 7ET.

UK RP: The Dezac Group Ltd, PO Box 17, Cheltenham Spa, England GL53 7ET

EU RP: The Dezac Group (Europe) B.V. Azura, Saturnusstraat 46-62, 2132 HB Hoofddorp, Netherlands'

www.bodi-tek.com

