



# User Guide

---

Please read this manual carefully before operating your set and retain it for future reference.

# Contents

## Getting Started with LG webOS TV

Home Tutorial . . . . .	5
Manage Home . . . . .	6
Live TV Preparation . . . . .	7
Connecting to the Network . . . . .	7
Managing Your LG Account . . . . .	10
Using Always Ready . . . . .	11
About User Guide . . . . .	13

## How to Operate TV

Pairing the Magic Remote . . . . .	14
Using the Magic Remote . . . . .	15
Using TV features with Hands-free Voice Control . . . . .	17
Using TV Functions through Speech . . . . .	19
Speech to Text . . . . .	21
Control your TV with your voice with Google Assistant . . . . .	23
Access Voice Recognition Using Amazon Alexa . . . . .	23
To View More Features of the Remote Control . . . . .	24
Using Universal Remote Control . . . . .	25
Launching Apps through Quick Access . . . . .	26
Connecting to SIMPLINK (HDMI-CEC) . . . . .	27
Shortcuts to Accessibility . . . . .	28
Connecting an Input Device to USB . . . . .	29

## Enjoy Live TV

Making the Most of Live Menu . . . . .	30
Viewing Guide . . . . .	31
Checking Programme Info . . . . .	32
Live Playback . . . . .	33
Recording . . . . .	35
Music Catch . . . . .	36
Using TV Scheduler . . . . .	37
Playing Recorded TV Programs . . . . .	39
Watching Internet Channel (LG Channels) . . . . .	40
TELETEXT . . . . .	41
HbbTV . . . . .	43

## Apps and Content

Installing Apps . . . . .	45
Content Recommendation . . . . .	46
Content Search . . . . .	47

## Connecting External Devices

Using Home Dashboard . . . . .	48
Connecting Home IoT Devices . . . . .	49
Connecting Smart Devices . . . . .	50
Connecting Smart Devices using NFC Tagging . . . . .	53
Watching Smart Device Screen on TV . . . . .	54
Playing Sound from a Smart Device through the TV's Speakers . . . . .	55
Connecting USB . . . . .	55
Using the Media Player . . . . .	56
Viewing Photos . . . . .	57
Playing Videos . . . . .	58
Listening to Music . . . . .	59
PC Remote Operation . . . . .	60
Sharing PC Content . . . . .	61
Watching PC Screen on TV . . . . .	62

## Making the Most of Smart TV

To Use Magic Explorer . . . . .	64
Using Multi View . . . . .	64
Using the Room to Room Share . . . . .	66
Making the Most of Art Gallery . . . . .	68
Surfing the Internet on TV . . . . .	68
Connecting a Camera to the TV . . . . .	72
Using Sports Alert . . . . .	73
Live Plus . . . . .	73

## Settings

Quick Settings . . . . .	74
Picture . . . . .	76
Sound . . . . .	85
Always Ready . . . . .	94
AI Service . . . . .	95
Game Optimiser . . . . .	98
OLED Care . . . . .	101
Family Settings . . . . .	103
Programmes . . . . .	104
Network . . . . .	110
Devices . . . . .	111

System . . . . .	115
Accessibility . . . . .	122
Support . . . . .	125

## **Troubleshooting**

Perform Check-up with the Quick Help . . . . .	126
Learn More About Always Ready . . . . .	127
Troubleshooting Power/Remote Control Issues . . . . .	128
Troubleshooting Screen Issues . . . . .	130
Troubleshooting Sound Issues . . . . .	133
Troubleshooting PC Connection Issues . . . . .	134
Troubleshooting Movie Playback Issues . . . . .	136
Troubleshooting Recording Issues . . . . .	137
Troubleshooting Network Connection Issues . . . . .	138
Troubleshooting LG Account Issues . . . . .	140
Troubleshooting Contents Issues . . . . .	141
Troubleshooting Internet Browser Issues . . . . .	142


## **Being Aware of the Information**

Supported Photo File Formats . . . . .	143
Supported Video File Formats . . . . .	143
Supported Music File Formats . . . . .	146
Supported Resolution : HDMI-DTV . . . . .	148
Supported Resolution : HDMI-PC . . . . .	151
License Information . . . . .	155


# Getting Started with LG webOS TV

## Home Tutorial

### Using the Home Feature of the LG webOS TV

You can open the Home screen by pressing the  button on your remote control. Roll the **Wheel (OK)** button on the Magic Remote to scroll through the menu. You can open apps and content or use various features of the smart TV.

- Standard remote control allows you to scroll through the menu with the / buttons.



- 1 You can check weather information and useful TV features.
- 2 You can log in to your **LG Account** or view basic information about the account to which you are currently logged in.  
For more information, see **Getting Started with LG webOS TV → Managing Your LG Account** in **User Guide**.
- 3 Launch **Search**.  
To see the details, click the **Apps and Content → Content Search** in **User Guide**.
- 4 Returns to the most recently used TV or external input.
- 5 You can get recommendations from various channels and programmes.
  - You must log in to your LG account to get personalized content recommendations.
  - You must connect to the network to use the recommendation feature.
- 6 You can run, move, and delete the apps installed on your TV.


- **App List** and **Top Picks For You** are automatically shown on the screen each time the TV is turned on. To change the Home screen display, change the setting of **Home Auto Launch** in ⚙️ → ⓘ → **General** → **System** → **Additional Settings** → **Home Settings**.
- The availability of and access to Contents and Services in LGE Device are subject to change at any time without prior notice.
- Available features vary depending on the region or service.

## Manage Home

### Manage LG webOS TV Home

You can change the order of the displayed apps or content lists by pressing the 🏠 button on the remote control.

Roll the **Wheel (OK)** button on the Magic Remote to scroll through the menu. You can enter edit mode by selecting ✎ located at the bottom of the screen.



- 1 Enters the **Edit App List** mode.  
Depending on your usage pattern, you can set the app order automatically or edit it yourself.
  - After selecting the app you wish to edit from **App List** on the Home screen, press and hold the **Wheel (OK)** button on the remote control, or select the **Edit App List** button located in the last area of **App List** to enter **Edit App List** mode.
- 2 Enters the **Edit Contents List** mode.  
You can directly edit the order of the content list displayed in Home.
- 3 **Reset App Order** : Resets the order of items in the app list.  
**Reset Usage Data** : It resets the content view history and the app usage history. If you

reset them, it takes some time to receive recommendations for contents again.

**Home Settings** : When turning the power on, go to the screen that sets the Home behavior or advertising display.

**User Guide** : Move to the **User Guide** app.

- Items that can be set may vary depending on the edit mode.

④ Exits edit mode.

## Live TV Preparation

### Watching Broadcast TV

01 Connect the broadcast antenna/cable to the TV.

You must check the markings on the antenna terminal and connect it to the terminal appropriate for your country.

02 Launch  →  → **General** → **Programmes** → **Programme Tuning** → **Auto Tuning**.

Finds and adds only programmes being broadcast.

- You can also connect a piece of equipment that can receive broadcasting such as a set-top box instead of the antenna.

Launch  →  → **General** → **Devices** → **External Devices** → **Universal Control Settings**.


- To solve a problem related to this function, refer to the **Troubleshooting** section of **User Guide**.

## Connecting to the Network

### Connecting to the Network

If you configure settings for the network, you can use various services such as online contents and applications.

#### Setting a Wired Network



01 Connect the LAN port of the TV and the router using a LAN cable. The router should be connected to the Internet beforehand.

- If the router supports DHCP, the TV is automatically connected to the network when you connect the TV to the network with a LAN cable.

## If the Network Is Not Automatically Connected

02 Press the  button on the remote control.

03 Select  → **General** → **Network** → **Wired Connection (Ethernet)**.

To see the details, click the **Settings** → **Network** → **Wired Connection (Ethernet)** in **User Guide**.



- Some models may not be supported.

## Setting a Wireless Network



01 Turn on the power of the router connected to the Internet.



- 02 Press the  button on the remote control.
- 03 Select  → **General** → **Network** → **Wi-Fi Connection**.
- 04 When the network search is complete, the list of networks available for connection is shown.
- 05 Select a network to connect.  
If your wireless LAN router is password protected, enter the password configured for the router.  
To see the details, click the **Settings** → **Network** → **Wi-Fi Connection** in **User Guide**.

## Network Setting Warnings

- Use standard LAN cable (connect to Cat7 or higher with RJ45 connector, 10 Base-T, or 100 Base TX LAN port).
- Resetting the router may cause network connection problems. In this case, the router will operate normally if you turn it off and disconnect the TV, and then reconnect and turn it on.
- LG Electronics is not responsible for network connectivity or operation failure due to problems such as equipment failure or disconnected lines.
- The network connection may not work properly because of network settings or the Internet service provider.
- DSL service must use a DSL modem; and cable service must use a cable modem. Since only a limited number of network connections may be available, TV network setting may not be used depending on the contract with Internet service provider. (If the contract does not allow more than one device per line, only the already-connected PC may be used.)
- A wireless network can experience interference from other devices that use the 2.4 GHz frequency (wireless phone, Bluetooth device, or microwave oven). Although interference can also happen when using the 5 GHz frequency, it is less likely to occur.
- The wireless environment can make wireless network service run slowly.
- Using several wireless devices at the same time can slow your network.
- The access point device must support wireless connections and wireless connection feature must be enabled on the device to have AP (access point) connection. Contact the service provider for availability of wireless connections on the access point.
- Check SSID and security settings of the AP. Refer to the appropriate documentation for SSID and security settings of the AP.
- If the network is changed by moving the TV or changing the router, you must set up the wireless network again. Existing wireless network connections will not be saved.
- Invalid settings of network devices (wired/wireless line sharer, hub) can cause the TV to operate slowly or not operate properly. Install the devices correctly according to the appropriate manual and network.
- The connection method may differ depending on the AP manufacturer.



- To solve a problem related to this function, refer to the **Troubleshooting** section of **User Guide**.

# Managing Your LG Account

## LG Membership

Logging in with **LG Account** enables you to use customised recommended content and various app services.

You can sign up for LG membership and log in with your email address in **LG Account**. Alternatively, you can sign up for LG membership using the ID and password of an external service account.

- 01 Select  →  → **General** → **System** → **LG Account**.
- 02 Choose one from the three options, **Sign in with the LG ThinQ App/Sign in with the Mobile Web/Sign in with the TV remote**, and sign up for LG membership.
- 03 Agree to the User Agreements and enter the information required to sign up.
  - Required information may vary depending on the country.
- 04 A verification link will be sent to the email address you entered when you signed up. Please complete email verification within the validity period.
- 05 Once your email address is verified, you can log in with your credentials.
  - This feature may not be available in some countries.
  - Age restrictions may apply for signing up.
  - To solve a problem related to this function, refer to the **Troubleshooting** section of **User Guide**.

## Managing Your LG Account

 →  → **General** → **System** → **LG Account**

When you enter **LG Account**, the previously logged-in account is displayed, and you can select an account to log in or edit the account list.

Basic information about the account can be viewed by selecting **Account Management** under the logged-in account. Also, you can change your password or edit your account information.

# Using Always Ready

## Using Always Ready

Turning off the TV switches it to **Always Ready** and displays the selected screen wallpaper, and then you can use voice recognition or output sound from your smart device to the TV speaker.

01 Set the **Enable the function** of  →  → **General** → **Always Ready** to **On**.



- Turning this option **On** may increase energy consumption.

02 Press the  button on the remote control. The wallpaper is displayed.

Press the **Wheel (OK)** button on the remote control to display the wallpaper when the TV is **Always Ready** with the screen off.

03 Set your preferred wallpaper.



① You can move between categories by pressing the   buttons on the remote control or by using the **Wheel (OK)** button on Magic Remote.

② You can choose which content to display from the options menu.



**1** Select the screen to display with **Always Ready**.

**Clock** : You can display the time and weather information of the region for which the TV is set.

Weather is displayed as the local weather of the region set on the Home screen.

**Art Piece** : You can set various art as your wallpaper.

**Movements** : You can set various media art as your wallpaper.

**Moments** : You can set a photo saved in a connected external device or a photo of a smart device connected to the LG ThinQ as the wallpaper.

**Sound Palette** : You can play music from a device connected via Bluetooth or USB.

**2** You can make detailed settings for **Always Ready**.



**Get Notifications** : Even when the screen is off, you can receive notifications from external devices set on **Home Dashboard**.

**Screen Off** : The time can be set to automatically turn off the screen.

**Slide Show Speed** : You can set the playback speed for the photos with **Art Piece** or **Moments**.

**Set Time to Turn On** : You can set the time when the wallpaper turns on when the TV is **Always Ready** with the screen off.

**Connect Illumination Sensor** : Controls the brightness of **Always Ready** in conjunction with the ambient light sensor.

**Go to Settings** : Move to the  →  → **General** → **Always Ready**. You can turn the **Always Ready** feature on or off from the corresponding Settings menu.

## Exit **Always Ready** and Watch TV

To watch TV when it is on **Always Ready** with the screen on, press the  button or the  button on the remote control.

The Hands-free Voice Control feature can be used to command the desired function to be executed.




When it is on **Always Ready** with the screen off, the TV can be turned on by pressing the  button on the remote control or by Hands-free Voice Control.

Press the **Wheel (OK)** button on the remote control to display the wallpaper when the

TV is **Always Ready** with the screen off. The wallpaper is displayed.

## Using **Always Ready** Without Screen Wallpaper



Even when the screen is off, you can play music using voice recognition or by connecting to a smart device via Bluetooth. Users can turn off only the screen in **Always Ready** using the below method.

- Method 1. When the TV is **Always Ready** with the screen on, press the  button on the remote control once more.
  - Method 2. Set the **Screen Off** time in the **Always Ready** settings menu. The wallpaper will be turned off automatically after the set time.
  - Method 3. Select **Use Always Ready without wallpaper** in  →  → **General** → **Always Ready**. You can always use **Always Ready** with the screen off without going through the wallpaper.
- The screen may take a few seconds to respond to your voice, depending on the model.
  - When the power is turned off for the first time after a software update, **Always Ready** does not work to reflect the update contents. To use **Always Ready** again, turn the power off and on again.
  - Some models may not be supported.




## About User Guide

### About **User Guide**

For information on each feature of the LG webOS TV, consult the **User Guide** available on the TV.

You can check the description of the associated **User Guide** by clicking  → **User Guide** in the upper-right corner while using the app, or by clicking  during setup in **Settings**.

If you click on **Try Now** in **User Guide**, you can navigate to that feature or setting. Text colour in this User Guide is used to indicate the following:

-  Red : the names of the remote control buttons.
-  Yellow : the buttons and the text to be displayed on the TV screen.
-  Green : the names of the TV input connectors.

- The images and information in the **User Guide** may differ depending on the model and operating environment.
- Product specifications may be changed without prior notice due to upgrade of product functions.

# How to Operate TV

## Pairing the Magic Remote

### Learn More about Magic Remote

You can select the functions you want easily and conveniently by moving and clicking the cursor on the TV screen, just as you would use a mouse on a computer screen.

- You can purchase the Magic Remote separately if it is not provided.

### Pairing the Magic Remote

You must pair the Magic Remote with the LG webOS TV to use it.

Pair the Magic Remote prior to use as follows:

- 01 Turn on the TV. After about 20 seconds, point the remote toward the TV and then press the **Wheel (OK)**.
  - 02 The remote control will automatically be registered, and the pairing completion message is displayed on the TV screen.
- If the Magic Remote failed to register, turn the TV off and back on, and then try to register again.

### Re-registering the Magic Remote

If the Magic Remote's pointer does not appear on the TV, you must re-register it.



- 01 Hold the remote control towards the TV and press the  and  buttons at the same

time for more than 5 seconds until instructions appear.

02 The previously registered remote control is deregistered and then registered again.

## Unregistering Magic Remote


If you have multiple LG Smart TVs and want to register the Magic Remote currently in use to another TV, you must unregister the previous one.


- 01 If you press the  button and the  button at the same time for more than 5 seconds, the lamp on Magic Remote will blink and the registration will be canceled.
- 02 If you want to unregister and register for another LG Smart TV, please follow the registration method above.























## Using the Magic Remote

### Using the Remote Control Button

Briefly press or press and hold remote control button to access various functions.



For buttons with , please long-press (hold for more than a second).

- **9**  : Launch **Quick Help**.
  - **GUIDE** : Launch **Guide**.
  - **GUIDE**  : Checking the saved programmes.
  - **0**  : The **Quick Access** edit screen appears.
  - **⋮** : Display the additional buttons on the remote control.
  - **⋮**  : Audibly describes the contents of the screen. (Some models may not be supported.)
  - **+ -** : Adjust the volume level.
  -  : Select to turn off the sound from the TV.
  -   : Enter the **Accessibility** menu.
  - **^v** : You can change the programme.
  -  : Check out the recommended contents. (Recommendation service may not be available depending on the countries you are in.)
- You can use the voice recognition feature by holding down the button and speaking toward the top of the remote control.
-  : Displays the Home menu.
  -   : Launches the last used app.
  -  : Selects an input source.
  -   : Entering into the **Home Dashboard**.
  -  : Move to the previous step.
  -   : Closes the menu.
  -  : Enters the Quick Settings menu.
  -   : Enters the All Settings menu.
  -   : Launch **Record**.

- The marks and positions of the remote control buttons may vary depending on the model.

## Using the Magic Remote

- 01 If you shake the Magic Remote left and right or turn its wheel while pointing it at the TV, a pointer will appear on the TV screen.  
If you move the remote control to the direction you want, the pointer follows the movement.
- 02 Move the pointer to the location you want and press the **Wheel (OK)** button to execute the function.





- 03 If the pointer has not been used for a certain period of time, it will disappear. When the pointer disappears from the screen, shake the Magic Remote right and left. It will then re-appear.
- The pointer will disappear if you press ▲/▼/◀/▶ buttons, and the remote will work as a standard remote control.
- 04 You can control the TV by scrolling or pressing **Wheel (OK)** button in the middle of ▲/▼/◀/▶ buttons. When viewing a screen that requires scrolling, you can easily move up and down by scrolling the **Wheel (OK)** button. When watching a video, you can press the **Wheel (OK)** button to pause/play.
- If the pointer is not responding smoothly, you can reset the pointer by moving it to the edge of the screen.
  - Use the remote control within the working distance (within 10 metres). If there is an obstacle between the TV and the remote control, it may not operate properly.
  - Depending on the peripherals (wireless router, microwave oven, etc.), communication failures may occur.
  - Impacts can cause the Magic Remote to malfunction.
  - Take care not to bump into nearby furniture, electronic equipment or other people when using the Magic Remote.
  - For details on configuring the pointer of the Magic Remote, see [User Guide](#) → [Settings](#) → [System](#) → [Pointer Options](#).

## Using TV features with Hands-free Voice Control


### Using TV features with Hands-free Voice Control

This function is only available when the TV is connected to the Internet.

If Hands-free Voice Control does not work, set **Use Hands-free Voice Control** to **On** in  →  → [General](#) → [AI Service](#) → [Voice Recognition Settings](#).

#### When the TV is on

- 01 Say “Hi LG” within the watching distance from your TV.
- 02 The speech recognition screen appears.



03 Say the feature you want.

Example) Find something to watch/Programme number OO/Turn up the volume/Turn on OOO/How is the weather today?/Voice Recognition Help, etc.


## When the TV is off

Even when the TV is off, you can use TV features through Hands-free Voice Control.

Set  →  → **General** → **Always Ready** to **On**.

The Standby Light on the front of the TV will change to white.

01 When you say “Hi LG” to the TV, the Standby Light on the front of the TV will blink and the TV will produce an alert sound.







02 Say the feature you want.

Example) Turn on the TV/How is the weather today?, etc.

- In some exceptions, the Hands-free Voice Control may not work, even if **Always Ready** is on.
- If a software update is in progress

- When set to the store mode
- If the TV has not been turned on for more than 96 hours
- When pixel cleaning is running



## Precautions When Using Hands-free Voice Control


- Some models do not support this function.
- The operation may be limited depending on the country and language settings.
- When updating the TV, the existing functions or operations you have used may change.
- The Hands-free Voice Control function enables the TV body to recognise the user's voice. For smooth operation, use this function within 3 m of the TV.
- Depending on the situation, symbols, numbers and special characters may not be recognised.
- It may be affected by the environment, such as voice tone or volume, unclear pronunciation, and ambient noise.
- When you use an external speaker connected to the TV, the sound output from such an external speaker can be recognised as noise. It is recommended to use the voice recognition function with Magic Remote.
- Hands-free Voice Control wake-up words can be changed in  →  → **General** → **AI Service** → **Voice Recognition Settings** → **Set Wake-up word for Hands-free Voice Control**. (The operation may be limited depending on the country and language settings.)
- If the Hands-free Voice Control function works when not intended, try lowering the sensitivity by going to  →  → **General** → **AI Service** → **Voice Recognition Settings** → **Set Sensitivity**.
- For speech recognition features using a remote control, see **How to Operate TV** → **Using TV Functions through Speech** in **User Guide**.

# Using TV Functions through Speech

## Using TV Functions through Speech

You can easily and quickly access the TV's various functions through speech recognition.

- 01 Press and hold the  button on the remote control and speak out the function you want to launch or the keyword you want to use for your search.
- 02 Once you release the  button after your speech input, the corresponding function is launched.



- Some models may not be supported.
- **Menu Language** must be set as the official language of the country in **Location** to see correct search results. If **Menu Language** is not set as the official language, some functions may be limited.
- You can change the language in ⚙️ → ⓘ → **General** → **System** → **Language** → **Menu Language**.
- The languages available for voice recognition features may be changed in accordance with Service Operation Policy.
- Details of service may vary by model.
- Please note that the services enabling voice commands, voice recognition and other smart features may be changed, removed or terminated, without notice, by LGE or its third party providers.
- You can change the voice-related settings or see which features are available to be used with the voice in ⚙️ → ⓘ → **General** → **AI Service** → **Voice Recognition Settings/Voice Recognition Help**.


## Cautions for Speech Recognition

- Voice recognition requires a Magic Remote, which may not be supported by certain models.
- To use all speech recognition features, you need to set your programmes, region, etc. Otherwise, you cannot use some features.
- You must have a network connection to use the speech recognition feature.
- If you have a network connection, you need to accept the terms and conditions to use speech recognition.
- To control the set top box connected to the TV with the voice recognition feature, go to ⚙️ → ⓘ → **General** → **Devices** → **External Devices** → **Universal Control Settings** to set up a universal remote control.
- It is recommended to point Magic Remote toward the set top box after the voice input.

- The rate of speech recognition may vary depending on the characteristics of the user (voice volume, pronunciation, accent, and talking speed) and the surroundings (noise and TV volume).
- To achieve accurate recognition of your speech, you must pronounce words in a slow and accurate manner at an appropriate voice volume at a distance of about 10 cm away from the Magic Remote's microphone.
- If your speech is not recognised properly, speech recognition may operate differently than you originally intended.


# Speech to Text

## Using Speech to Text

You can enter text in text fields using the speech recognition function. Select the  button on the keyboard screen to switch to speech input mode.


- Some models may not be supported.

01 Move the Magic Remote pointer in the text box to open the virtual keyboard.




02 Press the  button on the virtual keyboard.



03 After the voice recognition information window opens as shown below, speak into the microphone on the remote control slowly and clearly.




04 If there are words similar to that which you spoke out loud, you may see a list of multiple results as shown below. If you do not get the results you want, press **RETRY** to try again. Select a result and it will be displayed on the text box.



## Cautions When Using Speech to Text


- Check the network connection before using the Speech to Text function.
- You can change the language in  →  → **General** → **System** → **Language** → **Menu**


**Language.** To temporarily switch to another speech recognition language, press the  button in the voice recognition information display window.

- You can only use this function to agree to voice recognition terms.
- The Speech to Text rate may vary depending on the user's characteristics (voice, pronunciation, intonation and speed) and the environment (noise and TV volume).
- To improve the accuracy of Speech to Text, you must speak clearly and loudly about 10 cm from the Magic Remote microphone.
- Voice recognition is unavailable in any password input field and the address bar of your **Web Browser** (excludes general search).

## Control your TV with your voice with Google Assistant



### Control your TV with your voice with Google Assistant


Press and hold the  (Google Assistant) button on the remote control to talk to Google. Use your voice to easily find and play movies, shows, music and videos.

- Press the  (Google Assistant) button on the remote control to access the settings.
- Google is a trademark of Google LLC.
- Google Assistant is not available in certain languages and countries.
- Service operation and supported countries may change in accordance with Google's policies.

## Access Voice Recognition Using Amazon Alexa

### Access Voice Recognition Using Amazon Alexa

- 01 Press and hold the  (Amazon Alexa) button on the remote control and speak out the function you want to launch or the keyword you want to use for your search.
- 02 Once you release the  (Amazon Alexa) button after your speech input, the corresponding function is launched.

- Press the  (Amazon Alexa) button on the remote control to access the settings and help information for Amazon Alexa.
- Different services may run in countries where Amazon Alexa is not supported.
- Service operation and supported countries may change in accordance with Amazon's policies.

## To View More Features of the Remote Control


### To View More Features of the Remote Control

You can control more features or external devices connected to your TV by using the buttons displayed on your TV screen.

01 Press the  button on the remote control.

- If your remote control does not have a  button, press and hold the  button.

02 Using the remote control, select your desired button on **More Actions** displayed on your TV screen.



- ① These features can be used when you watch a live broadcast.
- ② These TV features are available now.



3 Additional features can be set when you watch a live broadcast.

- Available features may vary depending on the broadcast signal.
- The types of buttons appearing on the **More Actions** vary, depending on the region and the type of connected device.

## Using Universal Remote Control

### Automatically Setting the Universal Remote Control

When you set up the universal remote control, you can control the peripherals (Blu-ray/DVD player, home theater, set-top box, etc.) with the Magic Remote rather than using their dedicated remote controls.

Connect the devices to be set to the TV's **HDMI IN**, and turn the power of the device on. The TV will recognise the connected device to automatically set the universal remote control without manual setting.

- After setting the universal remote control, you may need to do some additional user settings.
- It may take several seconds to complete the settings for the universal remote control.
- In some models, you can set the universal remote control only after converting to an input of a connected device.
- Depending on the connected device, the automatic setting feature for universal remote control (automatic device connection) may not be supported.

### Manually Setting the Universal Remote Control

If the universal remote control has not been set automatically, you can set it up manually.

01 Select  →  → **General** → **Devices** → **External Devices** → **Universal Control Settings**.

02 Select the type of the device you want to set.

03 Complete the settings for the universal remote control according to the guidance on the screen.

You can change or cancel the universal remote control settings.

- This feature can only be used with the Magic Remote.

- You can purchase the Magic Remote separately if it is not provided.
- Some models may not be supported.
- When changing settings on a device, make sure it is powered on first.
- To set up a universal remote control with the latest information, connect to the network and accept the User Agreements.
- The manual setting feature for universal remote control is not supported for a game console.
- Some buttons may not work depending on the model of the external device.
- Point the Magic Remote at the device you want to control. Make sure that there are no objects in front of the device to ensure that the remote control signal is well received.

## Launching Apps through Quick Access

### Using Apps Quickly and Easily with Quick Access

Press and hold a number button on the remote control to open an app or to activate an external input registered to the button.

#### Setting Quick Access

01 Launch the app or select the programme or input you wish to assign.


02 Press and hold the number button (1~8) you want to register.  
No. 9 is fixed to Quick Help.

03 When the registration pop-up window appears, select Yes.

- If you press and hold a number button that has already been registered, the registered function will be performed.
- To see the items that can be registered, select a number that has not been registered in the Quick Access edit mode.
- If you are in a mode where Quick Access cannot run, no action will be performed.
- If you delete a registered app, Quick Access will be deregistered as well.

#### Checking and Editing Quick Access

Press and hold the 0 button on the remote control.  
The Quick Access edit screen appears.






- ❶ Selecting a number that has already been registered allows deregistering it.
- ❷ When you select a number that has not been registered, items that can be registered will be shown.
  - An item that has been registered to a different number is indicated with a check mark.
- ❸ You can view a brief instruction for this function.


## Connecting to SIMPLINK (HDMI-CEC)

### Using SIMPLINK

With a single remote control, you can easily manage various devices such as a soundbar or set-top box connected to a TV with HDMI.

- Up to three devices can be connected and used simultaneously.

- 01 Connect the SIMPLINK HDMI Output port to the TV **HDMI IN** port with an HDMI cable.
- 02 Press the  button on the remote control.
- 03 Select  → **General** → **Devices** → **HDMI Settings**.
- 04 Set **SIMPLINK (HDMI-CEC)** to **On**.
- 05 Turn on the connected device. When the TV automatically connects to the device, the input will change.  
If the device is not automatically connected to the TV, click the  button and select the device you wish to connect to.

- This feature works only with devices with the  logo. Check for the SIMPLINK logo on the external device.  
Use of any product other than those specified may cause problems during operation.
- To use SIMPLINK, you need to use a high-speed HDMI<sup>®</sup> cable with CEC (Consumer Electronics Control) function. The High-Speed HDMI<sup>®</sup> cable has the pin 13 for enabling information exchange between devices.
- To output sound from an external audio device, connect the audio device to the TV's **HDMI (eARC/ARC)** port with an HDMI cable. Set **Sound Out to HDMI(ARC) Device** and set **SIMPLINK (HDMI-CEC) to On**.

## Supported SIMPLINK Functions

### Instant Play

When you start a multimedia device, you can immediately watch content from the device on the TV without having to control anything.

### Controlling devices with the TV remote control

Enables the user to control multimedia devices with the TV remote control to watch content.

- The menu of the multimedia device can be operated with the arrow keys on the remote control.

### Main Power Off

Turning off the TV will also turn off the devices connected through SIMPLINK.

- This feature is only available in certain devices.

### Main Power On

Turning on a SIMPLINK device will also turn on the TV.

- Some models may not be supported.

## Shortcuts to Accessibility

### Shortcuts to **Accessibility**

You may go directly to **Accessibility** without entering the Advanced Settings menu.

Press and hold the  button on your remote control.

In **Accessibility**, you can set up **High Contrast**, **Greyscale**, **Invert Colours**, etc.

## Connecting an Input Device to USB

### Using a USB Wired/Wireless Mouse

Connect your mouse to the USB port. Use the mouse to move the pointer on the TV screen and select the menu you want.

- The right button and the special buttons on the mouse do not work.
- When using a wireless USB mouse, the connection can be lost or slowed, depending on the distance between the TV and mouse and the wireless environment.

### Using a USB Wired/Wireless Keyboard

Connect your keyboard to the USB port. You can enter text with the connected keyboard device.

- It is not possible to enter text on some screens.
- It is recommended that you use a product that has been tested for compatibility with LG TVs.  
Logitech K360, Logitech K400, Logitech K750
- You can change the input language by pressing the language switch key or the right Alt key, And also can change by pressing the Ctrl key and the Space key at same time.
- When using a wireless USB keyboard, the connection can be lost or slowed, depending on the distance between the TV and keyboard and the wireless environment.
- To enter text in the text field, use the on-screen keyboard on your TV screen or a USB keyboard.

### Using a Gamepad

Connect your gamepad to the USB port on the TV if the game requires a gamepad.

- It is recommended that you use a product that has been tested for compatibility with LG TVs.  
Sony DualShock 4, Sony DualShock 3, Microsoft Xbox 360 Controller, NVIDIA SHIELD

## Connecting Bluetooth Input Devices

You can connect and use devices such as a Bluetooth-enabled keyboard, mouse, or a gamepad with your TV.

To see the details, click the **Settings** → **Devices** → **External Devices** → **Connect Bluetooth Controller** in **User Guide**.

## Enjoy Live TV


### Making the Most of Live Menu

#### Using Live Menu

You can use the relevant features with ease when watching TV broadcasts.

Press and hold the **GUIDE** button on the Magic Remote.

Or press the **LIST** button on the standard remote control.



- 1 Guide** : You can view programmes and the schedule of each programmes.  
To see the details, click the **Enjoy Live TV** → **Viewing Guide** in **User Guide**.
- 2 Programmes** : View a list of broadcast content that is currently being broadcast.

3 **TV Scheduler** : You can enter the time and date of a programme to schedule watching or recording it at the set time.

To see the details, click the **Enjoy Live TV → Using TV Scheduler** in **User Guide**.

4 **Recordings** : You can check the recordings stored in the storage device and play the recordings.

To see the details, click the **Enjoy Live TV → Playing Recorded TV Programs** in **User Guide**.

- The menu appears only if an external storage device is connected and the recorded video can be viewed.
- The programmes displayed in Programme List are a configuration of programmes provided by the broadcast service provider. Therefore, if the broadcast service provider has changed its programme configuration without notice, the programmes displayed in Programme List may differ from the actual TV programmes.
- Because programme information displayed in programme List includes information provided by external Electronic Programme Guide (EPG) providers, it may differ from the actual TV programmes.
- You must complete the settings of the network, region, and auto-programme to receive normal live broadcast service.
- The configurable items differ depending on model.

## Viewing Guide


### Viewing TV Guide

You can view programmes and the schedule of each programmes.

01 Run **Live TV** by pressing .

02 Press the **⋮** button on the remote control and select **Guide**.

- If your remote control does not have a **⋮** button, press and hold the  button.



- ① Select each area to access the corresponding feature.
  - ② You can view information on the programme and broadcaster.
  - ③ You can view information about the programme you are currently watching as well as the focused programme information.
  - ④ Select the (i) button or the title of the desired programme. You can view more information on the programme and perform **Watch/Record** (only available on certain models) or **Reminder/Scheduled Recording** (only available on certain models), etc.
  - ⑤ You will be taken to the programme list for the current date and time.
  - ⑥ **Programme Manager** : Launch **Programme Manager**.  
**Programme Row** : You can change the size of the programme list to adjust the number of programmes displayed on the screen.  
**Filters** : Sets the filter.  
**Mini TV** : You can turn on/off Mini TV.  
**User Guide** : Move to the **User Guide** app.
  - ⑦ Closes the app.
- Programme information is not displayed for programmes with no provided broadcast information.
  - Some models may not be supported.
  - The configurable items differ depending on model.

## Checking Programme Info

### Viewing Programme Information


During watch the Live broadcast, press the **Wheel (OK)** button. The Programme Banner



appears.

You can move the banner's position by pressing the **⋮** button on the remote control and selecting **Change Banner Location**.

- If your remote control does not have a **⋮** button, press and hold the **⏏** button.



- 1 It displays the information about the programme you are watching. Select a programme banner to enter the detailed information pop-up to see the detailed programme information or run additional features related to the banner.

You can view broadcast information about other programmes using the **▲/▼** buttons.

You can view broadcast information about the programme you are currently watching using the **◀/▶** buttons.

- The features can be controlled only within the detailed information pop-up.
- 2 Launch **More Actions**.  
For more information, see **How to Operate TV → To View More Features of the Remote Control** in **User Guide**.
  - 3 You can get recommendations for what to watch next by setting **Next Picks** to **On**.
    - This feature may not be available in some countries.
    - Available features may vary depending on the broadcast signal.

## Live Playback

### Using Live Playback (Real-time Playback)

It is a function you can use to temporarily save the programme you are currently

watching to a USB HDD, so you can play back any scenes you might miss while watching TV. This function allows you to continue watching from where you were previously if you go out for a while.

01 Input the USB HDD in the USB port.

02 Press the **⋮** button on the remote control and select **Live Playback**.


- If your remote control does not have a **⋮** button, press and hold the **⏏** button.

03 The **Live Playback** setting confirmation screen appears. Complete the settings and press the **OK** button.

- If only one USB storage device is connected, the settings screen may not appear and Live Playback may run.

04 During watch the live broadcast, select a point on the progress bar which you want by the pointer. You can also press the **◀/▶** buttons on your remote control to use this feature.

Select a previous point than the current point on the progress bar.




- The Live Playback function can be used only for broadcast programmes you view through the antenna input terminal. However, you cannot use this option while listening to a radio programme.
- Select a device to be used with Live Playback when two or more USB HDDs are connected to the TV.
- You cannot use a USB stick. Connect a USB HDD with 80 GB or more of total storage.
- If there is not enough remaining space in the USB HDD device, Live Playback may not work properly. To use Live Playback function, you need the USB HDD which has at least 2.3 GB.
- With the Live Playback function, you can play a programme back for up to two hours depending on remaining USB HDD capacity. This time may vary depending on your region.
- The videos saved in Live Playback mode are deleted if you turn off the TV without recording them.

- Changing between programmes during Live Playback will delete the data of the previous programme.
- Some models may not be supported.

## Recording

### Using Instant Recording

- 01 Connect a USB HDD or USB stick to a USB port.  
It is recommended that you record to a USB HDD.
- 02 Press the **⋮** button on the remote control and select **Record**.
  - If your remote control does not have a **⋮** button, press and hold the **⏻** button.
  - To end the recording, press the **⋮** button on the remote control during recording and select **Record**.



### Matters That Require Attention of Recording

- While recording, press the **Wheel (OK)** button to display information about the recording.
- The duration of the recording can be set before the recording starts.
- If multiple USB storage devices are connected, the last recorded storage device is selected automatically.
- The available capacity of the USB HDD partition must be at least 1 GB.
- There must be at least 4 GB of partition size on USB stick.
- The recordable time may vary depending on the capacity of your USB storage device.
- Upon the initial attempt to record to the USB memory, the TV will perform a performance

test. Start recording after the test has been completed normally.


- Because of the content protection technology used, the recorded video cannot be played on PCs or other TV models. Also, the video cannot be played if the TV's video circuit is replaced.
- Do not remove the USB cable while recording.
- If you force your TV to power off while recording, the recorded content may not be saved. Ideally, you should stop the recording and check that the programme has been recorded before turning the TV off.
- Recording quality depends on the performance of the USB storage device.
- If a USB storage device is faulty, recording may not be completed properly.
- The USB storage device may not work or function properly when a USB hub or extension cable is used.
- Recording may be interrupted if the remaining storage capacity is insufficient. Use of a storage device with sufficient space for recording is recommended.
- The configurable items differ depending on model.
- Some functions may not be available while recording is in progress.
- Only broadcast programmes you view through the antenna input terminal can be recorded.
- Bluetooth and the USB port may not work properly when recording with a USB storage device.
- Recordings that are less than 10 seconds long will not be saved.
- You can save up to 600 pieces of content on a single partition.

## Music Catch

### Using Music Catch

It is a function you can use to record the music from the TV any time.

- 01 During watch the Live broadcast, press the **•••** button.
- 02 Select **Record Music**.



- Select a device to be used with record the music when USB HDD is connected to the TV.
- If there is not enough remaining space in the USB HDD device, Music Catch may not work properly. To use Music Catch function, you need the USB HDD which has at least 100MB.
- Stored files can be viewed in the **Media Player** app, and you can open them on your PC or portable devices.
- Recorded files are stored in aac or mp3 format. (The storage format varies depending on the TV model.)
- If you switch apps or input during recording, recording automatically ends and the recorded files will be saved.
- Only available with analogue broadcasts.
- With the Music Catch function, you can play a music for up to two hours.
- Some models may not be supported.

## Using TV Scheduler

### Using the TV Scheduler


You can enter the time and date of a programme to schedule watching or recording it at the set time.

01 Press  on the remote control to select **Live TV** and view the live broadcast.

02 Press the **...** button on the remote control and select **TV Scheduler**.

The **TV Scheduler** screen will be displayed.

- If your remote control does not have a **...** button, press and hold the  button.



- ① You can set the New Scheduled Recording.
- ② You can set the New Reminder.
- ③ **Sort** : You can sort the list.  
**Filter** : Sets the filter.  
**Delete** : You can set the Delete Mode.  
**Guide** : Launch **Guide**.  
**User Guide** : Launch **User Guide**.  
**Quit App** : Turns off the app from running in the background.
- ④ Closes the app.





## Scheduling a selected broadcast from **Guide**

You can select a show to schedule it for watching or recording.

- 01 Run **Live TV** by pressing 🏠.
- 02 Press the **⋮** button on the remote control and select **Guide**.
  - If your remote control does not have a **⋮** button, press and hold the **🟡** button.
- 03 Select the programme you want.  
If you want to record a live broadcast, click the **Record** or **Watch** button.  
In case of an upcoming programme, click the **Scheduled Recording** or **Reminder** button.
  - Scheduled recording does not guarantee exact recording time of the programme because the programme will be record as the information of broadcaster.
  - Applies to Digital broadcasting.

## Manual Scheduling



You can select the date, time and programme to watch or record the programmes.


- 01 Run **Live TV** by pressing .
- 02 Press the **⋮** button on the remote control and select **TV Scheduler**.
  - If your remote control does not have a **⋮** button, press and hold the  button.
- 03 Select the  or the .
- 04 Select **Create Manually**.
- 05 Set the date, time, and programme to record or watch.
  - The length of the scheduled recording should be at least 1 minute.

## Playing Recorded TV Programs

### Managing Recordings

You can view and play recordings stored on storage devices by using the **Recordings** app.

- 01 Run **Live TV** by pressing .
- 02 Press the **⋮** button on the remote control and select **Recordings**.
  - If your remote control does not have a **⋮** button, press and hold the  button.



- ① Launch **Search**.
  - ② You can apply settings, such as storage devices and sort options, for the content list.
  - ③ Closes the app.
- You can only play recordings made on the current TV in **Recordings**.

# Playing Recordings


You can access and operate basic features such as playback and pause on the playback screen.

01 Select your desired recording from the **Recordings** app.

02 Pressing the ◀▶ buttons on the remote control allows you to skip backward/forward 10 seconds.

You can control the playback of your desired recording by pressing the **Wheel (OK)** button during playback.

You can access more features by pressing the ▼ button on the remote control while using the playback control.



① Shows the previous recording.

② Plays or pauses the recording.

③ Shows the next recording.

④ Turn subtitles on or off.

⑤ You can set continuous playback.

⑥ Fast-rewinds the video at higher speeds.

⑦ Fast-forwards the video at higher speeds.

⑧ You can set features such as Resume and the audio language that can be outputted.

⑨ A list of recordings is shown below.

● The configurable items differ depending on model.

# Watching Internet Channel (LG Channels)





# Watching Internet Programme

You can watch real-time broadcasts through this service over the Internet.




You can see information on new Internet Programmes or manage the programmes you like in **LG Channels**.

Press the  button on the remote control and select **LG Channels**.

You can also watch **LG Channels** by pressing the  (**Programmes**)  buttons on the remote control.

You can use the 'Interactive Programme' service that enables users to conveniently enjoy content related to the current programme without having to switch apps.

You can use the 'Interactive Programme' by pushing the buttons on your remote control or clicking your screen according to the instructions that appear on the Internet programme screen.

- Some models may not be supported.
- You must connect to the network and agree to **User Agreements** before you use it.
- In the  →  → **General** → **System** → **Location**, the **Broadcast Country** and the **LG Services Country** must be the same. If you change any of them, you cannot use the service.
- While watching an Internet Programme, click the  button on the Remote control. You can start the **LG Channels**.
- Some content can cause a switch from **Live TV** app to a different app.
- Some Internet programmes may not support this service.
- Live Playback and recording are not available for internet programmes.
- Internet Programme services may be stopped or changed without prior notice by the broadcasting company.

# TELETEXT

## To Use Teletext

Teletext is a free service provided by the TV station that offers text-based information about TV programmes, news and weather.


The teletext decoder of this TV can support the SIMPLE, TOP and FASTEXT systems.

01 Press the  button on the remote control.

- If your remote control does not have a  button, press and hold the  button.

02 Select **Teletext**.

03 The Teletext window appears.

04 To view TV broadcasts and Teletext at the same time, press the  button on the remote control and select **Teletext**.

Colour button

To select the preceding or following page.

Number button

Enters the page number to move to.

 **(Programmes)**  Button

To select the preceding or following page.

- Some models may not be supported.

## Special Teletext Function

01 Press the  button on the remote control.

- If your remote control does not have a  button, press and hold the  button.




02 Select **Teletext Option**.

03 Select the **Teletext** menu.

 **Index**

Select each index page.

 **Time**

When viewing a TV programme, select this menu to display the time at the top right hand corner of the screen. In the teletext mode, press this button to select a sub page number. The sub page number is displayed at the bottom of the screen. To hold or change the sub page, press the , ,  or Number buttons.

 **Hold**

Stops the automatic page change which will occur if a teletext page consists of 2 or

more sub pages. The number of sub pages and the sub page displayed is, usually, shown on the screen below the time. When this menu is selected the stop symbol is displayed at the top left-hand corner of the screen and the automatic page change is inactive.

### **Reveal**

Select this menu to display concealed information, such as solutions to riddles or puzzles.

### **Update**

Displays the TV picture on the screen while waiting for a new teletext page. The display will appear at the top left hand corner of the screen. When the updated page is available then display will change to the page number. Select this menu again to view the updated teletext page.



## **Language**

Sets Teletext language.

- In Digital Mode Only

## **To Set Teletext Language**

Use the Teletext language function when two or more Teletext languages are broadcast.






- 01 Press the  button on the remote control.
- 02 Select  → **General** → **System** → **Language** → **Primary Teletext Language/Secondary Teletext Language**.

- In Digital Mode Only
- If Teletext data in a selected language is not broadcast, the default language will be displayed.
- If you select the wrong local country, teletext may not appear correctly on the screen and some problems may occur during teletext operation.

## **HbbTV**

## **Learn More about HbbTV**

HbbTV (Hybrid Broadcast Broadband TV) is a new broadcasting standard that enables super-teletext type services, delivered by a broadcast TV programme, to be integrated or linked to online services delivered over broadband to a connected Smart TV.

Consumers are therefore able to access various online services such as catch-up TV, Video on Demand (VOD), programme related applications and other rich information services in addition to traditional digital teletext services, all directly on to the TV in a seamless experience. HbbTV services can be activated in a number of ways, the most popular being pressing the . Users typically explore services with the traditional navigation keys (including the OK button and the , , , ). The current version of the HbbTV specification also includes support for “adaptive streaming” of video over a broadband connection thus guaranteeing the best possible image quality for the viewer. For more information about HbbTV, visit [www.hbbtv.org](http://www.hbbtv.org)

- Some models may not be supported.

## To Use HbbTV

 →  → **General** → **Programmes** → **HbbTV**

Sets HbbTV to On.

Enjoy a wide variety of content from HbbTV enabled services.



- Service features may be limited when the TV is not connected to the internet.
- The functionality and quality of the HbbTV service may vary depending on the quality of your broadband connection.
- HbbTV services are not guaranteed to be available for all programmes – only those that your broadcaster chooses to support.
- Some models may not be supported.
- When Live Playback is in operation, HbbTV is disabled.
- While using HbbTV service, navigation keys and the **Wheel (OK)** button may be disabled if the Magic Remote’s pointer is activated on the screen. In this case, press the left, right, up and down keys in order to deactivate the pointer. (This only applies to models that support the Magic Remote.)


## Apps and Content


# Installing Apps



## Installing Apps

You can install apps in a variety of categories such as games, education, and news and conveniently use them on your TV.

- 01 Press the  button on the remote control.
- 02 Launch **Apps**.
- 03 Select a category or press the  button to search for an app.
- 04 Select an app to install.
- 05 Read the details of the app and then press **Install**.
- 06 When the installation is complete, you can run the app immediately.



- ① Searches for content.  
To see the details, click the **Apps and Content** → **Content Search** in **User Guide**.
- ② You can log in to your LG account.
- ③ You can manage apps, such as updating or deleting installed apps.
- ④ Closes the app.  
To turn off the app from running in the background, press the **⋮** button on the remote control and select **Quit App**.
  - If your remote control does not have a **⋮** button, press and hold the  button.
  - In order to install apps, you must be logged in.
  - Available categories may vary depending on the country or service status.
  - If the storage on your TV is insufficient, you can install the apps by connecting an external memory device.


- Some USB storage devices may not be supported or may not work properly.
- USB stick containing apps from other TVs may not be used.
- Exercise caution when in use by children. Children may have access to inappropriate online content through this product. You can block inappropriate online content by restricting access to some apps.  
Configure the settings in  →  → **General** → **System** → **Safety** → **Application Locks**.

# Content Recommendation

## Content Recommendation


You can get content recommendations based on the programme you are watching or TV viewing patterns.

If you are watching the TV using a set-top box, you must complete the setup of the universal remote control to use the recommendation feature normally. For more information, see **How to Operate TV** → **Using Universal Remote Control** in **User Guide**.

01 Press the  button on the Magic Remote. The Content Recommendation screen appears.

- When using a standard remote control, press the  button on it.

02 You can view more content by pressing the  icon on the screen.



- Some models may not be supported.
- You must connect to the network to use the recommendation feature.
- The supported services vary depending on countries, so the recommendations may be

provided differently.

- The list of the recommendations may be less relevant or irrelevant, depending on the information of the programme you are watching.

# Content Search


## Content Search

Searches for content by title, actor/actress, and genre.

01 Press the  button on the remote control.

02 Launch .

03 Search for a variety of content and information using the desired search terms.



- 1 Enter a search term.
  - 2 Shows recent searches.
  - 3 You can select one from the suggested keywords and proceed to search.
  - 4 You can browse content by genre.
- You must connect to the network to use the search feature.
  - Search results may vary depending on the programme, region, network settings, and whether you have agreed to the terms and conditions.

# Connecting External Devices


## Using Home Dashboard

### Using Home Dashboard

You can select or control a device (mobile, external device, Home IoT Devices, etc.) connected to the TV.

Run **Home Dashboard** by pressing the  button on the remote control.

You can also press and hold the  button on Magic Remote.



- 1 You can check and select the external device connected through the external input port or network.
- 2 Connect your mobile device to TV to share the mobile screen and enjoy the stored contents.
- 3 Use AirPlay/HomeKit to control your TV and watch content from your iPad or Mac on the TV screen.
  - The availability of and access to Contents and Services in LGE Device are subject to change at any time without prior notice.
- 4 It can only be selected if you have connected a USB storage device or a media server.
- 5 The connected camera is launched.





- 6 The currently selected output speaker is displayed, and you can navigate to the output speaker settings screen.
  - 7 You can view the list of connected Bluetooth devices and select one.
  - 8 The PC can be remotely operated from the TV.  
Please refer to **Connecting External Devices** → **PC Remote Operation** in **User Guide** for more information on the action.
  - 9 You can check and control the device connected via the Home IoT.  
Please refer to **Connecting External Devices** → **Connecting Home IoT Devices** in **User Guide** for more information on the action.
  - 10 You can log in or out with your LG ThinQ account.
  - 11 **Edit Inputs** : You can edit the name of the connected device or apply the related settings.  
**Edit home IoT devices** : You can hide or show connected Home IoT Devices and rearrange the list.  
**Notification** : You can turn on or off the notifications on the connected device.  
**Show Connectable IoT Devices** : Shows devices that are available for connection on the screen.  
**Universal Control Settings** : Move to the **Universal Control Settings** app.  
**User Guide** : Move to the **User Guide** app.  
**Quit App** : Turns off the app from running in the background.
  - 12 Closes the app.
- Available settings vary depending on the model or region.

## Connecting Home IoT Devices


### Connecting Home IoT Devices

You can check and control the status of the connected Home IoT Devices.

- 01 Install LG ThinQ app on your smartphone.
  - 02 Log in to your LG ThinQ account, and register your own LG ThinQ device.
  - 03 Run **Home Dashboard** by pressing the  button on the remote control.
  - 04 Select the  at the top right.
  - 05 Log in to your LG ThinQ account. A list of the registered LG ThinQ devices will appear.
- If you are in an area where the LG ThinQ app is not in service, LG ThinQ device connection

will not be supported.

- To register your IoT device, select **Connect Home IoT Devices** and follow the instructions to apply settings.
- If you are controlling the external device from your mobile app, you might not be able to control the device from your TV. Quit the mobile app to control it from your TV.



- 1 You can check the connection guide for each type of **Home IoT Devices**. You can connect and see devices registered with your LG ThinQ account or IoT devices. Once the device is connected, the card will be changed to a smaller size and appear at the bottom of the device connection list.
  - 2 Select **⋮** → **Edit home IoT devices**.  
**Edit List** : You can hide or show the connected Home IoT Devices and rearrange the list.  
**Delete devices** : You can delete the connected device. You can only delete certain devices from the TV.
- Available settings vary depending on the model or region.
  - IoT devices that can be connected to a TV are subject to change without notice.
  - Connectable LG ThinQ devices and available functions may differ between mobile and TV.

## Connecting Smart Devices



### Connecting Smart Devices

You can use a variety of features by connecting the TV to a smart device.

### Connecting Your Smart Device to a TV Using the LG ThinQ App


- 01 Download the LG ThinQ app from the app store of your smart device.  
You can download the app easily by scanning the QR code.



- 02 Connect your TV and smart device to the same Wi-Fi network.  
You can check the Wi-Fi network of TV at  →  → **General** → **Network** → **Wi-Fi Connection**.
- 03 Run the LG ThinQ app installed on your smart device.
- 04 Follow the instructions from LG ThinQ app to connect your smart device to the TV.  
When your account information of LG ThinQ is linked to the TV, you can manage the IoT devices linked to your account using **Home Dashboard** of the TV.
- Voice commands can also be made through Smart Speaker linked to the account in the settings of the LG ThinQ app.
  - The service may not offer depending on country.

## Controlling Your TV with the LG ThinQ App

You can tap the buttons on your smart device's screen to control the TV.



- ① Simple remote control operation is possible. Select **View All** and try using the remote control in full screen.
- ② You can share and enjoy the sound, screen, or content on the TV and smart device interactively.
- ③ Displays a list of apps installed on the TV.
- ④ Displays a list of devices connected to the TV's external input.
- ⑤ When watching a broadcast, you can control the programme, volume, etc. or select the external input with voice commands instead of using the remote control.
- ⑥ You can use the same functions as the Magic Remote's pointer and arrow keys.
- ⑦ A speech recognition function is available.
  - Some models do not support this function.

- Some controls may be limited in external input mode.
- The app's screen and functionality are subject to change without prior notice.
- Available features may differ depending on your country and OS.

# Connecting Smart Devices using NFC Tagging

## Connecting Smart Devices using NFC Tagging

Near Field Communication (NFC) is a technology that allows you to conveniently send and receive information without any separate settings.

By bringing a smart device near the NFC-enabled remote control you can install the LG ThinQ app and connect the device to the TV.


01 Turn on NFC in the settings of the smart device.

To use NFC with Android devices, set the NFC option to enable read/write tags in the settings of the smart device.

The NFC settings may vary depending on the device.

02 Turn on the smart device screen and place it near the **N** on the remote control.


The maximum distance for NFC tagging is about 1 cm.



03 Follow the instructions to install the LG ThinQ app on your smart device.



04 Tag your smart device to the remote control again. LG ThinQ allows you to connect to the TV and watch the contents of your smart device or enjoy the screen of your smart device.

- Some countries do not support LG ThinQ app installation with NFC tags. In this case, download the LG ThinQ app from each app store.

- This feature is available for NFC-enabled smart devices only.
- Depending on the smart device, the NFC location may be different. For more information, refer to the user manual of the device.
- Features connected via NFC may differ depending on the smart device.
- This feature is only available if the remote control has an NFC logo.
- Some remote controls have  on the back of the remote.

## Watching Smart Device Screen on TV

### Watching Smart Device Screen on TV

- 01 Enable Screen Share mode on the smart device.
  - 02 Your TV will be displayed in the list of available devices.
  - 03 Select your TV and request connection.
  - 04 Select **Accept** in the connection request popup window.
  - 05 After the connection is established, the TV will display the screen of the connected device.
- When you connect **Screen Share** for the first time, a popup will appear which allows you to select **Accept**, **Decline** or **Block**.
    - **Accept** : You can connect the device. No connection popup will appear from the second time.
    - **Decline** : Do not connect the device. If you try to connect again, the popup will appear.
    - **Block** : Do not connect the device. Even if you try to connect again, the popup will not appear and the connection will not work.  
To turn off **Block**, go to  →  → **General** → **Devices** → **External Devices** and select **Delete Connection History**.
  - It is recommended that you always update your device to be connected to your TV to the latest OS version for a reliable connection.
  - Depending on the model or manufacturer of the smart device, the Screen Share feature may not be supported.
  - It is recommended that you connect the device to a 5 GHz router because the performance may be affected by your wireless environment.
  - The response rate may vary depending on the user's environment.
  - It's differ form devices. For more information on the device you want to connect to, refer to

its user guide.

- If connection fails repeatedly, turn off the TV and the device you want to connect to, then turn them back on and try again.

## Playing Sound from a Smart Device through the TV's Speakers

### Playing Sound from a Smart Device through the TV's Speakers

Connect a smart device to the TV via Bluetooth to play sound from the smart device through the TV's speakers.

01 Turn the smart device's Bluetooth on, then select the TV from the list of devices.

02 The TV will be connected to the smart device.

- The TV may not be found in the list of smart devices while searching for a broadcast programme or setting up a Bluetooth speaker.
- If you connect a smart device to the TV via Bluetooth and listen to the sound of the smart device through the TV speaker, the TV may not be connected to any other smart device.



## Connecting USB

### Connecting USB

Connect a USB storage device (USB HDD, USB stick) to the USB port on the TV to enjoy the content files stored on the USB storage device on your TV.

### Tips for Using a USB Storage Device

- A USB storage device that has a built-in automatic recognition programme or uses its own driver might not be recognisable.
- Some USB storage devices may not be supported or may not work properly.

- If you use a USB extension cable, the USB storage device may not be recognised or may not work properly.
- Please use only USB storage devices formatted with the FAT32, exFAT or NTFS file system provided by Windows OS.
- It is recommended that you use an external USB HDD with a rated voltage of 5 V or less and a rated current of 500 mA or less. If you use a device requiring a higher voltage/current than the rated voltage/current, it may not operate properly due to lack of current.
- It is recommended that you use a USB hub or USB storage device with a power supply.
- We recommend using a storage device with a capacity of 32 GB for the USB memory and 2 TB or less for the USB hard disk.
- If a USB HDD with power-saving function does not work, turn the hard drive off and on again to make it work properly. See the owner's manual for the USB HDD for more information.
- Data on a USB storage device may be damaged, so it is recommended that you back up any important files. Users are responsible for data management. The manufacturer bears no responsibility.
- Press the  button on the remote control. To remove the USB storage device, press the **Eject** button, which appears at the top when you focus on the USB storage device you want to remove. If you disconnect the USB storage device without selecting **Eject**, an error may occur in your TV or storage device.
- When you connect a USB storage device of a file system not supported by the TV to the **USB IN** port, the format message appears. To use the connected USB storage device, you should format the device first.  
Formatting deletes all data stored on the USB storage device, and the device is formatted with the FAT32, exFAT or NTFS file system.
- Run **Home Dashboard** by pressing the  button on the remote control. Select the connected USB from **Home Dashboard** and select the **Format** button to format the USB storage device.
- When connecting a USB storage device, a random file/folder can be created to provide Smart TV services such as the saving and retrieving of thumbnail images.

## Using the Media Player

### Using the **Media Player**


You can search and view photos or play videos and songs with the **Media Player** app.

- 01 Press the  button on the remote control.
- 02 Run the **Media Player** app.



03 Select a device to use from the device list.

04 Select the content to play.




- ① You can select a device connected to your TV.
  - ② Displayed only when music is playing. Press the **list icon** to access the Play Music screen.
  - ③ Launch **Search**.
  - ④ **View Type** : Selects a content display mode.  
**Sort** : Select the option to sort content.  
**Group** : If you filter by **Music**, you can group content into categories such as **Artist** and **Album**.  
**Selection Play** : You can select and play multiple pieces of content.  
**Copy** : You can copy content to a USB storage device.  
**Delete** : You can select and delete multiple pieces of content.  
**User Guide** : Move to the **User Guide** app.  
**Quit App** : Turns off the app from running in the background.
  - ⑤ Closes the app.
- You cannot delete files that are shared from other devices.
  - Different settings items are available depending on the filtering or model you selected.
  - Certain content may not be displayed on the list if the number of all content exceeds 40,000.

## Viewing Photos

### Viewing Photos

You can select a photo from the **Media Player** app and view the photo. You can use more features by pressing the ▼ button on the remote control while viewing a photo.




- ① Shows the previous content.
- ② Starts the slide show.
- ③ Shows the next content.
- ④ Rotates photos.
- ⑤ Enlarges or reduces the photo.
- ⑥ 360-degree photos can be viewed in 360 degrees.
  - Using the 360° VR Play on a normal photo may distort the image.
  - Some models may not be supported.
- ⑦ Plays a music file selected from the storage device as background music.
- ⑧ Sets the photo size or changes the speed or effects for the slideshow.
  - Some models may not be supported.

## Playing Videos

### Playing Videos

You can select a video from the **Media Player** app and play the video. Pressing the ◀▶ buttons on the remote control allows you to skip backward/forward 10 seconds.

You can access more features by pressing the ▼ button on the remote control while playing a video.




- ① Shows the previous video.
- ② Plays or pauses the video.
- ③ Shows the next video.
- ④ You can change subtitle settings.
- ⑤ Rotates videos.
- ⑥ Fast-rewinds the video at higher speeds.
- ⑦ You can do the settings related to play on repeat of the video.
- ⑧ Fast-forwards the video at higher speeds.
- ⑨ 360-degree videos can be viewed in 360 degrees.
  - Using the 360° VR Play on a normal video may distort the image.
  - Some models may not be supported.
- ⑩ **Resume Play** : You can set continue watching to resume playing from the last viewed scene.  
**Play Speed** : Sets the playback speed.  
**Audio Track** : You can set audio tracks.  
**User Guide** : Move to the **User Guide** app.  
**Quit App** : Turns off the app from running in the background.

## Listening to Music

# Listening to Music

You can select a song from the **Media Player** app and play the song.

You can use more features by pressing the **▼** button on the remote control while playing a song.



- ① You can set the random play mode.
- ② You can set the repeat play mode.
- ③ Lyrics are available for music files that provide them.  
In some music files, you can choose a lyric section and move the playback position.
  - The lyrics feature is only supported on some devices.
  - The lyrics may not be displayed in sync depending on the lyrics data in the music file.
- ④ You can listen to music with the screen turned off.
- ⑤ **Lyrics Sync** : You can set the lyric speed.
  - This feature may not be supported depending on the music.


**User Guide** : Move to the **User Guide** app.

**Quit App** : Turns off the app from running in the background.

# PC Remote Operation

## PC Remote Operation

The PC can be remotely operated from the TV.

- 01 Turn on the power of the PC to which you wish to connect.
  - 02 Turn on "Enable Remote Desktop" in the PC settings.
  - 03 Press the  button on the remote control to launch **Home Dashboard**.
  - 04 Run the **Remote PC**.
  - 05 Enter the IP address, **User Name**, and **Password** of the PC you wish to connect to, and select **Connect** to connect the PC.  
The screen of the connected PC will be displayed on the TV screen and can be operated with the TV remote control.
- Both TV and PC can be connected only after network connection and settings are set.
  - Only Windows 10 Professional or later operating systems can be connected.
  - Some features or programmes of the PC cannot be used.

## Sharing PC Content

### Watch content saved in your PC on the TV

You can enjoy videos/music/photos stored on your PC on the TV when these devices are connected to the same network.

#### Browse the content on your PC to watch on TV (Windows 10)

- 01 Connect your TV and PC to the same network.
  - 02 Right-click the file you want to play and select "Cast to Device".
  - 03 Select the name of the TV you want to watch from the displayed list, and playback will start on that TV.
- Even when multiple TVs or devices are connected, the selected file is only played through one device. The playback rate may vary depending on the network connection.
  - To play on other operating systems or devices, refer to the manual of the operating system/device.

#### Browse and watch the content stored on the PC using the TV (Windows 10)

- 01 Connect your TV and PC to the same network.

- 02 Open the “Start” menu on your PC screen, search for “media streaming options” and then select the result that appears.
  - 03 Select the “Turn on media streaming” button in the window that opens.
  - 04 Allow all of the “media streaming options”.
  - 05 Select “OK” to save the settings.
  - 06 Select the connected PC in the **Home Dashboard** app on the TV, and then select and play the file you want.
- To play on other operating systems or devices, refer to the manual of the operating system/device.

## **Matters That Require Attention of Content Share**

- Check your network settings if the content share option does not work properly.
- It is recommended that you connect the device to a 5 GHz router because the performance may be affected by your wireless environment.
- May not work properly depending on the network environment.
- If multiple TVs are connected to one device, the content may not be played properly depending upon server performance.
- To watch a 1080p video through the content sharing function, a router using the 5 GHz frequency is required. If you use the existing 2.4 GHz router, the video may be laggy or not play properly.
- The Content Share function may not be supported for a router that does not support multi-cast. For more information, refer to the user guide that came with your router or contact the manufacturer.
- Captions are only supported on some connected devices.
- If you have added a caption file afterward, disable the shared folder on the PC and then enable it again.
- The DRM files in the connected device will not play.
- Even for the file format supported by the TV, the supported file format may differ depending on the connected device environment.
- If there are too many folders or files in a folder, it may not work properly.
- The information on the file imported from the connected device may not be displayed correctly.
- Depending on the encoding, some streams may not play in content sharing mode.


## **Watching PC Screen on TV**

# Watching PC Screen on TV

## Connect Wireless (Windows 10)

- 01 Click the Notification Centre icon on the taskbar on the PC screen and select Connect.
  - 02 Select the TV you want to connect to and request the connection.
  - 03 After the connection is established, the TV will display the screen of the connected PC.
- It is recommended that you always update your device to be connected to your TV to the latest OS version for a reliable connection.
  - It is recommended that you use this function at close range.
  - Start Screen Share faster by having your smart device or PC connected to the same network as the TV.
  - Though it can be connected without a wireless router, connecting your device to a 5 GHz router is recommended because the performance can be affected by the surrounding wireless environment.
  - The response rate may vary depending on the user's environment.
  - It's differ from Windows version. For more information on the device you want to connect to, refer to its user guide.
  - If connection fails repeatedly, turn off the TV and the device you want to connect to, then turn them back on and try again.

## Connect Wired







- 01 Connect your PC to the TV using an HDMI cable.
  - 02 Switch the current input source to the port where the HDMI cable is connected in the  → **Home Dashboard**.
  - 03 After the connection is established, the TV will display the screen of the connected PC.
- If there is a problem with your connection, refer to **Troubleshooting** → **Troubleshooting PC Connection Issues** in **User Guide**.


# Making the Most of Smart TV

# To Use Magic Explorer

## To Use Magic Explorer

You can run a search conveniently through various apps based on on-screen text or video information.

- 01 Magic Explorer can be used if the pointer colour of the Magic Remote changes (e.g., to the )
- 02 Press and hold the **Wheel (OK)** button on the image if you are watching a broadcast, or on the text if you are using **Guide**, **Settings**, **Sports Alert** or **Art Gallery** apps.
- 03 On the broadcast screen, keywords associated with the programme appear. On the text in the app, an icon appears that allows you to go to an item, such as Web Browser or Search.
- 04 Choose an item to use.
  - You can move an item by pressing the     buttons on the remote control.
- 05 You can exit Magic Explorer by pressing the  button on the remote control.



- You can also use this feature by pressing and holding the **OK** button on the standard remote control.
- Available features vary depending on the region or service.
- Some models may not be supported.

## Using Multi View


### Using **Multi View**

You can split the screen and use two apps simultaneously.



01 Press the  button on the remote control.

02 Select  on the screen.



① You can select a screen layout.

**Side by Side** : You can view two apps on a split-screen.

**PIP** : You can run another app on top of the current screen and view it as a pop-up screen.

② You can choose which app you wish to run alongside the app that is currently running.

- For apps that do not support **Multi View**, the recommended **Multi View** combination is displayed.
- Depending on the model, some features may not be available.

## Using **PIP** Mode



① You can move the position of the sub-screen.

② You can change the size of the sub-screen.

③ You can operate the main screen.

- ④ You can operate the sub-screen.
- ⑤ You can select the screen of which to output sound.
- ⑥ Change to **Side by Side** mode.
- ⑦ Closes the app.

## Using **Side by Side** Mode





- ① You can operate the selected screen.
- ② The sound of the selected screen is output.
- ③ Change to **PIP** mode.
- ④ Closes the app.

## Using the Room to Room Share

### Using the **Room to Room Share**

By connecting multiple TVs connected to the same network, you can send video from the TV you are watching to another TV or receive video from other TVs.

- 01 Press the  button on the remote control.
- 02 Run the **Room to Room Share** app.
- 03 Select **Connect TV** and follow the on-screen instructions to connect.



- ① You can view the TV you are currently using.
- ② Enters the Edit screen. You can view the connected TV and block or delete the connection.
- ③ You can connect a new TV by selecting **Send Screen** or **Get Screen** and select **Connect TV**.  
**Send Screen** : You can select a TV on which to continue watching the current screen.  
**Get Screen** : You can select a TV from which to bring up the screen.
- ④ Connect to the **User Guide**.
  - The **Room to Room Share** feature may be discontinued without notice.
  - Depending on the model, some features may not be available.
  - Only models that support the **Room to Room Share** feature can be connected and used.
  - Up to five connections can be made to one TV.
  - The TVs you wish to connect to must be connected to the same network.
  - The operation may not be smooth, depending on the speed or environment of the network. If the feature does not work properly, please check the network settings and WOL settings of the router.  
The operation may not be smooth on wireless networks. A wired network connection is recommended.
  - When connecting with the LG ThinQ app in **Connect TV**, all TVs to be used with **Room to Room Share** must be registered to the same LG ThinQ account.
  - You can transmit only **Live TV** or set-top box screens connected via HDMI.
  - It can only be viewed on the TV that has gotten the screen.
  - For some broadcasts, you cannot send or bring up a screen.
  - Received broadcasts may have restrictions on viewing.
  - The TV that received the video turns the screen on automatically, and the TV that sent the video turns the screen off automatically.


# Making the Most of Art Gallery

## Making the Most of Art Gallery

You can enjoy a high-definition image provided for each theme.

01 Press the  button on the remote control.

02 Run the **Art Gallery** app.




① View the built-in images for each theme.

② You can view the information and image of the focused theme in advance.

③ You can delete a downloaded theme or select the desired theme to play.

④ Closes the app.

To turn off the app from running in the background, press the  button on the remote control and select **Quit App**.

● If your remote control does not have a  button, press and hold the  button.

# Surfing the Internet on TV


## Using the Web Browser



You can enter the website when you input the web address on the URL bar.

If you input the search word, it will find the information about search word base on the search engine.



01 Press the  button on the remote control.

02 Run the **Web Browser** application.



- ① You can refresh the web page you are viewing.
  - ② You can type in a web address to navigate to a specific website or enter a search term directly.
  - ③ You can view the tabs that are currently open.
  - ④ You can zoom in or out on the screen while browsing the website.
    - Block Ads** : You can block ads within the web page you are viewing. However, this button is only displayed if  → **Settings** → **Use Block Ads** feature is set to **On**.
    - TV View** : Split the screen to display the TV screen. You can browse web pages while watching TV.
    - History** : You can view and delete the website visit history.
    - Add to bookmarks** : You can add the website you are currently viewing to your Favourites.
    - Bookmarks** : You can view and delete the list of websites you have added to your Favourites.
    - Settings** : You can change the web browser settings.
    - User Guide** : Launch **User Guide**.
    - Quit App** : Turns off the app from running in the background.
  - ⑤ Closes the app.
  - ⑥ The new tab screen shows a list of **Recommended Sites** and **Most Visited Sites**. If you do not want **Recommended Sites** to be displayed, set  → **Settings** → **Show Recommended Sites** to **Off**.  
**Recommended Sites** may vary by country and is only available in certain countries.
- The **Web Browser** app on your TV is a browser for TV, so it may work differently than the browser for your PC.
    - Some contents may not be played properly.



- Flash Plug-in is not supported, and only HTML5 media is supported.
  - Plug-in installation is not supported.
  - Media in formats other than JPEG/PNG/GIF may not be played.
  - Apps may be forced to shut down if the TV runs out of memory.
  - The fonts provided on the TV are used. Depending on the content, characters may look different from PC or mobile browsers.
  - File and font downloads are not supported.
  - Caution is required because malicious or phishing sites are not automatically blocked.
  - Some functions of Web Browser may not be supported temporarily due to external factors.
- The website can be accessed through the TV's **Web Browser** app, so care needs to be taken about children's access to harmful online contents.  
You can lock the **Web Browser** app to prevent access to harmful online contents.  
Configure the settings in  →  → **General** → **System** → **Safety** → **Application Locks**.
  - If you experience problems while using **Web Browser**, refer to **Troubleshooting** in **User Guide**.

## Changing **Web Browser** Settings

Select  → **Settings** at the top of the **Web Browser** app.

### On Startup

You can choose the page that appears when you start the **Web Browser** app.

### Search Engines

You can select a search engine to search for when entering a keyword in the address bar.

- Search engine settings may be subject to change without notice based on the supplier's circumstances.

### Show Recommended Sites

You can set whether or not to display a list of **Recommended Sites** on the new tab screen.


### Always Show Address Bar

When set to **On**, the address bar and menu bar area at the top will always be displayed.

## Automatic Web Browser Issue Report

When it is set to **On**, if a failure (malfunction, media playback failure, page loading failure, abnormal shutdown, delay in response due to insufficient memory, etc.) occurs while using the web browser, the relevant information will be automatically sent to the web browser development team at the LG Electronics headquarters (Korea). The submitted information will only be used to improve the Web Browser performance.

## Use Block Ads

When it is set to **On**, if you press the  at the top of **Web Browser**, a button to turn on or off **Use Block Ads** will appear on the screen. Turning on the **Use Block Ads** feature speeds up page loading by blocking ads included in the website.

## Site Filtering

You can register websites to block or allow.

**Approved Sites** : You can configure the settings to open the previously registered web pages only.

**Blocked Sites** : You can configure the settings to block specific websites.

- To use the **Site Filtering** function, you should enter the TV password.

## Pop-up Blocker

Blocks pop-ups that are automatically displayed by web pages.

## Private Browsing

If set to **On**, a history of website visits will not be stored.

## Do Not Track

You can request to not leave a history of your visit on the website. The operation may vary depending on the policy of the website.

## Adaptive Streaming using JavaScript

The media streaming technology using JavaScript allows you to view video with optimised resolution.

If this is set to **Off**, the resolution of the videos played in **Web Browser** is limited to 720p.

## Cookies Settings

Enables the website to store and use cookie data.

## Clear Browsing Data

**Clear Cookies** : Deletes cookie data. When deleted, you are logged out of most sites.

**Clear All Browsing Data** : Deletes all browsing history, including cookies.

# Connecting a Camera to the TV

## Connecting a Camera to the TV

By connecting a camera to the TV, you can use it for video conferencing, etc.

01 Connect the camera to the **USB IN** port.

02 Run **Home Dashboard** by pressing the  button on the remote control.

03 Select **Camera**.


- For a detailed description of the camera's functions, refer to the device's manual.
- The camera must be purchased separately.  
It is recommended that you use a product that has been tested for compatibility with LG TVs.  
Logitech C920/C920s/C922 Pro/C922x/C925e/C930c/C930e
- Depending on the installation status of the TV, the camera may not be mounted on the TV.
- The USB storage device may not work or function properly when a USB hub or extension cable is used.

## Video Conferencing

You can have a video conference using an Internet website or an app that enables video conferences.

- This function may not be available in some countries or models.
- Internet connection is required to use this feature.
- Depending on camera performance or the network environment, the image quality may not be clear.

## Making the Most of Multi View


By pressing  → **Multi View**, you can run the video screen or broadcast screen, and camera simultaneously. For more information, see **Making the Most of Smart TV** → **Using Multi View** in **User Guide**.



- This feature is available only on models that support the **Multi View** feature.

## Using Sports Alert



### Using Sports Alert

- 01 Press the  button on the remote control.
  - 02 Run the **Sports Alert** app.
  - 03 You can view the list of teams by league and detailed information.
  - 04 Press **Add** to register your preferred team or player.  
By registering a team or player, you can view live scores and upcoming match schedules. You can receive notifications while watching TV by setting a game match alarm.
- The match schedule or status may differ from actual ones depending on the circumstances of the data provider.
  - Real-time alarm may not be available when using certain apps.
  - This feature is available only when the network is connected.
  - Some models may not be supported.

## Live Plus

### Using the Live Plus Function

**Live Plus** provides an enhanced viewing experience related to the content you're watching including looking at additional information, participating in events, interacting with advertisements, etc.

- 01 Press the  button on the remote control.
  - 02 Select  → **General** → **System** → **Additional Settings**.
  - 03 Set **Live Plus** to **On**.
- Some models may not be supported.
  - You can still access some of the **Live Plus** features when using external devices such as a

set-top box.

- If you set up a universal remote control, you can use **Live Plus** even when using external devices.
- This service is provided for only select content with contracted partners.


# Settings

## Quick Settings

### To Use Setting Function Quickly

Set of light-weight controls quickly and simply such as **Picture Mode**, **Sound Out**, **Game Optimiser** and so on.

Press the  button on the remote control.



- 1 You can set **Picture Mode**.
- 2 You can set **Sound Mode**.
- 3 You can choose **Sound Out**.
- 4 Directs to the **Game Optimiser** settings.
- 5 Launch **Multi View**.
- 6 Directs to the **OLED Care** settings.
- 7 Directs to the **Network** settings.



control to run the All settings directly.

#### ④ Launch **User Guide**.

- The configurable items differ depending on model.

## Picture

### Selecting Picture Mode

 →  → **Picture** → **Select Mode**

Select the picture mode that is best suited to your viewing environment, preferences or video type.

Select a picture mode. By adjusting and setting each item in more detail based on the mode, your video is better optimised for its characteristics.

- The configurable items differ depending on model.

### When You Use Normal Signals

#### **Vivid**

Sharpens the image by increasing the contrast, brightness and sharpness.

#### **Standard**

Displays the picture with normal contrast, brightness and sharpness levels.

#### **Eco / APS**

The Energy Saver feature changes settings on the TV to reduce power consumption.

- The configurable items differ depending on model.

#### **Cinema**

Suitable picture for movies.

#### **Sports / Football / Cricket**

Suitable picture for sports games. Sharpens the image of rapid movements such as kicking or throwing a ball.

- The name of the sport may differ depending on region.

## Game Optimiser

Suitable picture for gameplay.

## FILMMAKER MODE

Provides optimized Cinema Picture quality certified by UHD Alliance, the standard setting body for UHD-related technologies.

- To auto-switch to **FILMMAKER MODE** when a signal that can be operated with this mode is entered, set **FILMMAKER MODE Auto Start** to **On**.

## Expert (Bright space, daytime) / Expert (Dark space, night)

This mode is suitable for movies, etc. viewed in a dark environment.

**Expert (Dark space, night)** has lower color temperature than **Expert (Bright space, daytime)**.

Select a mode that is suitable for the movie you are watching.

ISFccc : Imaging Science Foundation Certified Calibration Control

## When You Use the HDR/Dolby Vision Signals

### Vivid

Sharpens the image by increasing the contrast, brightness and sharpness.

### Standard

In a normal viewing environment, it opens a screen that can properly show the expressiveness and brightness of HDR.

### Cinema Home

The screen appears as a bright and clear screen than the **Cinema**.

### Cinema


Suitable picture for HDR video signal.

## Game Optimiser

Suitable picture for gameplay.

## FILMMAKER MODE

Provides optimized Cinema Picture quality certified by UHD Alliance, the standard setting body for UHD-related technologies.

- To auto-switch to **FILMMAKER MODE** when a signal that can be operated with this mode is entered, set **FILMMAKER MODE Auto Start** to **On**.
- If the HDR/Dolby Vision video signal is input to the models that do not support the HDR/Dolby Vision technology, It will be provide normal signals picture mode options.
- Depending on the input signal, the available picture modes may be different.
- When watching online service content, the Picture Mode may be changed to match the content being shown.
-  Expert is an option that allows a picture quality expert to fine-tune the quality of the standard picture. Thus, it may not be effective for a normal picture.
- **Select Mode** change may modify **Energy Saving** and **Motion Eye Care** settings and it can affect energy consumption. You can change the settings in **General** → **OLED Care** → **Device Self Care** → **Energy Saving** and **Picture** → **Advanced Settings** → **Brightness** → **Motion Eye Care**.

## Setting the Screen Size

 →  → **Picture** → **Aspect Ratio** → **User Selection**

You can change the screen size according to the type of content you are watching.

### 16:9

Displays an aspect ratio of 16:9.

### Original

The optimal screen ratio changes depending on the input image signal.

### 4:3

Displays an aspect ratio of 4:3.

### Vertical Zoom

You can adjust the vertical dimension of the screen and align the screen vertically by using **Adjust Zoom Ratio** and **Adjust Screen Position**.

### 4-Way Zoom

You can adjust the horizontal/vertical/diagonal dimensions of the screen and align the screen horizontally/vertically by using **Adjust Zoom Ratio** and **Adjust Screen Position**.

- The configurable items differ depending on model.

- The picture may get distorted while zooming in or out.
- Selecting a different screen size from the original size may cause the image to look different.
- Depending on the combination of picture format and screen size, the edges may be hidden or shown in black, or both sides of the picture may flicker. Also, when selecting an item shown on the broadcast screen, the outline may not be aligned correctly.
- Depending on the input signal, the available screen sizes may be different.

## View Screen with **Just Scan**

 →  → **Picture** → **Aspect Ratio** → **Just Scan**

If you turn this feature **On**, you can view the content in the aspect ratio that is in the broadcast signal or content source. If the edge of the screen is not clean, please turn it **Off**.

If set to **Auto**, the feature switches between **On** or **Off** status depending on the information contained in the video signal.

- The items that can be selected may vary depending on the current input.

## Adjusting the Brightness of a Picture


 →  → **Picture** → **Advanced Settings** → **Brightness**

You can adjust the brightness of the entire screen.

### Panel Brightness

Controls the level of screen brightness by adjusting the backlight. The closer to 100, the brighter the screen.

- Decrease the **Panel Brightness** to reduce energy consumption.
- Depending on the **Energy Saving (Auto/Maximum)**, you may not be able to adjust the **Panel Brightness**.

In this case, navigate to  →  → **General** → **Energy Saving** → **Energy Saving Step** and set to **Off** or **Minimum**.

- Depending on your TV model, you might not have the **Panel Brightness** setting.

### OLED Pixel Brightness

Adjusts the display brightness by varying the brightness of the OLED panel.

- Depending on the **Energy Saving (Auto/Maximum)**, you may not be able to adjust the **OLED Pixel Brightness**.

In this case, navigate to  →  → **General** → **OLED Care** → **Device Self Care** → **Energy**

**Saving** → **Energy Saving Step** and set to **Off** or **Minimum**.

- Depending on your TV model, it might not have the **OLED Pixel Brightness** setting.

## **Adjust Contrast**

Adjusts the contrast of the bright and dark areas of the picture. The closer to 100, the higher the contrast.

## **Black Level**

Adjusts the brightness of dark areas of the screen. The closer it is to 100, the lighter the screen becomes.

## **Auto Dynamic Contrast**

Corrects the difference between the bright and dark sides of the screen for optimal results depending on the brightness of the picture.

## **Dynamic Tone Mapping**

Suitable contrast settings based on image brightness of the HDR content.

## **Peak Brightness**

Adjust peak brightness for the brightest luminance.

## **Gamma(Adjust Brightness)**

Adjusts the medium brightness of the picture.

- **BT.1886** expresses the gradation in ITU-R BT.1886, which is an international standard.

## **Video Range**

Adjusts the darkness of the screen in order to display a perfect black. Select **Video Range** to match the colour range of the external input device.

- This feature can be used while watching content through an external input.

## **LED Local Dimming**

Maximizes the contrast ratio by making the bright side of the screen brighter and the dark side of the screen darker.

- **Off** : Disables the **LED Local Dimming** function.
- **Low / Medium / High** : Changes the contrast ratio.



- Turning this option **Off** may increase energy consumption.

## Motion Eye Care

Automatically adjusts brightness and reduces image blur based on image data to reduce eyestrain.

- Turning this option **Off** may increase energy consumption.
- Depending on the input signal or the selected picture mode, the available options may differ.
- The configurable items differ depending on model.

## Adjusting the Colour of an Picture

⚙️ → ⓘ → **Picture** → **Advanced Settings** → **Colour**

### Colour Depth

Tones down or up the colours displayed on the screen. The closer to 100, the deeper the colour.

### Tint

Adjusts the colour balance between red and green displayed on the screen. The closer to Red 50, the more red the colour will be. The closer to Green 50, the more green the colour will be.

### Colour Gamut

Selects the range of Colours to display.

#### Native

Displays more vivid and richer colour.

#### Auto Detect

It automatically sets the **Colour Gamut** to match the signal.

#### Dynamic

It expands the **Colour Gamut** to match the scene.

#### Adobe RGB

Sets the **Colour Gamut** to Adobe RGB standards.

## Fine Tune

This is used when experts control it by using a test pattern. You can control it by selecting areas of six colours (**Red/Green/Blue/Cyan/Magenta/Yellow**).

For normal images, adjustments may not result in noticeable colour changes.

### Colour Adjustment

Adjusts the Colour and saturation of the picture to make the image more Colourful and lively.

### Select Colour

From **Red/Green/Blue/Cyan/Magenta/Yellow**, select a tone to adjust.

### Adjust Saturation / Adjust Tint / Adjust Luminance

Adjust the chroma/tint/luminance of the tone in the range of -30 to +30.

## White Balance

The function to adjust each colour to be reproduced more accurately based on white allows you to adjust the overall colour tone of the screen to your preference.

### Colour Temperature

You can set the colour to make the display look cooler or warmer.

### Method

This method is used for fine-tuning the color temperature setting. You can control the colour temperature at two points of the bright part and dark part of the video if you select **2 Points**, at each point of 10 levels if you select **10 Points Signal Level(%)**, and at each point of 22 levels of the video if you select **22 Points Signal Level(%)**.

### Point

Select screen brightness for color temperature adjustment.

If **Method** is set to **2 Points**, use Low to select shadows and High to select highlights.

If **Method** is set to **10 Points Signal Level(%)**, you can select brightness using numbers indicating 10 levels.

When the **Method** is set to **22 Points Signal Level(%)**, you can select the brightness with the 22 levels of brightness.

## Signal Level(%)

Select screen brightness for color temperature adjustment.

If **Method** is set to **10 Points Signal Level(%)**, you can select brightness using numbers indicating 10 levels.

When the **Method** is set to **22 Points Signal Level(%)**, you can select the brightness with the 22 levels of brightness.

## Show brightness level at the maximum signal level(%)

Adjusts the luminance of the highest 100% signal level.

## Adjust brightness level at the selected signal level(%)

The brightness of the selected signal level can be adjusted.

- You can do these settings only when the **Picture** → **Select Mode** is the **Cinema**, **Expert (Bright space, daytime)** or the **Expert (Dark space, night)** and when the **Method** is set to **10 Points Signal Level(%)** or **22 Points Signal Level(%)**.

## Red / Green / Blue

Adjust the color temperature of the selected point.

Adjust the intensity of **Red/Green/Blue** in the range of -50 to 50.

You can adjust respective values for the brightness selected in **Point**.

- Depending on the input signal or the selected picture mode, the available options may differ.
- The configurable items differ depending on model.

## Adjusting the Contrast of a Picture

 →  → **Picture** → **Advanced Settings** → **Clarity**

You can adjust the contrast of a Picture to show it more clearly.

### Adjust Sharpness

Adjusts the sharpness of the image. The closer to 50, the sharper and clearer the image.

### Super Resolution

Adjusts the resolution to make dim and blurred images clearer.

### Noise Reduction

Removes small dots that stand out so as to make the image clean.

### **MPEG Noise Reduction**

Reduces the noise produced during the creation of digital video signals.

### **Smooth Gradation**

It reduces the phenomenon that the outline of the image is rugged and in a staircase pattern and displays a smoother screen.

### **Real Cinema**

Optimise display for movies.

### **TruMotion**

Suitable the image quality of fast-moving pictures.

- **Off** : Turns off the **TruMotion**.
- **Cinematic Movement** : Adjusts the shaking of the motion on the screen to make it feel like you are in a movie theatre.
- **Natural** : Sets images with a lot of motions to look natural and clear.
- **Smooth Movement** : Softens fast-moving pictures.
- **User Selection** : Sets **TruMotion** manually.
  - **De-Judder** : Adjusts juddering on the screen.
  - **De-Blur** : Reduces the blurring effects of motion.
  - **OLED Motion / OLED Motion Pro / Motion Pro / NanoCell Motion Pro** : You can make your video clearer by eliminating afterimages.
- The advanced settings can be changed only in **User Selection** mode.
- Depending on the input signal or the selected picture mode, the available options may differ.
- The configurable items differ depending on model.

## **Applying the Current Picture Settings to All Inputs**

 →  → **Picture** → **Advanced Settings** → **Apply to All Inputs**

The settings you specify only apply to the currently selected input mode.

To apply your current picture settings to all input modes, select **Apply to All Inputs**.

## Resetting Picture Mode

 →  → **Picture** → **Advanced Settings** → **Reset**

If you want to reset the image settings to the factory defaults after configuring the image settings, select reset for each image mode.

## FILMMAKER MODE Auto Start

 →  → **Picture** → **Advanced Settings** → **FILMMAKER MODE Auto Start**

If set to **On**, **Picture Mode** will automatically be changed to **FILMMAKER MODE** when a signal that can be operated with **FILMMAKER MODE** is entered.

- While this mode effectively conveys the creator's intention, it may appear darker than other **Picture Mode**.

## To Use Reduce Blue light Feature

 →  → **Picture** → **Advanced Settings** → **Reduce Blue light**

The colour temperature will be adjusted to reduce eye fatigue.

### On

The colour temperature of your TV screen is adjusted.

### Off

Turns off the **Reduce Blue light**.

- Some models may not be supported.

# Sound

## Select Mode

 →  → **Sound** → **Select Mode**

You can select the most suitable sound mode for each genre.

### AI Sound / AI Sound Pro

Depending on the content you watch, you can enjoy the optimised sound and virtual surround in real time.

### **Standard**

Optimises the sound for all types of content.

### **Cinema**

Optimises the sound for cinemas.

### **Clear Voice / Clear Voice Pro**

Boosts voice clarity.

### **Sports / Football / Cricket**

Optimises the sound for sports games.

- The name of the sport may differ depending on region.

### **Music**

Optimises the sound for music.

### **Game Optimiser**

Optimises the sound for gameplay.

- This setting only applies to the internal speakers of the TV or **HDMI (eARC/ARC)** connected devices that support **Sound Mode Share**.
- The configurable items differ depending on model.

### **Use TV Speaker**

 →  → **Sound** → **Sound Out** → **Use TV Speaker**


Audio is played through the TV's internal speakers.

### **Use Wireless Speaker**

 →  → **Sound** → **Sound Out** → **Use Wireless Speaker**

### **Bluetooth Device**

Wirelessly connect a Bluetooth audio device to enjoy TV sound more conveniently. Refer to the user manual of the Bluetooth audio device for details on how to connect and use the device.

- Press  to view the connected devices or the devices that can be connected to connect any one of them.
  - For some Bluetooth devices, the device volume can be controlled by selecting from the connection list.
  - LG Sound Sync devices will automatically try to connect to the recently used devices when you turn the TV on.
  - We recommend that you connect an LG audio device that supports LG Sound Sync, using LG TV mode or LG Sound Sync mode on device.
- Some models may not be supported.
  - The audio codec that can be output via Bluetooth is SBC/aptX™.
  - If the device fails to connect, check the power of the device to connect to and check if the audio device is working properly.
  - Using a Bluetooth headset is recommended when you connect two Bluetooth devices.
  - Depending on the type of the Bluetooth device, the device may not connect correctly or an abnormal behavior may occur such as unsynchronized video and audio.
    - The mobile-only headsets may not work.
    - If two different Bluetooth devices are connected and used at the same time, the voice may not match.
  - Sound may stutter or sound quality may be reduced if:
    - the Bluetooth device is too far from the TV;
    - there are obstacles between the Bluetooth device and the TV; or
    - used together with radio equipment such as a microwave oven or wireless LAN
  - If the **Picture → Select Mode** is set to **Game Optimiser** and **Sound Out** is set to **Bluetooth Device**, the **Picture → Select Mode** changes to **Standard**.
  - If you continue to experience problems, we recommend using a wired connection. ( Optical digital, **HDMI (eARC/ARC)** port )

### WiSA Speakers

You can wirelessly connect the TV to the **WiSA Speakers** to enjoy high-quality sound. Select  to adjust detailed settings for **WiSA Speakers**.

- Some models may not be supported.

- To use the WiSA speakers, you need to connect the exclusive dongle.
- Connection issues between the WiSA Dongle and WiSA Speaker may occur in environments with wireless interference. In this case, contact the speaker manufacturer.
- For more information on the purchase of WiSA authorized products, check on [www.wisaassociation.org](http://www.wisaassociation.org).

### Mobile Device

If you install the LG ThinQ app on a smart device and connect it to your TV, you can use the device as a speaker for the TV.

## Use Wired Speaker

⚙️ → ⓘ → **Sound** → **Sound Out** → **Use Wired Speaker**

### Optical Out Device

You can connect an audio device that supports Optical to the optical digital audio output port to enjoy your TV's sound in richer quality and greater convenience.

- Only available for models with an optical digital port.
- For some devices, you can adjust the volume using the TV remote control.

### HDMI(ARC) Device

Sound from the TV can be output through an external audio device connected via a **HDMI (eARC/ARC)** port.

- Select **HDMI(ARC) Device** to automatically turn on SIMPLINK. Once SIMPLINK is turned off, the output speaker settings automatically revert to the default settings for uninterrupted audio output.

### Audio Out Device / Wired Headphones

Select **Wired Headphones** or **Audio Out Device** to optimise audio output according to the device connected.

- Some models may not be supported.
- If you connect the wired headphones while the TV is powered on, it automatically detects the wired headphones and redirects audio through them.

## Use External Speakers with TV Speaker








## → → **Sound** → **Sound Out** → **Use External Speakers with TV Speaker**

Audio can be played through the multiple devices simultaneously.

### **Bluetooth Device + TV Speaker**

Both the internal speaker of the TV and the Bluetooth speaker can be used to output the sound at the same time or a surround sound can be used.

Up to two Bluetooth devices of the same model can be connected.

- 01 Select  to connect a Bluetooth speaker.
  - 02 Run **Audio Delay** to synchronize the TV's internal speaker with the Bluetooth speaker. You can adjust the sync automatically or manually.
- When you set **Sound Out** as **Bluetooth Device + TV Speaker**, if **Picture** → **Select Mode** is **Game Optimiser**, it will be changed to **Standard** and **Dolby Atmos** will be turned off.
  - While using Screen Share function, the video and audio may be out of sync. We recommend using **Use TV Speaker** in **Sound Out**.
  - To adjust the volume with the volume button on your Bluetooth device, set  →  → **General** → **Accessibility** → **Enjoy TV Sound Together** to **On**. For Bluetooth devices that do not have volume buttons, you can adjust the volume of the device in the detailed settings screen of **Bluetooth Device + TV Speaker**.
  - If  →  → **General** → **Accessibility** → **Enjoy TV Sound Together** is set to **On**, only one Bluetooth device can be connected.
  - Depending on the type of your Bluetooth device, two devices may not be connected at the same time.
  - Depending on the type of the Bluetooth device, the device may not connect correctly or an abnormal behavior may occur such as unsynchronized video and audio.

### **Optical Out Device + TV Speaker**

Audio is played through the TV's built-in speakers and the audio device connected to the digital optical audio output port simultaneously.

### **Wired Headphones + TV Speaker**

Audio is played through the TV's internal speakers and the **Wired Headphones** simultaneously.

- Some models may not be supported.
- If you connect the wired headphones while the TV is powered on, it automatically detects the wired headphones and redirects audio through them.

## Dolby Atmos

 →  → **Sound** → **Advanced Settings** → **Dolby Atmos**

Dolby Atmos is based on the concept of audio objects. Any sound can be mixed as a single audio element, an object, that's independently placed in three-dimensional space. Your new LG TV has been enabled with the latest Dolby Atmos sound technology. Dolby Atmos is the ultimate sound experience which creates moving audio that flows around you using TV speakers.

The menu, which acts as On/Off, the default value is **On**. Given the effect of the **Dolby Atmos**, Dolby Atmos content applies. (Menu when turned **On**)

- Some Dolby Atmos contents may not be played.

## Balance

 →  → **Sound** → **Advanced Settings** → **Balance**

You can adjust the volume of the left and right speakers.

- This setting is only available for Internal TV Speaker.

## Equalizer

 →  → **Sound** → **Advanced Settings** → **Equalizer**

You can adjust the sound by increasing or decreasing the output of the specific frequency range of the voice signal.

- This option can be enabled if **Sound** → **Select Mode** is set to **Standard**.
- This setting only applies to the internal speakers of the TV or **HDMI (eARC/ARC)** connected devices that support **Sound Mode Share**.

## Applying the Current Sound Settings to All Inputs

 →  → **Sound** → **Advanced Settings** → **Apply to All Inputs**

The settings you specify only apply to the currently selected input mode.

To apply your current sound settings to all input modes, select **Apply to All Inputs**.

## Initializing Sound Settings

 →  → **Sound** → **Advanced Settings** → **Reset**

Restores the detailed effect settings for the **Standard** sound mode to the initial settings.

- This setting only applies to the internal speakers of the TV or **HDMI (eARC/ARC)** connected devices that support **Sound Mode Share**.

## Installation Type

 →  → **Sound** → **Advanced Settings** → **Installation Type**

This mode optimises the sound based on the TV setup.

### Stand

Select this if the TV is installed in stand-type.

### Wall-mounted

Select this if the TV is installed in wall-mounted type.

- This setting is only available for Internal TV Speaker.

## Automatic Volume Adjustment

 →  → **Sound** → **Advanced Settings** → **Automatic Volume Adjustment**

If it is set to **On**, the volume will be automatically adjusted to a suitable level for each content you watch to help you enjoy watching more comfortably.

- This setting only applies to the internal speakers of the TV or **HDMI (eARC/ARC)** connected devices that support **Sound Mode Share**.

## DTV Audio Setting

 →  → **Sound** → **Advanced Settings** → **DTV Audio Setting**

When different audio types exist in an input signal, this function allows you to select the audio type you want.

If set to **Auto** the search order is AC4 → HE-AAC → Dolby Digital Plus → Dolby Digital → MPEG and output is produced in the first Audio Format found.

- The following search order may change depending on the country : AC4 → HE-AAC → Dolby Digital Plus → Dolby Digital → MPEG.
- If the selected Audio Format is not supported, another Audio Format may be used for output.

- Some models may not be supported.

## Adjusting AV Synchronization

⚙️ → ⓘ → **Sound** → **Advanced Settings** → **Match Screen and Sound**

Adjusts the synchronization of the sound from the speaker that is working. The closer the value is set to 60, the slower the voice output speed will be than the default speed.

If you select **Bypass**, Outputs the broadcast signals or the sound from external devices without any audio delay. The audio may be output before the video because of the time the TV takes to process the video input.

- Available options vary by **Sound Out** setting.

## Select HDMI Input Audio Format

⚙️ → ⓘ → **Sound** → **Advanced Settings** → **Select HDMI Input Audio Format**

You can set the audio format for each HDMI input.

When connected to devices or content that support the latest surround sound technology, setting to **Bitstream** will enable you to listen to the intended sound quality. When the voice delivered through the HDMI port is not synchronized, set it to **PCM**.

## Sound Mode Share

⚙️ → ⓘ → **Sound** → **Advanced Settings** → **Sound Mode Share**

Plays the sound mode applied to the TV speakers on the soundbar, or selects the sound mode of the soundbar on the TV to play.

### Off

Turns off the **Sound Mode Share**.

### Enjoy TV Sound Mode

The **Sound** → **Select Mode** set on the TV is applied to the soundbar to deliver a variety of sounds.

### Enjoy Soundbar Sound Mode

You can set the sound mode of the soundbar in **Sound** → **Select Mode** on the TV.

- The name of the sound mode displayed on the soundbar may differ from that of the **Sound** → **Select Mode** on the TV, depending on the model. In this case, it will be matched with the Sound Mode with similar effects.

## LG Sound Sync

⚙️ → ⓘ → **Sound** → **Advanced Settings** → **LG Sound Sync**

Connect the LG Sound Sync device to the optical digital input port and set **Sound Out** to **Optical Out Device**.

By setting this feature to **On**, you can adjust the volume of the connected LG Sound Sync device using a TV remote control.

- If the auto-power feature of the sound bar that supports LG Sound Sync is set to On, the sound bar will be turned on or off together when the TV is turned on or off.

## Setting Digital Sound Output

⚙️ → ⓘ → **Sound** → **Advanced Settings** → **Digital Sound Output**

You can configure the **Digital Sound Output** settings.

- This setting is only available when ⚙️ → ⓘ → **Sound** → **Sound Out** → **Use Wired Speaker** is set to **Optical Out Device/HDMI(ARC) Device**.
- When **Pass Through** is enabled, sound effects may not be output.
- The codec output with a device may differ from input signals.

	Sound Input	Digital Sound Output
<b>PCM</b>	All	PCM
<b>Auto / Pass Through</b>	MPEG	PCM
	Dolby Digital	Dolby Digital
	Dolby Digital Plus / Atmos	(Optical) Dolby Digital (HDMI ARC) Dolby Digital Plus / Atmos
	Dolby TrueHD (HDMI only)	(Optical) Dolby Digital (HDMI ARC) Dolby Digital Plus / Atmos

---

HE-AAC / AAC

(Optical) Dolby Digital  
(HDMI ARC) Dolby Digital / Dolby  
Digital Plus

---

- Dolby TrueHD , HDMI eARC , Dolby Atmos : Some models may not be supported.
- When connected with HDMI eARC, the output audio type will depend on the audio type supported by the connected device.
  - Depending on the device connected and input audio type, it can be output as Dolby Metadata-Enhanced Audio Transmission PCM (Dolby MAT PCM).
  - If **Digital Sound Output** is set to **Pass Through** and HDMI input is Dolby TrueHD or Multi-Channel PCM, audio can be output as Bypass.

## Using eARC Supported Audio Device

 →  → **Sound** → **Advanced Settings** → **eARC Support**

eARC is a technology that can send and receive more sound information faster thanks to its wider bandwidth than that of the conventional ARC. You can enjoy TV sound with higher quality than ARC through a connected audio device.

- 01 Connect an audio device that supports eARC to the **HDMI (eARC/ARC)** port.
- 02 Go to **Sound Out** → **Use Wired Speaker** and choose **HDMI(ARC) Device**.
- 03 Set **eARC Support** to **On**.

## Always Ready

### Always Ready

 →  → **General** → **Always Ready**



Set **Enable the function** to **On**.

Turning off the TV switches it to **Always Ready** and displays the selected screen wallpaper, and then you can use voice recognition or output sound from your smart device to the TV speaker.

You can also turn on the TV with the voice recognition feature of an external AI speaker connected to the TV.

Selecting **Use Always Ready without wallpaper** enables **Always Ready** to be used without displaying the wallpaper.

For more information, see **Getting Started with LG webOS TV → Using Always Ready** in **User Guide**.



- Energy consumption may increase during **Always Ready**.
- To use voice recognition in **Always Ready**, set **Use Hands-free Voice Control** to **On** in  →  → **General** → **AI Service** → **Voice Recognition Settings**.
- Some models may not be supported.

## AI Service

### AI Picture Pro

 →  → **General** → **AI Service** → **AI Picture Pro**

When set to **On**, artificial intelligence, which has been trained with LG Electronics' deep learning techniques, finds the most suitable resolution according to the video type and displays it using vivid, realistic, and rich colours.

- It is supported for only digital broadcasting, videos of a USB memory device, and HDMI video input.
- If  →  → **Picture** → **Select Mode** is **Game Optimiser**, you cannot set up this feature.
- It does not work with copy protected content.

### AI Brightness Settings

 →  → **General** → **AI Service** → **AI Brightness Settings**

Set to **On**. AI adjusts the dark areas according to the brightness around your TV and specific contents.

### AI Genre Selection

 →  → **General** → **AI Service** → **AI Genre Selection**

When set to **On**, the image quality is automatically optimised for the genre of the content by the artificial intelligence.

- It does not work with copy protected content.

## AI Sound / AI Sound Pro

⚙️ → ⓘ → **General** → **AI Service** → **AI Sound / AI Sound Pro**

If set to **On**, the optimal sound and realistic surround effects are provided per the content based on artificial intelligence.

- This setting only applies to the internal speakers of the TV or **HDMI (eARC/ARC)** connected devices that support **Sound Mode Share**.
- When this feature is set to **On**, ⚙️ → ⓘ → **Sound** → **Select Mode** is changed to **AI Sound/AI Sound Pro**.
- The configurable items differ depending on model.

## AI Acoustic Tuning

⚙️ → ⓘ → **General** → **AI Service** → **AI Acoustic Tuning**

With the **AI Acoustic Tuning** feature, you can detect the space where your TV is installed using your Magic Remote's microphone to optimise the audio of your TV for your environment.

Select **Start New Sound Tuning** to measure the space in which the TV is installed. When the initial detection is complete, you can select your desired audio mode.

- **Off** : This option disables the use of **AI Acoustic Tuning**-adjusted audio. Selecting this option outputs your TV's default sound without making any adjustments to it.
- **Standard** : Selecting this option outputs **AI Acoustic Tuning**-adjusted audio in Standard mode. This mode provides a clean and natural sound.
- **Bass Boost** : Selecting this option outputs **AI Acoustic Tuning**-adjusted audio with an emphasis on bass.
- **Treble Boost** : Selecting this option outputs **AI Acoustic Tuning**-adjusted audio with an emphasis on treble.
- If there is more than a library noise level (over 30 ~ 40 dBA), we recommend that you install from within 3 metres.
- This function may not work properly
  - The background noise is too large over 40 dBA.
  - TV and Magic Remote distance 5 metres or more.

## Viewing Voice Recognition Help



⚙️ → ⓘ → **General** → **AI Service** → **Voice Recognition Help**

It shows a list of voice commands the TV can perform.

## Using **Voice Recognition Settings**

⚙️ → ⓘ → **General** → **AI Service** → **Voice Recognition Settings**

You can apply settings for voice recognition features.

## **AI Recommendation**

⚙️ → ⓘ → **General** → **AI Service** → **AI Recommendation**

You can get content recommendation messages according to your content viewing history and app usage history.

## **Alarm**

### **Smart Tips**

You can get an introduction to smart features you can use when watching TV or using an app.

### **Next Picks**

You can get recommendations based on your TV viewing patterns.

- This feature may not be available in some countries.

### **Sports Alert**

Move to the **Sports Alert** app. You can check information about sports events and set alarms.

For more information, see **Making the Most of Smart TV** → **Using Sports Alert** in **User Guide**.

## **Usage Data Management**

### **Reset Usage Data**

It resets the content view history and the app usage history. If you reset them, it takes some time to receive recommendations for contents again.

- The configurable items differ depending on model.

# Game Optimiser





## Game Optimiser

Sets up the features for an immersive experience when you play with a video game console.

01 Press the  button on the remote control.

02 Select **Game Optimiser**.

03 Selecting **On** turns on all related settings.

- It only works with HDMI inputs.
- If you set  →  → **Picture** → **Select Mode** to a mode other than **Game Optimiser**, some items in **Game Optimiser** cannot be set.
- If you turn this feature **On**, you cannot change some video settings items.
- When **Game Optimiser** is set to **On**, audio delays may occur if you set **Sound Out** to **Bluetooth Device/WiSA Speakers/Optical Out Device/HDMI(ARC) Device**. Switch to **Use TV Speaker** or change  →  → **Sound** → **Advanced Settings** → **Select HDMI Input Audio Format** to **PCM**.
- The configurable items differ depending on model.

## Game

### Game Genre

You can optimise the screen depending on the genre of the game.

### OLED Motion / OLED Motion Pro

You can make your video clearer by eliminating afterimages.

### Reduce Blue Light

You can adjust the blue light output to rest your eyes while watching the screen.

### Dark Room Mode

You can adjust the brightness of the entire screen to reduce eye strain in a dark environment or when watching for a long time to make the screen easier to watch.

### Prevent input delay (input lag)

Minimize the input delay according to the image signal.



## Game Dashboard

If you set this option to **On**, you can use the **Game Dashboard** feature.

- Please see **Settings** → **Quick Settings** → **Game Dashboard** of **User Guide** for more information about **Game Dashboard**.

## AI Game Sound

Optimises the sound for gameplay.

- When this feature is set to **On**,  →  → **Sound** → **Select Mode** is changed to **Game Optimiser**.
- This setting only applies to the internal speakers of the TV or **HDMI (eARC/ARC)** connected devices that support **Sound Mode Share**.

## VRR

This reduces screen cracking and video lagging during game play.

## VRR & G-Sync

NVIDIA's display adaptive sync technology adjusts frames to minimize screen tearing and stuttering.

## AMD FreeSync Premium

AMD's display adaptive sync technology adjusts the injection rate to minimize screen breaks and stuttering.

## Fine Tune Dark Areas

You can calibrate the brightness of the dark areas with **VRR**, **VRR & G-Sync** or **AMD FreeSync Premium** set to **On**.

- It may not operate normally depending on the features or settings of the connected PC or game console.

## Menu Colour

Menu colour of **Game Optimiser** and **Game Dashboard** can be changed.

## User Guide

Move to the **User Guide** app.

## Picture

### Black Stabiliser

You can fine-tune dark areas.

### White Stabiliser

You can fine-tune light areas.

### Adjust Contrast

Adjusts the contrast of the bright and dark areas of the picture.

### Black Level

Adjusts the overall screen brightness.

You may use the **Black Level** settings particularly to set the dark part of the image.

### Adjust Sharpness

Adjusts the sharpness of the image.

### Colour Depth

Tones down or up the colours displayed on the screen.

### Dynamic Tone Mapping

Suitable contrast settings based on image brightness of the HDR content.

### Reset

You can reset the settings.

### Wide Aspect Ratio

You can set the screen ratio optimised for the game.

### Screen Position

You can change the position of the screen when you set it to a widescreen ratio.

### Advanced Picture Settings

Move to the  →  → **Picture** → **Advanced Settings**.

# OLED Care

## OLED Care

⚙️ → ⓘ → **General** → **OLED Care**

It provides various premium care services for OLED TV users.

### Care Picture Settings

It sets the screen mode suitable for your viewing pattern.

- **Picture** → **Select Mode** and **Device Self Care** → **Energy Saving** cannot be set while using the **Care Picture Settings**.

#### Off

Turns off the **Care Picture Settings**.

#### Comfort Mode

Displays the picture with normal contrast, brightness and sharpness levels.

#### Theatre Mode

Suitable picture for movies.

#### Kids Care Mode

It adjusts the blue light to make the screen easier for children to view.

## Device Self Care

It provides multiple features to optimise the TV's condition.

### Memory Optimiser

Optimise your TV by cleaning up unused apps or unnecessary memory.

### Screen Self-diagnosis

After running a test to verify that the image signal is output normally, you can select whether there is an error with the signal on the screen.

If there are no problems in the test, check the connected external device or broadcast signal.

## Sound Self-diagnosis

Start the Sound Test to check that the sound signal output is normal, and then select whether there is an error.

If there are no problems in the test, check the connected external device or broadcast signal.

## Energy Saving

Reduces power consumption by adjusting screen brightness.

### Energy Saving Step

- **Auto** : TV sensor detects the ambient lighting and automatically adjusts the screen brightness.
  - Some models may not be supported.
- **Off** : Turns off the **Energy Saving Step**.
- **Minimum / Medium / Maximum** : Use the power saving feature according to **Energy Saving Step** set on TV.

### Minimum Brightness

You can set how dark the screen is when the **Energy Saving Step** is set to **Auto**.

### Auto Power Off

When the TV is on, it turns off automatically if you do not press any button within the set period of time.

- Some models may not be supported.

### Screen Off

Screen is turned off and only sound is played.

Press any button except the power and the volume buttons to turn the screen back on.

- Some models may not be supported.
- If you use **Energy Saving Step** function, brightness of your TV will be affected.

## OLED Panel Care

With **OLED Panel Care**, you can improve image quality issues related to image sticking when the screen has been on for a certain amount of time.

### Pixel Cleaning

It calibrates any issues that may arise on the screen when your TV has been turned on for a long time.

Calibration may take more than an hour.

- Do not unplug the power cord while it is in progress.
- If you power on the TV, the **Pixel Cleaning** will stop operating.

### Screen Move

This moves the screen slightly at regular intervals to prevent image sticking on the display panel.

### Adjust Logo Brightness

Adjust the luminance of static images such as logos within content to correct potential picture quality issues.

### Care Recommendations

You can turn the Care Recommendations ON or OFF.

# Family Settings

## Usage Limits Setting

 →  → **General** → **Family Settings** → **Usage Limits Setting**

You can use the TV in the set time period only. Outside of the set time period, you must enter your password to use the TV.

01 Set **Enable the function** to **On**.

02 Set **Start Time** and **End Time**.

Selecting **Repeat** will activate this feature every day.

03 Select **Set**.

- For instructions on how to reset the password, refer to **Settings** → **System** → **Safety** in

## Eye Care Mode

⚙️ → ⓘ → **General** → **Family Settings** → **Eye Care Mode**

Set **Enable the function** to **On**. A screen with lowered blue light is displayed for the protection of your eyes.

- Using **Eye Care Mode** sets ⚙️ → ⓘ → **Picture** → **Advanced Settings** → **Reduce Blue light** to **On**.

## Volume Limit Mode

⚙️ → ⓘ → **General** → **Family Settings** → **Volume Limit Mode**

Set **Enable the function** to **On**. The volume cannot be raised above a certain level for the protection of your hearing.

- **Volume Limit Mode** may not work for audio devices connected to the optical digital/**HDMI (eARC/ARC)**/headphone port.

## Screen Time Reports

⚙️ → ⓘ → **General** → **Family Settings** → **Screen Time Reports**

You can check your TV usage time.

# Programmes

## Automatically Setting Up Programme

⚙️ → ⓘ → **General** → **Programmes** → **Programme Tuning & Settings** → **Auto Tuning**

Automatically tunes the programmes.

- 01 Select Country where the TV is used. Programme settings change depending on the country you choose.
- 02 Initiate **Auto Tuning**.
- 03 Select programme tuning modes.
- 04 Set Auto Tuning following screen instructions.



- If Input Source is not connected properly, programme registration may not work.
- **Auto Tuning** only finds programmes that are currently broadcasting.
- If **Safety** is turned on, a pop-up window will appear asking for password.

## Set Cable Setting

When searching for programmes using FULL setting it can take a long time. The following values are needed in order to search all available programmes quickly and correctly. The commonly used values are provided as “default”. The configurable items differ depending on **Type**.

### Frequency (kHz)

Enter a user-defined frequency.

### Symbol Rate (kS/s)

Speed at which a device such as modem sends symbols to a programme.

### Modulation

Loading of audio or video signals onto carrier.

### Network ID

Unique identifier allocated for each user.

### Start Frequency (kHz)

Enter a user-defined start frequency range.

### End Frequency (kHz)

Enter a user-defined end frequency range.

## Set Satellite Setting

You can add/delete/set the satellite you want.

- This function only works when the programme mode is satellite.

### Satellite

Select your desired Satellite.

## LNB Frequency

Select one value from 9750/10600, 9750/10750, 9750, 10600, 10750, 11300, 5150, MDU1, MDU2, MDU3, MDU4, MDU5. If you select 9750/10600, 9750/10750(MHz), **22kHz Tone** is disabled. If you cannot find the LNB frequency value from the list, select User and manually enter the frequency.

- Some models may not be supported.

## Transponder

Select the transponder you want to tune.

## 22kHz Tone

When using 22kHz Tone switch, select 22kHz or 0 Hz. If you use **22kHz Tone**, Unicable and Motor Type are disabled.

## LNB Power

To enable the power supply for the LNB, select **On**. If you select **Off**, **Motor Type** is disabled.

## DiSEqC

When using DiSEqC, select one option from A~D/ToneA~B. If you use **DiSEqC**, Unicable and Motor Type are disabled.

## Unicable

Select On to use Unicable and set the Unicable in the **Unicable Settings** menu. When Unicable is enabled, **22kHz Tone**, **DiSEqC**, **Motor Type** are disabled.

## Motor Type

Select Motor Type to use Motor and set the Motor in the Motor Setting menu. When Motor is enabled, **22kHz Tone**, **DiSEqC**, **Unicable** are disabled.

- If you set satellite to others, you must add a transponder using Transponder Edit.
- When selecting 22kHz Tone and DiSEqC, you must connect them in the same position as displayed on the OSD.
- If you delete a Satellite, all programmes stored in the Satellite are deleted.

## Set Motor Setting

**DiSEqC 1.2** : Control motor to change satellite dish position.

## Drive Direction

Select the direction in which you want to move the motor.

## Drive Mode

Two modes are available : Step and Continuous.

- Step : The motor moves based on the value you enter (from 1 to 128).
- **Continuous** : The motor moves continuously until you press the Stop.

## Test Transponder

Select the test Transponder you want to tune.

## Set Limit

Set the motor movement to east or west to have the motor move only within the direction set.

- On : You can limit the movement to the current direction by selecting the West/East.
- Off : You can cancel the limit you set.

## Go to 0

You can move the motor to Zero.

**USALS** : Set your current location (Longitude/Latitude).

## To Use Manual Programme Tuning

 →  → **General** → **Programmes** → **Programme Tuning** (**Programme Tuning & Settings**) → **Manual Tuning**

This function is for manually searching and saving programmes.

For digital broadcasting, signal strength and signal quality can be checked.

## Programme List Update

 →  → **General** → **Programmes** → **Programme Tuning & Settings** → **Programme List Update**

It updates the changed Programme List information by based on country broadcasting circumstance and satellite.

It updates the Programme List when the TV is turned off.  
 After updates, the Programme List may be changed. If not want, select **Off**.

- Some models may not be supported.

## To Use the Signal Test

⚙️ → ⓘ → **General** → **Programmes** → **Programme Tuning** (**Programme Tuning & Settings**) → **Signal Test**

Shows the MUX and Service information etc.

- Signal test is only available in Antenna or Cable mode.
- Some models may not be supported.


## Edit Programmes

You can edit the selected programmes from all the stored programmes or add/delete them to/from the favourite programmes.

### Edit All Programmes List

⚙️ → ⓘ → **General** → **Programmes** → **Programme Manager** → **Edit All Programmes**

You can lock or unlock the selected programmes from all the stored programmes, or you can set them to be skipped when switching programmes.



- 1 Set the sorting option.
- 2 **Lock / Unlock** : Lock the selected programmes or unlock the locked programmes.  
**Skip / Restore** : Set the selected programmes to be skipped when switching programmes, or disable the skipping option of the programmes previously set to be skipped.

**Move** : Move the selected programmes.

**Edit Programme Numbers** : Change the numbers of the selected programmes.


**Delete** : Delete the selected programmes.

- Available features may vary depending on the broadcast signal.
- For a model that supports satellite programmes, you can manage the satellite programmes in **Edit Satellite Programmes (Advanced)**.

## Edit Favourite Programmes List

⚙️ → ⓘ → **General** → **Programmes** → **Programme Manager** → **Edit Favourites**

You can add/delete desired programmes to/from the favourite programmes, change their positions, etc.



- 1 Select the desired programmes from the all programmes list and press the button to add them to the favourite programmes list.
- 2 Delete the selected programmes from the favourite programmes list.
- 3 **Move** : Select one or more programmes in the Preferred Programmes list, press the **Move** button, and then select the position to move it to. The selected programmes will move to the position you selected.  
**Change Group Name** : Change the name of the favourite programmes list.  
**Sort by Programme** : Sorts the list of favourite programmes by programme.

## Learn More about HbbTV

HbbTV (Hybrid Broadcast Broadband TV) is a new broadcasting standard that enables super-teletext type services, delivered by a broadcast TV programme, to be integrated or linked to online services delivered over broadband to a connected Smart TV.

To see the details, click the **Enjoy Live TV** → **HbbTV** in **User Guide**.

- Some models may not be supported.

## Copy Programmes

 →  → **General** → **Programmes** → **Copy Programmes**

Export your TV's programme list information to a connected USB storage device or Import your TV's programme list information from a connected USB storage device.

- For Satellite models

## Network

### Setting a Wired Network

 →  → **General** → **Network** → **Wired Connection (Ethernet)**

If the router connected to the network supports the DHCP feature, connecting the TV and router by wire will automatically connects to the network. If the automatic setup is not supported, you can select **Edit** to manually set up the network connection.

- Some models may not be supported.

### Setting a Wireless Network

 →  → **General** → **Network** → **Wi-Fi Connection**

If you have set the TV up for a wireless network, you can check and connect to the available wireless Internet networks. Select the wireless router to connect.

For more detailed settings, select **Other Network Settings**.

#### **Add a hidden wireless network**

If you input the name of network directly, you can add a wireless network.

#### **Connect via WPS PBC.**

If the wireless router you want to connect to has a Wi-Fi Protected Setup-Push Button Configuration (WPS-PBC) feature, you can easily connect to the wireless router by pressing the WPS-PBC button on the router. Press the wireless router's WPS-PBC button and then press the TV's [Connect] button.

## Connect via WPS PIN.

This is a method to connect to an access point using a Wi-Fi Protected Setup-Personal Identification Number (WPS-PIN). Select the access point you want to connect to. Enter the PIN displayed on the access point's Wi-Fi device.

## Advanced Wi-Fi Settings

Once you connect to a wireless network, you can view connection information such as detailed IP address information. In addition, you can change the IP address and DNS server address you want to connect to by pressing the **Edit** button.

- For more information on how to connect to the network, see **Getting Started with LG webOS TV → Connecting to the Network** in **User Guide**.

# Devices

## Setting TV

 →  → **General** → **Devices** → **TV Management**

### Home/Store Mode

You can choose between **Home Mode** and **Store Mode**.

To use the TV at home, select **Home Mode**.

Select **Store Mode** only when the TV will be displayed in store. The **Store Mode** provide settings optimised for store display.

### Quick Start+

This setting puts your TV in standby mode when it's turned off so it will help using TV's functions quicker when you turn the TV back on.

Set **Quick Start+** to **On**.

- Some models may not be supported.
- Turning this option on may increase energy consumption.

### TV Information

You can view information including **Model**, **Serial Number**, **Device Name**.

## Managing External Device Connections

## ⚙️ → ⓘ → **General** → **Devices** → **External Devices**

You can set to use a smart device connected to the TV to control the TV or manage the connection history.

- The configurable items differ depending on model.

### **Connect Bluetooth Controller**

You can connect and use devices such as a Bluetooth-enabled keyboard, mouse, or a gamepad with your TV.

Turn on the device, set it to pairing mode, and then click **Connect** on your TV screen. When a device you've connected before is turned on, it automatically connects to your TV. To disconnect the existing connection, click **Disconnect**.

- It is recommended that you use a product that has been tested for compatibility with LG TVs.  
Bluetooth Mouse : Logitech M535, Logitech MX Master 2S, Apple Magic Mouse2  
Bluetooth Keyboard : Logitech K480, Arteck HB030B, Arteck HB192, Apple Magic Keyboard  
Bluetooth Gamepad : Sony Dualshock4, Microsoft Xbox One S Controller, Microsoft Xbox Series X Controller, NVIDIA SHIELD Controller
- This feature is available for Bluetooth-enabled models only.
- Connecting multiple Bluetooth devices may result in poor connection or operation.
- If the Bluetooth device is too far from the TV, or there are obstacles between them, they may not operate normally.
- Depending on the peripherals (wireless router, microwave oven, etc.), communication failures may occur.
- If the device you selected from **Registered Devices** does not reconnect, **Disconnect** and then reconnect the device.
- It's differ form devices. For more information on the device you want to connect to, refer to its user guide.

### **Camera**

You can set access permissions to the camera for each app.

### **Universal Control Settings**

If you set up the universal remote control, you can control peripheral devices connected to the TV with the Magic Remote instead of their own remote controls. For more information, see **How to Operate TV → Using Universal Remote Control** in **User Guide**.

### **TV On With Mobile**



If **Turn on via Wi-Fi** or **Turn on via Bluetooth** is set to **On**, you can turn on your TV using an application that supports **TV On With Mobile**.

- The TV should be connected to a network.
- The TV and the device to be used should be connected to the same network.
- The **Turn on via Wi-Fi** feature must be used in an app on a smart device that supports the feature.
- **Turn on via Bluetooth** is only available on some smartphones.
- The TV must be plugged in.
- To connect for the first time, make sure the device to be used is ready to connect.
- Some models may not be supported.

## Delete Connection History

You can delete the connection history of the devices connected to the TV on the wireless network.

## Setting HDMI External Input

⚙️ → ⓘ → **General** → **Devices** → **HDMI Settings**

You can apply settings to ensure a clear picture and easy control for the HDMI connected devices.

### HDMI Deep Colour

If you connect a device that supports **HDMI Deep Colour**, you can enjoy a clearer image. After connecting the playback device, set **HDMI Deep Colour** to **4K**. If the connected device does not support this function, it may not work properly. When a screen problem occurs, change the **HDMI Deep Colour** setting to **Off**.

#### Supported Display Resolution

- 4K : Supports 4K@120 Hz (4:4:4, 4:2:2, 4:2:0) (120 Hz models only), 4K@60 Hz (4:4:4, 4:2:2, and 4:2:0)
- Off : Supports 4K@60 Hz (4:2:0)

4K @ 50/60 Hz Support Format  
(60 Hz models only)

Resolution	Frame rate (Hz)	Colour Depth/Chroma Sampling		
		8 bit	10 bit	12 bit

3840 × 2160p	50	YCbCr 4:2:0	YCbCr 4:2:0 <sup>1)</sup>	YCbCr 4:2:0 <sup>1)</sup>
4096 × 2160p	59.94			
	60	YCbCr 4:2:2 <sup>1)</sup>	YCbCr 4:2:2 <sup>1)</sup>	YCbCr 4:2:2 <sup>1)</sup>
		YCbCr 4:4:4 <sup>1)</sup>	-	-
		RGB 4:4:4 <sup>1)</sup>	-	-

4K @ 100/120 Hz Support Format  
(120 Hz models only)

Resolution	Frame rate (Hz)	Colour Depth/Chroma Sampling		
		8 bit	10 bit	12 bit
3840 × 2160p	50	YCbCr 4:2:0	YCbCr 4:2:0 <sup>1)</sup>	YCbCr 4:2:0 <sup>1)</sup>
4096 × 2160p	59.94			
	60	YCbCr 4:2:2 <sup>1)</sup>	YCbCr 4:2:2 <sup>1)</sup>	YCbCr 4:2:2 <sup>1)</sup>
		YCbCr 4:4:4 <sup>1)</sup>	YCbCr 4:4:4 <sup>1)2)</sup>	YCbCr 4:4:4 <sup>1)2)</sup>
		RGB 4:4:4 <sup>1)</sup>	RGB 4:4:4 <sup>1)2)</sup>	RGB 4:4:4 <sup>1)2)</sup>
	100 <sup>1)2)</sup>	YCbCr 4:2:0	YCbCr 4:2:0	YCbCr 4:2:0
	120	YCbCr 4:2:2	YCbCr 4:2:2	YCbCr 4:2:2
		YCbCr 4:4:4	YCbCr 4:4:4	YCbCr 4:4:4
		RGB 4:4:4	RGB 4:4:4	RGB 4:4:4

1) Supported when **HDMI Deep Colour** is set to **4K**.

2) This feature is available for **HDMI (4K@120 Hz) IN** terminals only.

- You can only change the settings of the **HDMI IN** you are watching at the time.

- You can specify a different setting for each HDMI port.

## **SIMPLINK (HDMI-CEC)**

You can conveniently control and use various multimedia devices connected through HDMI with the TV remote control.

To see the details, click the **How to Operate TV → Connecting to SIMPLINK (HDMI-CEC)** in **User Guide**.

# System

## **Configuring Language Settings**

 →  → **General** → **System** → **Language**

You can choose the menu language displayed on the screen and the audio language of the digital broadcast.

### **Menu Language**

You can select one of the menu languages to be displayed on the screen. The language for the speech recognition will be automatically set to the selected language for the menu.

- The speech recognition is only applied to some models.

### **Primary Audio Language / Secondary Audio Language**

You can choose the language you want when watching a digital broadcasting programme, which includes multiple audio languages.

For programmes that do not support multiple languages, the default will be used.

- Applies to Digital broadcasting.

### **Keyboard Languages**

Select the language to use the on-screen keyboard.

## **To Set Teletext Language**

Sets Teletext language.

To see the details, click the **Enjoy Live TV → TELETEXT** in **User Guide**.

- In Digital Mode Only

## Setting the Location

 →  → **General** → **System** → **Location**

You can change the location setting of your Smart TV.

### Address Setting

You can set the **Region** and **City** of your TV.

### Broadcast Country

You can set the broadcast country on your TV.

### Postcode

This function is used to set the broadcast location of the TV by entering your postcode.

### LG Services Country

If you don't set the **Set Automatically**, you can select the country manually.

- You must set the country manually when you are not connected to the network.
- The configurable items differ depending on model.

## Time & Timer

 →  → **General** → **System** → **Time & Timer**

You can check the time or configure related settings.

### Set Automatically

The TV time is automatically set to the time of digital broadcasting information sent from the broadcasting station or the time sent from the server.

### Time / Date / Time Zone

You can manually set the time and date if the automatically set current time is incorrect.

- If you set the time manually with the antenna connected, schedule information, programme guide, etc. may not function correctly.

### Custom Time Zone

When select the **Custom** in **Time Zone**, **Custom Time Zone** menu is activated.

## Timers

### Sleep Timer

Sets the TV to turn off at a specified time.  
If you do not want to use **Sleep Timer**, select **Off**.

### Power On Timer

Set **Power On Timer** to **On**.  
The TV is turned on and displays the set programme at the set time.

- **Time** : Set the time at which to turn the TV on.
- **Timer Repeat** : Set the day of the week. Set the option to **None** to operate the feature only once.
- **Input** : Set an external input to display when the power is turned on.
- **Timer Programme** : Set a channel to display when the power is turned on. This option can be set only when **Input** is set to **TV**.
- **Volume** : Set audio volume to use when the power is turned on.

### Power Off Timer

Set **Power Off Timer** to **On**.  
The TV is turned off at the set time.

- **Time** : Set the time at which to turn the TV off.
- **Timer Repeat** : Set the day of the week. Set the option to **None** to operate the feature only once.

### Auto Power Off after 4 Hours

If you do not press any button for 4 hours after the TV is turned on by a feature such as **Power On Timer**, the TV will be turned off automatically.  
To ensure the TV does not automatically turn off, set **Auto Power Off after 4 Hours** to **Off**.

- Some models may not be supported.
- To use **Power On Timer/Power Off Timer**, set the time correctly.

## Setting Safety

 →  → **General** → **System** → **Safety**

You can put a lock on TV broadcasts or apps.  
Set it to **On** to apply the lock.

### TV Rating Locks

This function operates according to information from the broadcasting station. Therefore if the signal has incorrect information, this function does not operate. Prevents children from watching certain adult's TV programmes, according to the ratings limit set. Enter a password to watch a blocked programme. Rating differs by country.

- Supported only in the digital mode.
- Some models may not be supported.

### Programme Locks

Blocks the programmes that contain inappropriate contents for children. The programmes can be selected but the screen is blank and the audio is muted. To watch a locked programme, enter the password.

### Application Locks

You can lock or unlock the application.

- The lock function is not immediately available for the currently running application.

### Input Locks

You can lock or unlock the Inputs.

### Reset Password

Set or change the password for the TV.

- The default password is set as "0000".  
When France, Norway or Belgium is selected for Country, the password is not "0000" but "1234".

### Resetting a Lost Password

If you lose the password you set, you can reset it as follows:

- 01 Press the  button on the remote control.
- 02 Select  → **General** → **System** → **Safety**.

- 03 Press **[+]** (Programmes) **^** → **[+]** (Programmes) **^** → **[+]** (Programmes) **∨** → **[+]** (Programmes) **^** on the remote control. The master password input window will appear.
- 04 Enter the numbers “0313” in the master password input window, then press **OK**. The password will be reset.


## Managing Your LG Account

You can sign up for LG membership and log in with your email address in **LG Account**. For more information, see **Getting Started with LG webOS TV → Managing Your LG Account** in **User Guide**.

## Using Notifications

**⚙️** → **ⓘ** → **General** → **System** → **Additional Settings** → **Notifications**

You can view or delete notifications from TV apps and LG services. For notifications that support shortcuts, you can go directly to that app or website.



- 1 You can check the details by selecting the desired item. If it supports shortcuts, you can launch the app.
- 2 You can delete notifications.
- 3 Closes the app.  
To turn off the app from running in the background, press the **⋮** button on the remote control and select **Quit App**.
  - If your remote control does not have a **⋮** button, press and hold the **⏻** button.

## Home Settings

 →  → **General** → **System** → **Additional Settings** → **Home Settings**

### Home Auto Launch

You can set Home to launch automatically when turning on the TV.

### Home Promotion

You can turn on or off the advertisements on the Home screen.

- The configurable items differ depending on model.

## To Set Power Indicator

 →  → **General** → **System** → **Additional Settings** → **Standby Light**

You can turn the standby light on or off.

- Some models may not be supported.

## Setting the Pointer of Magic Remote

 →  → **General** → **System** → **Additional Settings** → **Pointer Options**

You can set the pointer speed and size you want while it is on the screen.

### Tracking Speed

Sets the pointer speed.

### Pointer Size

Selects the pointer size.

## Advertisement

 →  → **General** → **System** → **Additional Settings** → **Advertisement**

If your TV is connected to the Internet, webOS may use a frequency capping cookie to keep track of the number of times an ad is shown on your TV.

This information is used to help limit the number of times the same ad is displayed. You can clear this cookie or turn it on or off at any time by going to the **Advertisement** setting on your TV.

No personally identifiable information is tied to this cookie.



## Limit AD Tracking

If set to **On**, personalised advertisements based on user interests may not be provided.

## Reset AD ID

User interest information is newly collected, and advertisements are provided according to the information.

- Some models may not be supported.

## Using the Live Plus


**Live Plus** is a service that provides various information on the programme you watch. To see the details, click the **Making the Most of Smart TV → Live Plus** in **User Guide**.

- Some models may not be supported.

## To Use Settings Help

⚙️ → ⓘ → **General** → **System** → **Additional Settings** → **Settings Help**

When set to **On**, you can get help for the selected items when navigating through the Settings menu.



## Set ID

⚙️ → ⓘ → **General** → **System** → **Additional Settings** → **Set ID**

You can set a number (ID) to manage multiple TVs.

- This feature is for administrators. It is not recommended for use in a typical home

environment.

## Restoring the Default Settings

⚙️ → ⓘ → **General** → **System** → **Reset to Initial Settings**

Return TV to its initial settings. After reset, the TV will automatically turn off and on.

### Reset All

All items on the TV are changed to their default settings.

### Reset all except network settings

All items except the network settings are changed to their default settings.

- If **Safety** is set to **On**, you should type the password to **Reset to Initial Settings**.
- Do not turn off the power during initialization.
- We recommend that you reset the TV to **Reset to Initial Settings** before you sell it or transfer it to a third party.

# Accessibility

## Enjoy TV Sound Together

⚙️ → ⓘ → **General** → **Accessibility** → **Enjoy TV Sound Together**

The sound simultaneously outputs to the TV's built-in speaker and Bluetooth device, so that users with different hearing abilities can watch TV together.

Set to **On**. **Sound Out** changes to **Bluetooth Device + TV Speaker**.

The existing Bluetooth connection history will then be deleted.

- For Bluetooth devices, earphone or headset type is recommended.
- For instructions on how to connect and set up a Bluetooth device, refer to **Settings** → **Sound** → **Use External Speakers with TV Speaker** in **User Guide**.

## Changing the Menu to High-Contrast Screen

⚙️ → ⓘ → **General** → **Accessibility** → **High Contrast**

When this feature is set to **On**, it adjusts the background of some of the menus on the

screen and font colours to highlight the contrast between the light and dark areas.

## Greyscale

 →  → **General** → **Accessibility** → **Greyscale**

Change the colour of the menu on the screen to black and white tone to make its ambiguity very clear. Set to **On**.

## Invert Colours

 →  → **General** → **Accessibility** → **Invert Colours**

To enhance the visibility of the menus on the screen, you can invert and calibrate certain colours in some menus. Set to **On**.

## To Set Subtitle

 →  → **General** → **Accessibility** → **Subtitles**

View subtitles when the TV station provides subtitled programming. Change **Subtitles** to **On** and select subtitle setting.

- Some models may not be supported.
- Applies to Digital broadcasting.

## Menu for the Visually Impaired

 →  → **General** → **Accessibility** → **Audio Description**

The contents on the screen will be described with voice for visually impaired viewers. You can use this function if the broadcasting company supports **Audio Description** for the visually impaired.

- Some models may not be supported.

## Audio Type

 →  → **General** → **Accessibility** → **Audio Type**

Audio commentary or subtitles are provided for those who are hard of hearing or visually impaired.

## Normal

Selects default Audio.

## Audio Description

For the visually impaired Selects the preferred default Audio combined with Visual Impaired Audio.

## Spoken Subtitle

For the visually impaired, selects the preferred Visual Impaired Audio only.

## Any Supplementary Audio

Displays all supplementary audio.

- Some models may not be supported.

## Additional Audio Function

 →  → **General** → **Accessibility** → **Additional Audio Selection**

Audio commentary or subtitles are provided for those who are hard of hearing or visually impaired.

## None

Selects default Audio.

## Audio Description

For the visually impaired Selects the preferred default Audio combined with Visual Impaired Audio.

## Clean Audio

For the hearing-impaired Selects the preferred Clean Effect and Hearing Impaired Audio.

## Spoken Subtitle

For the visually impaired, selects the preferred Visual Impaired Audio only.

- Some models may not be supported.

## To Set Hard of Hearing

01 Press the  button on the remote control.

02 Select  → **General** → **Accessibility**.

03 Set **Subtitles** to **On**.

04 Set **Hard of Hearing** to **On**.

A caption will be provided for the hearing-impaired.

- When the **Hard of Hearing** is turned **On**, it will be prioritized over the general captions.
- Some models may not be supported.

# Support

## Software Update

 →  → **Support** → **Software Update**

Uses software update to check and obtain the latest version.

### Auto Update

When it is set to **On**, updates are automatically made without a separate confirmation procedure except for some important updates.

### Check for Updates

When checking for the latest update version, you can only perform updates if an update file of a later version is available. The TV automatically checks your software version but, if necessary, you can perform a manual check.

- The configurable items differ depending on model.
- The latest version can be obtained via digital broadcast signals or internet connections.
- Changing the programme while downloading the software via digital broadcast signal interrupts the download process. Returning to the initial programme allows downloading to resume.
- If software is not updated, certain functions may not work properly.
- In some countries, **Auto Update** is not displayed if you are not connected to the Internet.

## Privacy & Terms

 →  → **Support** → **Privacy & Terms**

### **User Agreements**

These are the terms and conditions related to use of the Smart TV service and protection of privacy.

### **Legal Notice**

It's a legal notice for services provided via TV.

### **Open Source Software Notice**


You can view the instructions for each item.

# Troubleshooting

## Perform Check-up with the Quick Help

### Perform Check-up with the **Quick Help**

When the TV malfunctions, you can get help to solve the problem.

Press  button on the remote control and select  → **Support** → **Quick Help**.

You can also long-press the number **9** button of the remote control to run the **Quick Help**.

### **Optimisation Settings**

You can automatically check the overall status of your TV and view and change the recommended setting values.

### **Check Items**

Select the problematic item, and you can get help to solve the problem.

- **Self-Diagnosis of TV Settings** : Select the item that matches the symptom to find instructions that can help you solve the problem.

- **Check the status of TV** : You can check your TV's current status for the selected item.

## LG Remote Service

You can get help for troubleshooting through the remote control.

For **LG Remote Service**, make sure to contact the LG Electronics Customer Service Center.

- This function may not be available in some countries or models.
- When there is no related content in the **Quick Help**, please refer to the **Troubleshooting** in **User Guide**.
- If you still fail to solve the problem, please contact our Customer Service Centre.









# Learn More About Always Ready

## Learn More About **Always Ready**

 What is the difference between **Always Ready** and the power off?




- Unlike the power off, you can operate the TV with Hands-free Voice Control, connect Bluetooth, and receive responses from a reserved Home IoT Devices.  
However, standby power may be consumed more than when the power is turned off.

 How can I use **Always Ready**?




- Set the **Enable the function** of  →  → **General** → **Always Ready** to **On**.
- When watching TV  
Press the  button on the remote control to switch to **Always Ready** with the screen on.  
Press the  button on the remote control twice to switch to **Always Ready** with the screen off.
- When the TV is **Always Ready** with the screen on  
To watch TV, press the  button or the  button on the remote control.  
To turn off the screen, press the  button on the remote control. **Always Ready** will remain.
- When the TV is **Always Ready** with the screen off  
To watch TV, press the  button on the remote control.  
To turn on the screen, press the **Wheel (OK)** button on the remote control. **Always**

**Ready** will remain.

 How can I continue to use **Always Ready** without a wallpaper?

- Selecting **Use Always Ready without wallpaper** of  →  → **General** → **Always Ready** enables you to immediately switch to **Always Ready** with the screen off by pressing the  button on the remote control while watching TV.

 I don't want to use **Always Ready**.

- Setting **Enable the function** of  →  → **General** → **Always Ready** to **Off** enables you to immediately turn it off by pressing the  button on the remote control while watching TV.  
In this case, features such as Bluetooth connection or Hands-free Voice Control will not work.

 When the TV is **Always Ready**, the Standby Light is white. Did it turn off correctly?

- The colour of Standby Light differs, depending on whether Hands-free Voice Control is activated or not. If Hands-free Voice Control is enabled, it is displayed in white; if it is not available, it is displayed in red.  
For more information on Hands-free Voice Control, please refer to **How to Operate TV** → **Using TV features with Hands-free Voice Control** in **User Guide**.

## Troubleshooting Power/Remote Control Issues

### Troubleshooting Power/Remote Control Issues


If you experience any of the problems below while using the product, please check the following: There may be no problem with the product.

 I cannot turn on the TV.

- Check that the power Standby Light on the TV is red. If the Standby Light is off, check the connection of the TV power plug, as shown below.








- If you are using a multi-outlet, check if it is working properly. To check whether a power strip is working properly, plug the TV's power plug directly to a wall outlet and observe its operation.
- Try to power on using the button on your TV set.

 The power is on, but the screen comes on later.

- This is because there is a noise-removal process to eliminate any possible noise that may appear during power-on. This does not mean the product is defective.

 The pointer of Magic Remote is not appear in the screen.

- Hold the remote control towards the TV and press the  and  buttons at the same time for more than 5 seconds until instructions appear. The previously registered remote control is deregistered and then registered again.
- Replace the batteries when you are prompted to do so on your TV screen. (Use alkaline batteries.)
- If  →  → **General** → **Accessibility** → **Audio Guidance** is set to **On**, the pointer of the Magic Remote does not appear. Set **Audio Guidance** to **Off**. (Some models may not be supported.)


 I cannot turn the TV on with the remote control.

- Please make sure your TV power plug is correctly connected to the outlet.
- Replace the batteries in the remote control. (Use alkaline batteries.)
- Check if there is an obstacle blocking the signal in front of the TV's remote control receiver. If there is an obstacle, such as a soundbar, in front of the receiver at the bottom of the TV, it may interfere with the remote control signal reception.
- When using a set-top box remote control, if the TV integrated control function of the set-top box remote control is turned off, you cannot power on or off the TV with the set-top box remote control. Please contact your set-top box provider.

 The power turns off suddenly.

- Check if **Power Off Timer** is set.
- The TV will be turned off automatically if you do not press any buttons for 4 hours even after the TV is turned on at the time set by **Reminder** or **Power On Timer**.
- There is also a chance that the internal protection circuitry has activated because the internal temperature of the product has risen unusually or excessively.

- If you are using a set-top box, the TV may be set to turn off when the set-top box is turned off. To prevent the TV from turning off when you turn off the set-top box, switch the TV power sync function off on the set-top box.

 I cannot turn on or operate the device with the TV remote control even after setting the universal remote control.

- Make sure that the device's power plug is plugged into the outlet.
- Replace the batteries in the remote control. (Use alkaline batteries.)
- Check if there are any obstacles blocking the signal in front of the connected device's remote control receiver.

## Troubleshooting Screen Issues


### Troubleshooting Screen Issues


If you experience any of the problems below while using the product, please check the following: There may be no problem with the product.

First of all, perform a  →  → **General** → **OLED Care** → **Device Self Care** → **Screen Self-diagnosis** for check any abnormalities in the TV.



If you are using a set-top box, turn it off, and then turn it back on.

Make sure that the set-top box is correctly connected to your TV.



 It says there is no signal on the screen.


- Check whether the antenna or the cable connected to the external device is properly connected to the TV.
- Go to  to choose the connected input.
- Check if your external device, such as set-top box or Blu-ray player, is turned on.

 I cannot see some programmes.


- Launch  →  → **General** → **Programmes** → **Programme Tuning (Programme Tuning & Settings)** → **Auto Tuning**.
- If you are using a set-top box, consult its supplier.

 The screen is cut off.


- Go to  →  → **Picture** and change the **Aspect Ratio**.
- When using an external device (set-top box, game console, etc.), check the screen size settings in the Settings menu of the device.

 The screen shakes after the momentary appearance of vertical/horizontal lines and net pattern.

- Connect wireless telephones, hairdryers, electrical drills, etc. to a different power outlet. The problem may be caused by high-frequency electronic devices such as another TV or strong electro-magnetic sources nearby.



 Each programme has a different image quality.

- Depending on the type of videos provided by the broadcasters, programmes may have different image qualities.
- If you are using a set-top box, consult its supplier.
- Run **Screen Self-diagnosis** first. If it is normal, there may be a problem with the broadcast signal.

 There is a difference in image quality from those seen at the store.

- Depending on the type of video provided by the broadcasters, there may be a difference in image quality from those displayed at the store.
- Run **Screen Self-diagnosis** first. If it is normal, there may be a problem with the broadcast signal.

 A digitally broadcasted programme stops or its screen is broken.

- This happens when a signal is weak or reception is unstable. Adjust the antenna direction or check the cable connection.
-  →  → **General** → **Programmes** → **Programme Tuning (Programme Tuning & Settings)** → **Manual Tuning**  
If the signal strength is too low in **Manual Tuning**, contact the broadcasting station or management office to have the signals checked.
- If you are using a set-top box, consult its supplier.


 When HDMI input is in use, a vertical solid line or colour blurring appears on the



upper/lower/left/right edges of the screen.

-  →  → **Picture** → **Aspect Ratio** → **Just Scan**









Set **Just Scan** to **Off**.

**Just Scan** shows you the original image as it is. If the signal is weak, the top/bottom/left/right sides of the screen may be snowy.





 I don't see anything, or the image keeps flickering when I try to connect the HDMI cable.

- Check whether your HDMI<sup>®</sup> cable is compliant with the specifications. You may experience flickering or a blank screen if the HDMI<sup>®</sup> cable is faulty (bent, broken).
- Make sure that the cable is correctly connected to the port. Bad or loose contact may cause display problems on the screen.
- If using a UHD set-top box, adjust  →  → **General** → **Devices** → **HDMI Settings** → **HDMI Deep Colour**.


 The screen looks too dim or dark.

-  →  → **Picture** → **Select Mode**  
Switch **Select Mode** to your desired picture mode. (**Standard**, **Vivid**, etc.)  
This applies to the current input mode only.
-  →  → **Picture** → **Advanced Settings** → **Brightness** → **Motion Eye Care**  
Switch **Motion Eye Care** to **Off**. This applies to the current input mode only.
-  →  → **General** → **OLED Care** → **Device Self Care** → **Energy Saving**  
Switch **Energy Saving Step** to either **Off** or **Minimum**.
-  →  → **Picture** → **Advanced Settings** → **Reduce Blue light**  
Switch **Reduce Blue light** to **Off**.

 The screen brightness keeps changing.

-  →  → **General** → **OLED Care** → **Device Self Care** → **Energy Saving**  
Switch **Energy Saving Step** to either **Off** or **Minimum**.
-  →  → **General** → **AI Service** → **AI Picture Pro**  
Switch **AI Picture Pro** to **Off**.

 The screen is in black and white or displaying strange colours.

- Check the input mode or cable connection.
- Go to  to choose the connected input.

- When you are connecting to the **AV IN**, check to ensure each cable is matched with the corresponding color connection.
- **AV IN** port is available in certain models only.

 **ULTRA HD video does not display.**

- With some HDMI cables, signals may not be received.
- Change the settings of the connected device to the supported signal.

## Troubleshooting Sound Issues

### Troubleshooting Sound Issues



If you experience any of the problems below while using the product, please check the following: There may be no problem with the product.

First of all, perform a  →  → **General** → **OLED Care** → **Device Self Care** → **Sound Self-diagnosis** for check any abnormalities in the TV.



If you are using a set-top box, turn it off, and then turn it back on.

Make sure that the set-top box is correctly connected to your TV.


 **The screen is fine, but it does not play any sound.**



- Try another programme.
- If you use a set-top box, there will be no sound if you have set the volume of the set-top box or your TV to 0 or enabled Mute. Set the volume to an appropriate level.
-  →  → **Sound** → **Sound Out**  
Set the **Sound Out** to **Optical Out Device + TV Speaker** or **Use TV Speaker**, and then check it once again. If you can hear the sound without any problem, check the connection with external speakers such as sound bar and the settings of the external speakers.

 **There is no sound coming from one of the speakers.**



-  →  → **Sound** → **Advanced Settings** → **Balance**  
Adjust the balance as necessary with the Navigation button in **Balance**.
- When you are connecting to the **AV IN**, check if the audio left/right (white/red) cables are


correctly connected. (**AV IN** port is available in certain models only.)





 The TV sound is not synchronized with the picture, or the sound sometimes breaks up.


- If this happens on only some of the programmes, it may be caused by the broadcasting company's transmission signal. Please have your broadcasting services provider (wired/cable) diagnose the problem.
- If all programmes are out of sync, go to  →  → **Sound** → **Advanced Settings** → **Match Screen and Sound** and adjust the sync.
- If you are using a set-top box, consult its supplier.

 The volume changes when I change the programme.




- The volume of different broadcasting stations' transmission output may vary.
-  →  → **Sound** → **Advanced Settings** → **Automatic Volume Adjustment**  
Set **Automatic Volume Adjustment** to **On**.
- If you are using a set-top box, consult its supplier.

 The volume keeps changing.

-  →  → **Sound** → **Advanced Settings** → **Automatic Volume Adjustment**  
Set **Automatic Volume Adjustment** to **On**.
-  →  → **General** → **AI Service** → **AI Sound** / **AI Sound Pro**  
Switch **AI Sound** or **AI Sound Pro** to **Off**.



 The sound does not work or only the background music is played in some programmes.

(Programmes produced for export by broadcasting companies)

- Set your language preference in  → **Audio Language**.
- If your remote control does not have a  button, press and hold the  button.

## Troubleshooting PC Connection Issues


# Troubleshooting PC Connection Issues



Run **Home Dashboard** by pressing the  button on the remote control. Select  → **Edit Inputs** in the upper right corner. In the Edit mode, set the icon of the HDMI terminal connected to the PC to **PC** to apply the video and aspect ratio settings that are aligned with the PC.

If you experience any of the problems below while using the product, please check the following: There may be no problem with the product.

 The screen remains blank after it is connected to a PC.

- Check that the PC is properly connected to the TV.
- Turn the TV off and back on using the remote control.
- Restart the PC with the TV on.
- Make sure that the output resolution set on the PC is set to the HDMI-PC supported resolution of the TV.
- To use dual monitors, check that the PC or notebook supports dual-monitor mode.
- Reconnect the HDMI cable.
- If you have connected the RGB output port of your PC to the **HDMI IN** of your TV, you need an RGB to HDMI gender.  
You will not see anything on the screen if you use an HDMI to RGB gender.

 The screen is not fully shown or is lopsided when connected to a PC.

- Set the PC's resolution to one supported by the TV. For more information, see **Being Aware of the Information → Supported Resolution : HDMI-PC** in **User Guide**.
- Set the connected HDMI device's name to PC.  
Run **Home Dashboard** by pressing the  button on the remote control. Select  → **Edit Inputs** in the upper right corner. Change the icon of the HDMI port connected to **Inputs** to PC and select **Save**.

 The sound does not play when the PC is connected with an HDMI cable.

- Set LGTV as the default device in Sound → Playback in Control Panel of PC settings.
- Consult your manufacturer on whether your graphics card supports HDMI audio output.

# Troubleshooting Movie Playback Issues

## Troubleshooting Movie Playback Issues

If you experience any of the problems below while using the product, please check the following: There may be no problem with the product.


More information about supported files can be found in **Being Aware of the Information** → **Supported Video File Formats** in the **User Guide**.

 I cannot find a file in the **Media Player**.

- Check whether the files saved on your USB storage device can be read by the PC.
- Check that the file extension is supported.
- Change the filter to **All**.

 I see a message that says the file is not supported.



- Check that the file plays without any problems on the video player on a PC. (Check for file damage.)
- Check that the file extension is supported.
- Check that the resolution is supported.
- Check that the video codec is supported.
- Check that the frame rate is supported.

 I get a message saying “This audio is not supported” or the video is playing normally but the audio is not.

- Check that the file plays without any problems on the video player on a PC. (Check for file damage.)
- Check that the file extension is supported.
- Check that the audio codec is supported.
- Check that the bit rate is supported.
- Check that the sample frequency is supported.
- Check that the number of audio programmes is supported.



## I cannot see the subtitles.

- Check that the file plays without any problems on the video player on a PC. (Check for file damage.)
- Check that the video and subtitle files have the same name.
- Also check that both the video file and the subtitle file are in the same folder.
- Check that the subtitle file format is supported.
- Check that the language is supported.  
(You can check the language of the subtitle file by opening the file in the Notepad.)
- If subtitles encoding is incorrectly set, subtitles may not be displayed properly. Press the  button on the remote control during video playback actions. Select  and change the **Code Page** value.
- If you play a video file stored on another device by using the content sharing feature, subtitles may not be available depending on the programme you use.
- Subtitles are not supported if you are playing video through an NAS unit. Consult your NAS manufacturer.

## My USB storage device is not recognised when connected.





- Check whether it is a USB storage device supported by the TV.  
For more information, see **Connecting External Devices** → **Connecting USB** in **User Guide**.

# Troubleshooting Recording Issues

## Troubleshooting Recording Issues

Refer to **Enjoy Live TV** → **Recording** in the **User Guide** for details on recording.

## How do I start recording?

- Connect a USB storage device with at least 4 GB of total space. The device must have at least 1 GB of available space. (Refer to **Connecting External Devices** → **Connecting USB** in the **User Guide** for details on USB storage devices.)  
Press the  button on the remote control and select **Record**. If your remote control does not have a  button, press and hold the  button.  
You can also start recording by long pressing  button on the Magic Remote.

- Some USB storage devices require formatting on your TV. Formatting deletes all data stored on the USB storage device, and the device is formatted with the FAT32, exFAT or NTFS file system. Before you connect a USB storage device to your TV, back up any data that is stored on your device to your PC.

### Which signals support recording?

- You can only record broadcasts that are directly received through the antenna terminal on the TV.
- Programmes from the set-top box cannot be recorded.
- Protected content is not recorded.

### Is **Scheduled Recording** possible even if the TV is off?

- **Scheduled Recording** starts and completes recording at the set time even if the TV is off.
- If the TV is turned off completely as follows, **Scheduled Recording** cannot be used.
  - When the TV is not connected to a power outlet
  - When the switch of the multi-outlet to which the TV's power plug is connected is off
  - When the standby power cutoff switch is on so that power is not supplied to the TV

## Troubleshooting Network Connection Issues

### Troubleshooting Network Connection Issues

If you experience any of the problems below while using the product, please check the following: There may be no problem with the product.

Before connecting to a wireless network, check the name and password of the Wi-Fi device to connect.

You can check the network connection status as shown below.

-  →  → **General** → **Network** → **Wired Connection (Ethernet)**
-  →  → **General** → **Network** → **Wi-Fi Connection** → **Other Network Settings** →

## Advanced Wi-Fi Settings

- Some models may support the **Wi-Fi Connection** function only.



### When X appears next to TV

- Check the TV or the AP (Router).
- Check the connection status of the TV, AP (Router) and cable modem.
- Power off and power on in the following order;
  1. Turn your cable modem off and back on, and wait for the device to reset.
  2. Turn the wired/wireless router off and back on, and wait for the device to reset.
  3. Turn the TV off and on.
- If you want to establish a wired LAN connection, check whether an IP address can be obtained from your router properly. If you are setting up your network manually, check whether all settings are correct.
- If you want to establish a wireless connection, check the following points as well.
  - ① Set your router's SSID (network name) or wireless channel.
  - ② Set your router's security key.If you can't complete this setting, refer to the router's user manual and the instructions provided by your Internet provider. If you are still unable to establish your configuration, consult your router's manufacturer or your Internet service provider.
- If you are using a static IP, enter the IP directly.



### When X appears next to Gateway

- Check the AP (Router) or consult your Internet service provider.
- Unplug the router/cable modem from the wall outlet, wait 10 seconds and reconnect it.
- Initialize (Reset) the AP (Router) or cable modem.
- Check the AP (Router) manufacturer's website to make sure your router has the latest firmware version installed.
- If you can't complete this setting, refer to the router's user manual and the instructions provided by your Internet provider. If you are still unable to establish your configuration, consult your router's manufacturer or your Internet service provider.




### When X appears next to DNS

- Check the AP (Router) or consult your Internet service provider.
- Unplug the router/cable modem from the wall outlet, wait 10 seconds and reconnect it.
- Initialize (Reset) the AP (Router) or cable modem.
- Check that the MAC address of the TV/AP (Router) is registered with your Internet service provider. (The MAC address displayed on the pane of the network status window should be registered with your Internet service provider.)
- If you can't complete this setting, refer to the router's user manual and the instructions provided by your Internet provider. If you are still unable to establish your configuration, consult your router's manufacturer or your Internet service provider.

## Troubleshooting LG Account Issues


### Troubleshooting LG Account Issues

 I've signed up for the membership on TV. Do I have to sign up again on the website ([www.lgappstv.com](http://www.lgappstv.com))?

- You can use the website with the membership information that you used when signing up on TV.

 I forgot my password. What should I do?

- On the TV's login screen, select the **Forgot Password?** button to go to the find password page. Enter your email address on the find password page, and we'll send you a link to reset your password.
- You can also reset your password in LG Account → Reset Password on the website ([www.lgappstv.com](http://www.lgappstv.com)).

 I wish to delete the account saved on the TV.


- When you log in to your LG account on the TV, the account will be saved to the TV. You can delete accounts stored on the TV at any time, as follows.

01 Select  →  → **General** → **System** → **LG Account**.

02 Select  → **Edit Account List** at the top of the screen.

03 Pressing **Delete** will delete the account.

It will not delete the login history or close the account.

 I wish to delete the usage history on the TV.

- When you use the TV after logging in to your LG account, the usage history will be saved and you can delete it at any time.

01 Select  →  → **General** → **System** → **LG Account**.

02 Select **Account Management** for the account you wish to set up.

03 Select **Usage Data Management**.

04 Pressing **Delete** will delete the usage history.

 I wish to close my account on the TV.

- You can also close your LG account on the TV as follows.

01 Select  →  → **General** → **System** → **LG Account**.

02 Select **Account Management** for the account you wish to set up.

03 Select **Terminate My Account**.

04 Enter your password and press **OK** to close your account.



- In some countries, access to the website ([www.lgappstv.com](http://www.lgappstv.com)) may be restricted.


## Troubleshooting Contents Issues

### Troubleshooting Contents Issues

If you experience any of the problems below while using the product, please check the following: There may be no problem with the product.

 I cannot see any content in HOME.

- You may not be able to see the content if the service country setting has been changed. Change to the service country you are going to use the service from in  →  → **General** → **System** → **Location** → **LG Services Country**.  
(Some models may not be supported.)


- If you cannot see some apps, it may be because you deleted them. Please reinstall the appropriate app.
- If the app is deleted, you can download the app at **Apps** and reinstall it. Go to  → **Apps** to find and install the app you want.
- The type of supported content differs by country.
- The content offerings are subject to change or interruption by the service provider.

# Troubleshooting Internet Browser Issues

## Troubleshooting Internet Browser Issues

If you experience any of the problems below while using the product, please check the following: There may be no problem with the product.


 Some parts of a particular website are not visible when I am using the Internet.

- The **Web Browser** supports only HTML5 media and not Flash Plug-in.
- The **Web Browser** does not support plug-in installation.
- On the **Web Browser**, it may not be possible to play media files in formats other than : JPEG/PNG/GIF
- You cannot save attachments or images.
- If the **Use Block Ads** feature is turned on, the area on the website that appears to show an ad will appear blank. If some content on the website is hidden and invisible, try setting  → **Settings** → **Use Block Ads** to **Off** in **Web Browser**. **Sponsored AD** on the new tab page will be displayed even if you set the **Use Block Ads** feature to **Off**.

 The Internet browser automatically shuts down when I visit a website.

- The Internet browser may be forced to shut down if the available memory size is not sufficient to accommodate the image information for a website. Check if you can access the site with the issue on your PC.

 When watching a video in **Web Browser**, the video is forced off.

- You may be able to fix this by setting  → **Settings** → **Adaptive Streaming using JavaScript** to **Off** in **Web Browser**. The setting is not applied to tabs that were open

before the change, and is only applied to tabs opened after the change.

# Being Aware of the Information

## Supported Photo File Formats

### Supported Photo File Formats

File Format	Format	Resolution
jpeg, jpg, jpe	JPEG	Minimum : 64 × 64 Maximum Normal Type : 15360 (W) × 8640 (H) Progressive Type : 1920 (W) × 1440 (H)
png	PNG	Minimum : 64 × 64 Maximum : 5760 (W) × 5760 (H)
bmp	BMP	Minimum : 64 × 64 Maximum : 1920 (W) × 1080 (H)
avif, heic, heif	AVIF/HEIF	Minimum : 64 × 64 Maximum : 4800 (W) × 3600 (H) 9600 (W) × 7200 (H) (8K models only)

## Supported Video File Formats

### Supported Video File Formats

## Maximum Data Transfer Rate

- Full HD video  
H.264 1920 × 1080@60P BP/MP/HP@L4.2 Maximum 40Mbps  
HEVC 1920 × 1080@60P Main/Main10@L4.1 Maximum 40Mbps
- ULTRA HD video (ULTRA HD models only)  
H.264 3840 × 2160@30P BP/MP/HP@L5.1 Maximum 50Mbps  
HEVC 3840 × 2160@60P Main/Main10@L5.1 Maximum 60Mbps
- HFR video (HFR supported models only)  
HEVC 3840 × 2160@120P Main/Main10@L5.2 Maximum 60Mbps
- Dolby Vision video (Dolby Vision supported models only)  
HEVC 3840 × 2160@60P Main/Main10@L5.1 Maximum 50Mbps  
HEVC 7680 × 4320@60P Main/Main10@L6.1 Maximum 100Mbps (8K models only)
- 8K video (8K models only)  
AV1 7680 × 4320@60P  
HEVC 7680 × 4320@60P Main/Main10@L6.1 Maximum 100Mbps  
VVC 7680 × 4320@60P

## Supported External Subtitles

smi, srt, sub (MicroDVD, SubViewer 1.0/2.0), ass, ssa, txt (TMPlayer), psb (PowerDivX), dcs (DLP Cinema)

## Supported Embedded Subtitles Format

Matroska (mkv) : Sub Station Alpha (SSA), Advanced Sub Station Alpha (ASS), SRT  
MP4 : Timed Text

## Supported Video Codecs

Extension	Codec	
asf wmv	Video	VC-1 Advanced Profile (except for WMVA), VC-1 Simple and Main Profiles
	Audio	WMA Standard (except for WMA v1/WMA Speech)
avi	Video	Xvid (GMC is not supported), H.264/AVC, Motion Jpeg, MPEG-4



	Audio	MPEG-1 Layer I, II, MPEG-1 Layer III (MP3), Dolby Digital, LPCM, ADPCM
mp4 m4v mov	Video	H.264/AVC, MPEG-4, HEVC, AV1, VVC
	Audio	Dolby Digital, Dolby Digital Plus, AAC, MPEG-1 Layer III (MP3), Dolby AC-4
3gp 3g2	Video	H.264/AVC, MPEG-4
	Audio	AAC, AMR-NB, AMR-WB
mkv	Video	MPEG-2, MPEG-4, H.264/AVC, VP8, VP9, HEVC, AV1
	Audio	Dolby Digital, Dolby Digital Plus, AAC, PCM, MPEG-1 Layer I, II, MPEG-1 Layer III (MP3)
ts trp tp mts	Video	H.264/AVC, MPEG-2, HEVC
	Audio	MPEG-1 Layer I, II, MPEG-1 Layer III (MP3), Dolby Digital, Dolby Digital Plus, AAC, PCM, Dolby AC-4
mpg mpeg dat	Video	MPEG-1, MPEG-2
	Audio	MPEG-1 Layer I, II, MPEG-1 Layer III (MP3)
vob	Video	MPEG-1, MPEG-2
	Audio	Dolby Digital, MPEG-1 Layer I, II, DVD-LPCM

- Dolby AC-4 , VVC : Some models may not be supported.

## Cautions for Video Playback

- Some user-created subtitles may not work properly.
- A video file and its subtitle file must be in the same folder. For subtitles to be displayed properly, make sure that the video file and the subtitle file have the same name.
- Subtitles on a Network Attached Storage (NAS) device may not be supported depending on the manufacturer and model.
- Streams that include Global Motion Compensation (GMC) and Quarterpel Motion Estimation (Qpel) are not supported.
- ULTRA HD video (ULTRA HD models only) : 3840 × 2160, 4096 × 2160  
Some HEVC-encoded ULTRA HD videos other than the content officially provided by LG Electronics may not be played.  
Some codecs can be supported after a software upgrade.

Extension	Codec	
mkv/mp4/ts	Video	H.264/AVC, HEVC
	Audio	Dolby Digital, Dolby Digital Plus, AAC

- Only Window Media Audio V7 and later are supported.
- The AAC main profile is not supported.
- Video files created by some encoders may not be played.
- Video files in a different format than specified may not be played properly.
- Video files stored on a USB storage device that does not support High Speed may not be played properly.

## Supported Music File Formats

### Supported Music File Formats

File Format	Info	
mp3	Bit rate	32 kbps ~ 320 kbps
	Sample freq.	16 kHz ~ 48 kHz

	Support	MPEG-1, MPEG-2
	Channels	mono, stereo
wav	Bit rate	-
	Sample freq.	8 kHz ~ 96 kHz
	Support	PCM
	Channels	mono, stereo
ogg	Bit rate	64 kbps ~ 320 kbps
	Sample freq.	8 kHz ~ 48 kHz
	Support	Vorbis
	Channels	mono, stereo
wma	Bit rate	128 kbps ~ 320 kbps
	Sample freq.	8 kHz ~ 48 kHz
	Support	WMA
	Channels	up to 6 ch
flac	Bit rate	-
	Sample freq.	8 kHz ~ 96 kHz
	Support	FLAC

Channels	mono, stereo
----------	--------------

- The number of supported programmes may vary depending on the sample frequency.

## Supported Resolution : HDMI-DTV

### HDMI-DTV Supported Mode

Resolution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)
640 × 480p	31.46	59.94
	31.5	60
720 × 480p	31.46	59.94
	31.5	60
720 × 576p	31.25	50
1280 × 720p	37.5	50
	44.95	59.94
	45	60
1920 × 1080i	28.12	50
	33.71	59.94
	33.75	60

1920 × 1080p	26.97	23.97
	27	24
	28.12	25
	33.71	29.97
	33.75	30
	56.25	50
	67.43	59.94
	67.5	60
1920 × 1080p (ULTRA HD, 8K models only)	112.5	100
	134.86	119.88
	135	120
2560 × 1080p <sup>4) 5)</sup> (ULTRA HD, 8K models only)	66	60
	131.74	120
3840 × 2160p (ULTRA HD, 8K models only)	53.94	23.97
	54	24
	56.25	25
	67.43	29.97

	67.5	30
	112.5	50
	134.86	59.94
	135	60
3840 × 2160p <sup>1) 2) 3)</sup> (ULTRA HD, 8K models only)	225	100
	269.73	119.88
	270	120
4096 × 2160p (ULTRA HD, 8K models only)	53.94	23.97
	54	24
	56.25	25
	67.43	29.97
	67.5	30
	112.5	50
	134.86	59.94
	135	60
4096 × 2160p <sup>1) 2) 3)</sup> (ULTRA HD, 8K models only)	225	100
	269.73	119.88

	270	120
7680 × 4320p <sup>2)</sup> (8K models only)	107.89	23.97
	108	24
	110	25
	131.87	29.97
	132	30
	220	50
	263.74	59.94
	264	60

1) Supported when **HDMI Deep Colour** is set to **4K**.

2) Supported when **HDMI Deep Colour** is set to **8K**.

3) (ULTRA HD models only) Only some HDMI input ports are supported.

4) Supported when **Wide Aspect Ratio** is set to **21:9**.

5) Supported when **Wide Aspect Ratio** is set to **32:9**.

## Supported Resolution : HDMI-PC

### HDMI-PC Supported Mode

Resolution	Horizontal Frequency (kHz)	Vertical Frequency (Hz)
640 × 350	31.46	70.09

720 × 400	31.46	70.08
640 × 480	31.46	59.94
800 × 600	37.87	60.31
1024 × 768	48.36	60
1152 × 864	54.34	60.05
1360 × 768 <sup>3)</sup>	47.71	60.01
1280 × 1024	63.98	60.02
1920 × 1080	67.5	60
1920 × 1080 (ULTRA HD, 8K models only)	134.86	119.88
	135	120
2560 × 1080 <sup>4) 5)</sup> (ULTRA HD, 8K models only)	66	60
	131.74	120
2560 × 1440 <sup>1)</sup> (ULTRA HD, 8K models only)	182.99	119.99
3840 × 1080 <sup>5)</sup> (ULTRA HD, 8K models only)	66.62	60
	137.25	120
3840 × 1600 <sup>4)</sup> (ULTRA HD, 8K models only)	99.41	60



3840 × 2160 (ULTRA HD, 8K models only)	53.94	23.97
	54	24
	56.25	25
	67.43	29.97
	67.5	30
	112.5	50
	134.86	59.94
	135	60
3840 × 2160 <sup>1)</sup> (ULTRA HD, 8K models only)	225	100
	269.73	119.88
	270	120
4096 × 2160 (ULTRA HD, 8K models only)	53.94	23.97
	54	24
	56.25	25
	67.43	29.97
	67.5	30
	112.5	50

	134.86	59.94
	135	60
4096 × 2160 <sup>1)</sup> (ULTRA HD, 8K models only)	225	100
	269.73	119.88
	270	120
7680 × 4320 <sup>2)</sup> (8K models only)	107.89	23.97
	108	24
	110	25
	131.87	29.97
	132	30
	220	50
	263.74	59.94
	264	60

- 1) Supported when **HDMI Deep Colour** is set to **4K**.  
2) Supported when **HDMI Deep Colour** is set to **8K**.  
3) Supported when **HDMI Deep Colour** is set to **Off**.  
4) Supported when **Wide Aspect Ratio** is set to **21:9**.  
5) Supported when **Wide Aspect Ratio** is set to **32:9**.

- Supported HDMI-PC port is differ by model. Refer the manual that provide with product.

# License Information

## License Information

Supported licenses may differ by model.

### Dolby

Manufactured under license from Dolby Laboratories. Dolby, Dolby Vision, Dolby Vision IQ, Dolby Audio, Dolby Atmos, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

### HDMI

The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

### Bluetooth

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by LG Electronics Inc. is under license. Other trademarks and trade names are those of their respective owners.

### Quickset

**QUICKSET**®

### HEVC

**HEVC** Advance™  
Covered by patents at [patentlist.accessadvance.com](http://patentlist.accessadvance.com)