

10110 2,4 GHZ WIRELESS+ SET SINGLE

D	Montage- und Betriebsanleitung
GB USA	Assembly and operating instructions
F	Instructions de montage et d'utilisation
E	Instrucciones de uso y montaje
P	Instruções de montagem e modo de utilização
	Istruzioni per il montaggio e l'uso
NL	Montage- en gebruiksaanwijzing
S	Monterings- och bruksanvisning
FIN	Asennus- ja käyttöohjeet
N	Montajse- og bruksanvisning
H	Ősszeszerelési és használati útmutató
PL	Instrukcja obsługi i montażu
SK	Návod na montáž a pre prevádzkuo
CZ	Návod na montáž a pro provoz
BG	Ръководство за монтаж и експлоатация
GR	Οδηγίες συναρμολόγησης και λειτουργίας
RO	Instrucțiuni de montaj și de utilizare
DK	Monterings- og driftsvejledning
RC	安装和使用说明
J	取扱説明書取扱説明書の内容は予
ROK	조립과 작동 방법
Arabic	اِرشْدادات التركيب و الأستخدام
TB	Montaj ve işletme kılavuzu
RUS	Инструкция по монтажу и эксплуатации

Verpackungsinhalt · Contents of package · Contenu du carton · Contenido de la caja · Conteúdo da embalagem · Contenuto della confezione · Verpakkingsinhoud · Innehållet i förpackningen Pakkauksen sisältö · Innholdet i pakningen · A csomag tartalma · Zawartość opakowania Obsah balenia · Obsah balení · Съдържание на опаковката · Пεριεχόμενα συσκευασίας Conținutul ambalajului · Emballageindhold · 包装内容 · 梱包内容 · 포장내용물 محتويات الغلاف






Table of contents

Safety instructions	6
Declaration of Conformity	6
Important information	6
Contents of package	6
Description	6
Before first use	6
Care of the battery	6
Assembly instructions	6
Connecting the receiver	
Preparation of start	
Binding process	7
Troubleshooting	7
Maintenance and care	7
Technical specifications	7
Requirement for FCC Part 15	7
Warnings	7

Welcome

Welcome to the Team Carrera!

The operating instructions contain important information regarding assembly and operation of your Carrera DIGITAL 124/132 WIRELESS+ system.

Please read them carefully and keep them in a safe place afterwards. If you have any queries, please do not hesitate to contact our distributor or visit our websites:

carrera-toys.com · carreraclub.com

Please check the contents for completeness and possible transport damage. The packaging contains important information and should also be retained.

Please note that WIRELESS+ will only function in conjunction with the Carrera DIGITAL 124/132 Control Unit or Black Box WIRELESS+ can be used for Carrera DIGITAL 124/132 cars.

Should you need information on operating the 30352 Carrera DIGITAL 124/132 Control Unit or the Black Box, please refer to the operating instructions for the Control Unit.

We hope you will derive a lot of pleasure from your new 2.4 GHz WIRELESS+ Set single for Carrera DIGITAL 124/132.

Safety instructions

• WARNING! Not suitable for children under 36 months. Danger of suffocation due to small parts which may be swallowed. Caution: risk of pinching caused by function.

• WARNING!

Only allow children at least 8 years old to use the battery charger. Sufficient instruction must be given to enable the child to use the battery charger in a safe way and explain that it is not a toy and must not be played with.

Important note to parents:

Transformers and power supply units are not suitable to be used as toys. The use of such products needs to be constantly supervised by the parents.

· Regularly check the track, cars and charger for damage to cables, plugs and housings! Replace defective parts.

• The car racetrack is not suitable for outdoor operation or operation in wet locations! Keep away from liquids.

· Do not place any metal parts onto the track to avoid short-circuits. Do not place the track in the immediate vicinity of delicate objects, as these could be damaged by cars hurled from the track.

· Pull the plug before cleaning the racetrack! Only use a damp cloth for cleaning, no solvents or chemicals. When it is not in use, store the track in a dry and dust-protected location, preferably in the original cardboard box.

 Do not operate race track at face- or eye-level – risk of injury due to cars being catapulted off the track.

Misuse of transformer can cause electrical shock.

. The toy is only to be connected to Class II equipment bearing the following symbol.

. The toy and the charger must only be used with a transformer

designed for toys. . If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similary qualified persons in order to avoid danger.

Note:

The vehicle may only be operated again in a completely assembled condition. Assembly may only be carried out by an adult.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. Instruct the child not to try and recharge non-rechargeable batteries because of the danger of explosion. Please also observe the safety instructions included with the basic sets of Carrera DIGITAL 124/132.

Declaration of Conformity

The company Stadlbauer Marketing + Vertrieb GmbH, hereby con-firms that the product .2.4 GHz WIRELESS+" complies with the fundamental requirements of Guideline 1999/5/EC (R&TTE). The Declaration of Conformity can be called up from the following address: www.carrera-toys.com

Important information				
Carrera EXCLUSIV EVOLUTION EVOLUTION Carrera DIGITA	AL 124/132			
Garrera Garrera DIGITAL124 DIGITAL132				
Carrera DIGITAL 124/132	EXCLUSIV EVOLUTION			

Please note that Exclusiv/Evolution (analog system) and Carrera DIGITAL 124/132 (digital system) involve two separate and com-pletely independent systems. We hereby expressly indicate that both systems must be kept separate when setting up the track, i.e. no connecting rail from Exclusiv/Evolution may be used together with the connecting rail and Black Box of the Carrera DIGITAL 124/132, even if only one of the two connecting rails (Exclusiv/Evolution con-necting rail or Carrera DIGITAL 124/132 connecting rail and Black Box) is attached to the current supply. Furthermore, no other Carrera DIGITAL 124/132 components (switches, electronic lap counter, pit stop) may be built into an Exclusiv/Evolution course, i.e. via analog operation.

Non-compliance with the above information may result in damage or destruction of the respective Carrera DIGITAL 124/132 components. In this case no warranty may be claimed.

Contents of package



- WIRELESS+ Speed controllers
- WIRELESS+ Receiver
- WIRELESS+ Single charging cradle LiPo rechargeable batteries for speed controllers
- Adapter Unit
- Shoulder complement 2
- Shoulder end sections Track section bolts
- 8 Instructions

Description

WIRELESS+ is the latest new cordless racetrack delight for Carrera DIGITAL124 and Carrera DIGITAL 132. The 2.4 GHz radio technoloof up to 15 metres. Thanks to powerful lithium polymer rechargeable battery, continuous play for up to eight hours is possible and standby operation for over 80 days. WIRELESS+ offers cordless freedom for up to six drivers at the racetrack.

Before first use

Before first using the speed controller, the rechargeable battery supplied 2 must be inserted in the controller. Unscrew the battery compartment 1 on the underside of the speed controller.

Connect the battery plug into the socket in the speed controller and put the battery in place in the compartment. Finally screw down the cover of the battery compartment again. The battery is part-loaded at the factory, but it should be charged completely before being used for the first time.



Care of the battery


To make sure the battery performs well for as long as possible, the following points should be observed regarding its care and storage. · Before first using them, new batteries should always be charged fully.

 \bullet With a fully-charged battery, continuous play is possible for up to eight hours. When the battery power is falling off, range of the speed controller will diminish. As soon as you notice this, the battery should be fully recharged.

 If it is not to be used for an extended period, remove the battery. and store the controller at room temperature (16-18 °C) in a dry place. To prevent a deep discharge of the battery, the stored battery should be charged every 2 to 3 months.


Assembly instructions

The charging unit is plugged in to the position provided at the side of the adapter unit. This can be placed at any desired position on the track layout. Take care the adapter unit is fitted the right way round!



Connecting the receiver

Connect the receiver according to the symbol to either of the two sockets on the control unit which are marked Tower 1 and Tower 2. It does not matter whether the receiver is connected to the Black Box 30344 or the Control Unit 30352. For operating six WIRE-LESS+ speed controllers only one 2.4 GHz receiver is required.



Preparation of start

Before first being used, the WIRELESS+ speed controller should be fully charged. Place the speed controller in the charging cradle and switch on power to the track. While the unit is charging, the LED (1)on the speed controller will flash. When charging is completed, the

LED (1) will light up continuously. When using a lithium polymer rechargeable battery, it is possible to top up the speed controller at any time.



Binding process



Before the speed controller can be used to control the cars, it must be "bound" to the receiver.

To do this, switch on the control unit.

The receiver indicates it is ready for operation by a revolving light signal in the segment display (1)

Push the "SET" button (2) once until the figure 1 appears in the seg-ment display (1). The number shown is then the address of the car. Switch to the next address by further pressing the button.

Now press the binding button (3) on the top of the speed controller. The speed controller signals a successful binding process with flashing of the LED, while the receiver indicates it by revolving lights in the segments. The binding process is now complete and the speed controller is ready for use.

To bind the second speed controller, follow the same procedure. Press the "SET" button (2) on the receiver twice, until the figure 2 appears (1). Then press the binding button (3) on the second speed controller.

When the binding process has been successfully carried out, the cars can be coded to the corresponding speed controller. For coding the cars, setting the speed, braking behaviour and tank capacity also see the owner's instructions for the Black Box, Control Unit or car.

To display the address set for the speed controller, press once on the binding button (2) on the top of the speed controller. The LED (1) will then flash, according to the address set.

If the speed controller is not actuated, it switches automatically after about 20 seconds into energy-saving mode. The speed controller can be reactivated by pressing the tappet or the lane-change button.

Troubleshooting

In case of any malfunctions, please check the following:

. Is the adapter unit correctly installed facing the direction of travel? Is the speed controller battery properly connected?

- Is the battery fully charged?
- . Does the LED on the controller flash while charging?
- Is the speed controller bound to the receiver?
- · Has the speed controller got a duplicate address assignment?

During operation small car parts as spoilers or mirrors may get off or

Note:

brake due to being original detailed parts of the car model. To avoid this it is possible to remove them before operation

All Carrera spare parts are available in the webshop:

carrera-toys.com

Delivery exclusively to Germany, Austria, Netherlands, Belgium and Luxembourg.

Maintenance and care

To ensure a proper operation of the motor-racing circuit, all racetrack components should be regularly cleaned. Pull the plug prior to cleaning

1 Racetrack: Keep the track surface and track slots clean with a dry cloth. Do not use any solvents or chemicals for cleaning. When it is not in use, store the racetrack in a clean and dust-protected location, preferably in the original cardboard box.

Technical specifications

(GB)


Output voltage: Toy transformer

¢	18 V 54 VA 14,8 V 51,8 VA	(Carrera DIGITAL 124) (Carrera DIGITAL 132)
- +	lithium polymer rechargeable h	attery: 3.7 — 150mAh

+lithium polymer rechargeable battery: 3,7 = = 150mAh

Electricity modes:

- 1.) Operating mode = cars are operated via speed controllers
- 2.) Idle mode = speed controllers not activated, no game
- 3.) Stand-by mode = after approx. 20 minutes idle mode the connecting section switches to stand-by mode. LED flashes at long intervals. CURRENT CONSUMPTION < 1 watt / 1w By operating the speed controller the stand-by mode is finished, the racetrack returns to idle-mode again.
- 4.) Off-state = power supply unit disconnected from mains supply





This device is marked by "selective sort throught" symbol related to sort through domestic, electric and electronic, waste. This means the product must be treated by a specialized "sorting/collecting" system in accordance with European directive 2002/96/CE, to reduce the impact upon environment. For more precise information, please contact your local administration. Electronical product which are not going through special collecting, are potentially dangerous for environment and human health, because of dangerous substance.

(USA) Output voltage: Toy transformer

14,8 V = _ 51,8 VA

-+ lithium polymer rechargeable battery: 3,7 ____ 150mAh

Electricity modes:

- 1.) Operating mode = cars are operated via speed controllers
- 2.) Idle mode = speed controllers not activated, no game 3.) Stand-by mode = after approx. 20 minutes idle mode the
- connecting section switches to stand-by mode. LED flashes at long intervals. CURRENT CONSUMPTION < 1 watt / 1w By operating the speed controller the stand-by mode is finished,
- the racetrack returns to idle-mode again.
- 4.) Off-state = power supply unit disconnected from mains supply





Conforms to the safety requirements of ASTM F963.

Requirement for FCC Part 15

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the

limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency

energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver, · Connect the equipment into an outlet on a circuit different

from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Warnings

Guidelines and warnings about using the LiPo battery/ batteries:

LiPo rechargeable batteries are much more sensitive than the traditional alkaline or NiMh rechargeables. For this reason all instructions and warnings must be scrupulously observed. Incorrect treatment of LiPo rechargeable batteries may cause a fire. In handling, charging and using the LiPo battery/batteries supplied, you take over all responsibility for the risks attached to lithium batteries.

• Non-rechargeable batteries must not be recharged!

For recharging batteries, only the charging cradle supplied may be used. If this instruction is disregarded, there is a risk of fire which may endanger your health and/or cause damage to property. NEVER use any other charging unit!

Rechargeable batteries may only be recharged under adult supervision. When charging, never leave the battery unattended.

When you recharge the battery, you should always be in the vicinity to keep watch on the process so that you can react to any possible problem. • If the battery swells or deforms during either discharge or charging

process, stop the process immediately. Remove the battery as fast and as carefully as possible and place it on a safe and open area away from any flammable materials, and keep it under observation for at least 15 minutes. If you continue to charge or discharge a battery which has already started to swell or deform, there is danger of fire! Even at the slightest sign of swelling or deforming, the battery must be taken out of service.

• The battery supplied must be charged in a safe place away from flammable materials.

• Store the battery at room temperature (16 - 18 °C) in a dry place. Do not expose the battery to direct sunlight or any other sources of heat. Temperatures over 50 °C are generally to be avoided.

 Always recharge the battery after use to avoid the possibility of its becoming deep discharged. When it is not in use, recharge the battery from time to time, say every 2-3 months. Failure to observe the methods of handling described above may lead to defects.

 When changing batteries do not use any sharp or pointed objects or tools. Avoid damaging the protective foil around the battery at all costs.

 When replacing defective batteries, only the recommended battery types may be used. Damaged or unusable batteries are hazardous waste, and must be disposed of accordingly.

• Never throw batteries, rechargeable or otherwise, on the fire or expose them to high temperatures. This may cause a fire or an explosion.

• The electrolyte and electrolyte vapour in the LiPo batteries are

hazardous to health. Always avoid direct contact with electrolyte. If electrolyte makes contact with skin, eyes or other parts of the body, it must immediately be washed out or off with plenty of fresh

water and a doctor must be consulted. · Rechargeable batteries are not toys and must not fall into the

hands of children. Keep batteries inaccessible to children. . The connector clips / battery connections must never be shortcircuited!

• The toy is only to be operated with a transformer or power pack designed for use with toys!

The transformer / the power pack is not a toy!



Stadlbauer Marketing + Vertrieb GmbH · Rennbahn Allee 1 · 5412 Puch / Salzburg · Austria

7.80.12.43.00 · 01/2013