

# Handleiding

## NVO-EB03



**NEDERLANDS**

Nuvoo Elektronische bovendecken

Spanning: 220-240V 50/60Hz

Vermogen: 160W

Model: NVO-EB03

Afmeting: 180x160cm

Flanel Fleece / Sherpa Fleece

10 warmte standen: 29°C, 30°C, 31°C, 32°C, 33°C, 35°C, 37°C,  
39°C, 41°C, 43°C, ±5°C

1-10 uur instellingen tijd

Bescherming tegen oververhitting

Schakelt automatisch uit

Kabel lengte: 2.3m



## **BELANGRIJKE INSTRUCTIES BEWAREN VOOR TOEKOMSTIG GEBRUIK**

Lees de gebruiksaanwijzing zorgvuldig voordat u de warmtedeken gebruikt, vooral de veiligheidsinstructies, en bewaar de gebruiksaanwijzing voor toekomstig gebruik. Als u de warmtedeken aan iemand anders geeft, is het van vitaal belang dat u ook de gebruiksaanwijzing doorgeeft.



Niet geschikt voor kinderen jonger dan 3 jaar.



Prik niet in het verwarmde deken!



Niet opgevouwen of opgerold gebruiken



Niet in de droger



Niet chemisch reinigen



Niet strijken



Niet bleken



Liefst op handwas reinigen,  
kan ook met de wasmachine op 30°C

## **BELANGRIJKE VEILIGHEIDSINSTRUCTIES**

- Controleer de dekens zorgvuldig voor elk gebruik.
- Als u zichtbare schade ziet op de dekens, niet gebruiken
- De dekens kunnen alleen worden gebruikt met de meegeleverde controller.
- Doorboor de dekens niet en bevestig er geen veiligheidsspelden of andere stekelige of scherpe voorwerpen aan.
- Gebruik de elektrische dekens vooral niet bij zwakkeren, baby's of personen die gevoelig zijn voor warmte.
- Dit apparaat kan worden gebruikt door kinderen vanaf 8 jaar en ouder. Personen met verminderde fysieke, zintuiglijke of mentale capaciteiten of gebrek aan ervaring en kennis als zij onder toezicht staan of instructie hebben gekregen over gebruik van de deken op een veilige manier en de bijbehorende gevaren en risico's begrijpen.
- Controleer de deken regelmatig op tekenen van slijtage of beschadigingen. Als er dergelijke tekenen zijn, als de deken verkeerd gebruikt of werkt het niet, breng het dan terug naar de leverancier voordat u het weer inschakelt.

- De deken is niet bedoeld voor medisch gebruik in ziekenhuizen.
- De deken mag niet worden gebruikt door jonge kinderen leeftijd van drie jaar, tenzij de bediening vooraf is ingesteld door een ouder/voogd.
- Kinderen mogen niet met de deken spelen.
- Reiniging en onderhoud de deken regelmatig.
- Gebruik de dekens nooit zonder toezicht.
- Langdurig gebruik van de dekens op een hoge stand kan leiden tot leiden tot verbranding van de huid.
- Raak nooit de deken aan die in het water is gevallen. Haal de deken onmiddellijk uit het stopcontact.
- Houd het netsnoer uit de buurt van hete oppervlakken.
- Draag, trek of draai de deken nooit aan het netsnoer en laat de kabel niet in de war raken.
- Gebruik de deken niet als ze nat zijn en gebruik ze alleen in droge omgevingen (niet in de badkamer of vergelijkbare omgevingen).
- De controller en kabel mogen niet worden blootgesteld aan vocht.
- Als er een storing optreedt, probeer de deken dan niet zelf te repareren, reparaties mogen alleen worden uitgevoerd door een geautoriseerde dealer of ander gekwalificeerd personeel.
- Als de voedingskabel beschadigd is, mag deze alleen worden vervangen door een geautoriseerde dealer of een gekwalificeerde elektricien.
- Laat de deken volledig afkoelen voordat u ze opvouwt en opbergt, vouw het niet te strak op.
- Bewaar de deken in de originele verpakking en bewaar ze op een schone, droge plek.
- Vouw het netsnoer voorzichtig op om kabelbreuken te voorkomen.
- Kreuk de dekens niet door er voorwerpen op te leggen tijdens het opbergen.
- Raadpleeg uw arts als u zich zorgen maakt over uw gezondheid voordat u de deken gebruikt.
- Het snoer en de bedieningseenheid van het apparaat kunnen aanleiding geven tot risico van verstrikking, verwurging, struikelen of betreden als het niet op de juiste manier zijn aangebracht.

De gebruiker moet ervoor zorgen dat overtollige en elektrische snoeren op een veilige plaats worden gelegd.



1. Nuvoo Elektrische bovendeken
2. Netsnoer
3. Schakelaar en aan/uit-knop

## SCHOONMAKEN EN ONDERHOUD

Haal de stekker uit het stopcontact voordat u de deken schoonmaakt en laat de deken volledig afkoelen. De deken is uitgerust met een afneembaar snoer. Haal de stekker uit het stopcontact en verwijder de kabel uit de deken. U kunt de deken het liefst wassen in een handwasprogramma maar kan ook 30°C met lage stand centrifugeren. Gebruik geen droger om de deken te drogen, laat het natuurlijk opdrogen op een vlakke ondergrond. Bewaar de deken op een schone en droge plaats, plat neergelegd zonder dat er iets overheen ligt of op rust. Gebruik de deken pas als ze helemaal droog zijn. - Je kunt de deken ook wassen in een wasmachine op een

## **AFVOER**

Dit product mag niet weggegooid worden samen met huishoudelijk afval. Alle gebruikers zijn verplicht om alle elektrische of elektronische apparaten in te leveren, ongeacht of ze giftige stoffen bevatten, in te leveren bij een gemeentelijke of inzamelpunt, zodat ze kunnen worden verwijderd op een op een milieuvriendelijke manier kunnen worden verwijderd. Raadpleeg uw gemeente of leverancier voor informatie over afvalverwijdering.

**ENGLISH**



Electric Blankets (Overblanket)

Voltage:220-240V~50/60Hz      Power: 160W

Model:SS20 (OB20201)

Size: 180x130cm

PolyesterWith ten-step  
heat adjustment

Overheating protection

Shuts off automatically



## **IMPORTANT INSTRUCTIONS RETAIN FOR FUTURE USE**

Read the instruction manual carefully before using this device, especially the safety instructions, and keep the instruction manual for future use. Should you give this device to another person, it is vital that you also pass on these instructions for use.



Not suitable for children under 3 years.



Do not puncture the heated cushion!



Do not use folded or rucked



Do not tumble dry



Do not dry-clean



Do not iron



Do not bleach



Machine wash, 30°C

## **IMPORTANT SAFETY INSTRUCTION**

- Check the blankets carefully before each use.
  - If you notice visible damage on the blankets, do not use and return to the manufacturer or dealer.
- The blankets can only be operated with the controller (SS20) supplied.
- Before the blankets to the power supply, please ensure that the supply voltage stated on the rating plate is compatible with your main supply.
  - During use, the controller switch and cable must not be placed on or under the blankets or be covered in any way.
  - Neither pierce the blankets with, nor attach safety pins or other spiky or sharp objects to the blankets.
  - Particularly do not use the electric blankets with the infirm, infants or persons insensitive to heat.
  - This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

- Examine the appliance frequently for signs of wear or damage. If there are such signs, if the appliance has been misused or does not work, return it to the supplier before switching it on again.
- This appliance is not intended for medical use in hospitals.
- The appliance is not to be used by young children over the age of three unless the controls have been pre-set by a parent or guardian, and unless the child has been adequately instructed on how to operate the controls safely.
- This appliance must not be used by persons insensitive to heat and other very vulnerable persons who are unable to react to overheating.
- Not to be used by very young children (0-3 years). Children under the age of three are not to use this appliance due to their ability to react to overheating.
- Children shall not play with the blankets.
- Cleaning and user maintenance shall not be made by children without supervision.
- Never use the blankets unsupervised.
- Prolonged use of the blankets at a high setting could lead to skinburns.
- Never touch a blankets that has fallen into water. Unplug the blanket from the mains outlet immediately.
- Keep the mains cable away from hot surfaces.
- Never carry, pull or turn the blankets by the mains cable and do not let the cable get tangled.
- Do not use the blankets when wet and only use it in dry environments (not in the bathroom or similar environments).
- The controller and cable must not be exposed to any kind of moisture.
- If a fault occurs, do not attempt to repair the blanket by yourself. Repairs must only be carried out by an authorized specialist dealer or other suitably qualified personnel.
- If the power supply cable is damaged, it may only be replaced by, an authorised dealer or by qualified electricians. In order to prevent hazards, always send the blanket in to the service centre.

- Let the blankets cool down completely before folding and storing it. Do not fold it too tight.
- When not in use, store the blankets as follows:
  - Store the blankets in its original packaging and keep it in a clean, dry place.
  - Fold the power cable carefully to avoid cable breaks.
  - Do not crease the blankets by placing items on top of it during storage.
- Should you have any concerns about health issues, consult your doctor before using the blankets.
- The appliance can be used by children older than 3 years and younger than 8 years under supervision and with the control always set to minimum temperature value.
- The cable and control unit of the appliance can give rise to risks of entanglement, strangulation, tripping or treading if not correctly arranged. The user shall make sure that excess ties and electric cords shall be arranged in a safe way.



1. Electric Overblanket
2. Mains cable
3. Operating indicator
4. Switch & On/Off button


## CLEANING AND MAINTENANCE

- Before cleaning the blankets, unplug it from the mains outlet and let it cool down completely or for at least ten minutes.
- The blankets is equipped with a detachable cable. Disconnect the plug and remove the cable from the blankets.
- You may Machine wash,30°C.
- Do not use hair dryer to dry this product, have todry naturally, stretch the blanket out on a flat surface.
- Rinse the blankets several times to remove all the detergent.
- Store the blankets in a clean and dry place, laid out flat with nothing covering or resting on top ofit.
- Only use the blankets once it is completelydry.
- You may also wash the blankets in a washing machine at a maximum temperature of 30°C with low mechanical action and spin. It's advisable to wash it by hand in order to prolong the life of theproduct.

## DIS POSAL



This product must not be disposed of together with domestic waste.

All users are obliged to hand in all electrical or  electronic devices, regardless of whether or not they contain toxic substances, at a municipal or commercial collection point so that they can be disposed of in an environmentally acceptable manner.

Consult your local authority or your supplier for information about disposal.