

# EN

1. Speed adjusting 4 level speed with indicator light

2. Charging Red light: Charging Green light: fully charged

3. Angel Adjusting 45° vertical manually adjusting

### 4. Safety instructions

To prevent damage to this unit or injury to you or others, please read the following operating instructions before usage. Keep these operating instructions for your reference when needed.

- Do not use this product near open fire.
- This is not a toy and should be used only under adult supervision.
- Do not use outside in wet weather conditions, not water resistant.

## DE

1. Geschwindigkeitsanpassung 4-stufige Geschwindigkeit mit Kontrollleuchte

#### 2. Ladevoraana

Rotes Licht: Ladevorgang aktiv Grünes Licht: Vollständig geladen

3. Anpassung Schwenkkopf

45 ° vertikale manuelle Anpassung

#### 4. Sicherheitshinweise

Um Schäden an diesem Gerät oder Verletzungen bei Ihnen oder anderen Personen zu vermeiden, lesen Sie bitte vor dem Gebrauch die folgende Gebrauchsanweisung. Bewahren Sie diese Gebrauchsanweisung zum Nachschlagen auf, wenn Sie sie benötigen.

- Verwenden Sie dieses Produkt nicht in der Nähe von offenem Feuer.
- Dies ist kein Spielzeug und sollte nur unter Aufsicht von Erwachsenen verwendet werden.
- · Nicht im Freien bei nassem Wetter verwenden, nicht wasserdicht.











**Bedienungsanleitung** 

Art. no.: 2437 Batch. No.: 21415