

NEDERLANDSE GEBRUIKSAANWIJZING

- 1. Plaats de TEN Frietsnijder XXL** op een stabiele en niet-gladde ondergrond.
- 2. Selecteer de gewenste snijvorm (7mm, 10mm, 14mm).** Bevestig eerst de bijbehorende zwarte pers aan de bovenzijde van de frietsnijder. Zorg ervoor dat u de juiste maat schroevendraaiër gebruikt.
- 3. Het is belangrijk om de pers en de messen niet te vast aan te draaien;** gebruik niet overmatig veel kracht. Eenmaal vast is vast.
- 4. Bevestig vervolgens de messen door ze stevig vast te schroeven.** Controleer of de pers correct op de messen is geplaatst.
- 5. Opvangbak voor de gesneden frietjes** en plaats deze op de witte voet van de frietsnijder.
- 6. Plaats een aardappel op de messen van de frietsnijder** en klem deze stevig tussen de pers en de messen.
- 7. Begin met het snijden van de frieten,** terwijl u ervoor zorgt dat uw handen zich niet in de nabijheid van de messen bevinden. Bouwtijdens het snijden de kracht langzaam op.
- 8. Reinig de frietsnijder grondig** nadat u klaar bent met het snijden van frietjes.

Materialen

Roestvrijstaal, kunststof.

Reinigen

Was de frietsnijder handmatig af.

ENGLISH USERMANUAL

- 1. Place the TEN French Fry Cutter XXL on a stable and non-slip surface.**
- 2. Select the desired cutting size (7mm, 10mm, 14mm).** First, attach the corresponding black press to the top of the French fry cutter. Ensure that you use the correct size screwdriver.
- 3. It is important not to tighten the press and the blades too tightly;** do not use excessive force. Once secured, they are secured.
- 4. Next, securely fasten the blades by screwing them in place.** Verify that the press is correctly positioned on the blades.
- 5. Place a collection tray for the cut fries on the white base of the French fry cutter.**
- 6. Place a potato on the blades of the French fry cutter** and firmly clamp it between the press and the blades.
- 7. Begin cutting the fries,** ensuring that your hands are not near the blades. Gradually increase pressure while cutting.
- 8. Thoroughly clean the French fry cutter after finishing cutting fries.**

Materials

Stainless steel, plastic

Cleaning

Wash the French fry cutter and accessories manually.

GARANTIEVOORWAARDEN TEN® FRIETSNIJDER

- 1. Deze garantie geldt uitsluitend voor fabricagefouten en defecten die onder normale gebruiksomstandigheden optreden.** De garantie dekt geen schade veroorzaakt door misbruik, verkeerd gebruik, ongevallen of normale slijtage.
Next Gen. Trading VOF behoudt zich het recht voor om te bepalen of een product al dan niet aan de garantie voldoet.
- 2. Naleving van onderhoudsrichtlijnen:** het is essentieel om de onderhoudsinstructies/handleiding te volgen voor een geldige garantie.
- 3. Gebruik van door de fabrikant goedgekeurde accessoires:** het gebruik van niet-goedgekeurde accessoires kan de garantie ongeldig maken.
- 4. Uitsluiting van externe reparaties:** reparaties uitgevoerd door niet-geautoriseerde servicecentra doen afbreuk aan de garantie.
- 5. De klant dient duidelijke foto's en videomateriaal te verstrekken.**
6. Vervolgens sturen wij een vervangend onderdeel met bijbehorende instructies.
- 7. Geldigheidsduur van de garantie:** de levenslange garantie blijft geldig zolang de originele koper het product in bezit heeft.
- 8. Uitsluiting van normale slijtage:** Normale slijtage en veroudering van onderdelen die geen invloed hebben op de prestaties vallen niet onder de garantie.
- 9. Bewijs van aankoop:** een geldig aankoopbewijs (factuur) is vereist als bewijs voor garantiediensten.
- 10. Uitsluiting van externe schade:** schade veroorzaakt door externe factoren zoals natuurrampen of ongelukken valt niet onder de garantie. Ook vallen en stoten valt niet onder de garantie.

WARRANTY CONDITIONS FOR TEN® FRENCH FRY CUTTER

- 1. This warranty is valid only for manufacturing defects and defects occurring under normal usage conditions.** The warranty does not cover damage caused by abuse, improper use, accidents, or normal wear and tear. Next Gen. Trading VOF reserves the right to determine whether a product meets the warranty criteria.
- 2. Compliance with maintenance guidelines:** It is essential to follow the maintenance instructions/manual for a valid warranty.
- 3. Use of manufacturer-approved accessories:** The use of non-approved accessories may invalidate the warranty.
- 4. Exclusion of external repairs:** Repairs conducted by unauthorized service centers invalidate the warranty.
- 5. The customer must provide clear photos and video material.** Subsequently, we will send a replacement part with accompanying instructions.
- 6. Warranty validity period:** The lifetime warranty remains valid as long as the original purchaser owns the product.
- 7. Exclusion of normal wear and tear:** Normal wear and aging of parts that do not affect performance are not covered by the warranty.
- 8. Proof of purchase:** A valid purchase receipt (invoice) is required as evidence for warranty services.
- 9. Exclusion of external damage:** Damage caused by external factors such as natural disasters or accidents is not covered by the warranty. Additionally, falls and impacts are not covered by the warranty.