

140x95mm




6 IN 1 SCHEERAPPARAAT

GEBRUIKSAANWIJZING

Nominale spanning : 3.7V
 Nominale vermogen : 5W (USB)
 Invoerparameter : 5V (USB)
 Opladetiijd : 90 minuten
 Gebruiksduur : 60 minuten



Made in China

TRIMTECH

INHOUDSOPGAVE

NEDERLANDS.....3
 ENGLISH.....13

NEDERLANDS


NL Waarschuwing

Houdt het scheerapparaat en de USB-oplaadkabel uit elkaar voordat u het in water reinigt.

- Dit product maakt gebruik van een USB-oplaadkabel.
- U kunt de meegeleverde USB-adapter, oplader voor mobiele telefoons of een USB-interface van auto's, computers en andere gebruiken om op te laden.
- Als de USB-oplaadkabel beschadigd is, vervangt u deze door een nieuwe kabel om gewaar te vermijden.
- Het scheerapparaat moet worden opgeladen en opgeslagen tussen de 5°C (41 °F) en 35°C (95 °F).
- Zorg ervoor dat het laadstation en de USB-oplaadkabel droog zijn. Niet koppelen of ontkoppelen met natte handen om elektrische schokken te voorkomen.
- Controleer of de scheerbladen beschadigd of vervormd zijn om schade aan uw huid te voorkomen.
- Was het scheerapparaat met schoon water, maar week het niet te lang in het water.
- Gebruik geen zout water, heet water boven 60°C (140 °F), verdunners, benzine, alcohol of andere chemicaliën om het scheerapparaat te reinigen.
- Het is noodzakelijk om het scheerapparaat te bedekken met de beschermkap (wanneer u op reis gaat) om de scheerbladen te beschermen.
- Tijdens het gebruik en opladen kan het scheerapparaat licht verwarmd aanvoelen. Dit is normaal en veilig.
- Laadt het scheerapparaat niet langer op dan de oplaadtiijd van 90 minuten.
- Bewaar het scheerapparaat niet in direct zonlicht of in de buurt van andere warmtebronnen.

4

NL Hoe te gebruiken




- Opladen**
 1. Wanneer het LED-display '10' weergeeft, geeft dit aan dat het scheerapparaat bijna leeg is en moet worden opgeladen (Fig. 1).
 2. Sluit het uiteinde van de USB-oplaadkabel (1) aan op het scheerapparaat, sluit vervolgens de USB-kabel (2) aan op de oplader en steek deze in het stopcontact (Fig. 2) of sluit het andere uiteinde van de USB-kabel aan op een USB-poort van computers, auto's of andere.
 3. Wanneer het scheerapparaat wordt opgeladen, zal het LED-display oplichten met het stekkersymbool en nummers die oplopen naarmate je het apparaat oplaad, wat aangeeft dat het apparaat wordt opgeladen (Fig. 3).
 4. Volledig opladen duurt ongeveer 90 minuten. Na volledig opladen wordt '100' weergegeven op het LED-display (Fig. 4), wat aangeeft dat het scheerapparaat volledig is opgeladen en ongeveer 60 minuten kan worden gebruikt.

Het LED-display van het scheerapparaat toont het batterijniveau. Een volledig opgeladen scheerapparaat kan tot ongeveer 60 minuten mee, maar de werkelijke scheerduur kan minder zijn dan verwacht vanwege verschillen in scheer gewoonten, schoonaak gewoonten en baardtypen.

⚠ Het scheerapparaat kan worden gebruikt tijdens het opladen.

5

NL Hoe te gebruiken



Scheren

- Druk op de aan/uit-knop om het scheerapparaat in of uit te schakelen (Fig. 5).
- Beweeg de bladen van het scheerapparaat tegen de groeirichting van je haar en maak rechte en herhaalde bewegingen (Fig. 6).
- Tijl je kin op om je nek te scheren (Fig. 7).
- Voordat je je hoofd scheert, maak je het schone met warm water en droog je je haar. Voor het beste gebruik effect, gebruikt u het schoonmaakborstelje om de scheerkop schoon te maken tijdens het scheren van het hoofd. Was de scheerkop met schoon water nadat u klaar bent met scheren (Fig. 8).

Wanneer het scheren en reinigen is voltooid, bedekt u de scheerkop met de beschermkap om schade aan de scheerbladen te voorkomen.


⚠ Gebruik geen beschadigde scheerkop om letsel aan uw huid te voorkomen.

Veiligheidsnot

- Houdt de aan/uit-knop van het scheerapparaat ingedrukt, waarna het vergrendelde veiligheidsslot op het LED-display wat aangeeft dat het veiligheidslot is ingeschakeld (Fig. 9).
- Houdt de aan/uit-knop van het scheerapparaat ingedrukt om het veiligheidslot te ontgrendelen (Fig. 10).

6


NL Hoe te gebruiken



Simme weergeve van LED-display

- Wanneer het scheerapparaat overbelast is, wordt het automatisch uitgeschakeld en geeft het LED-display het signaal 'bescherming tegen verstopping' aan. Op dit moment moet het scheerapparaat voor gebruik worden schoongemaakt (Fig. 11).
- Wanneer het kraansymbool op het LED-display verschijnt, geeft dit aan dat het scheerapparaat moet worden gereinigd (Fig. 12).

Onderhoud



Wassen en reinigen met water

- Voor het schoonmaken ontkoppel het scheerapparaat van de USB-oplaadkabel en schakel het scheerapparaat uit. Maak het scheerapparaat met schoon water, maar week het niet lang in water.
- Trek aan de magnetische scheerkop van het scheerapparaat om deze los te halen (Fig. 13).

7

NL

- Het scheerapparaat en de magnetische scheerkop kunnen direct onder een lopende kraan worden gewassen (Fig. 14), maar week het niet te lang in water.
- Giet na het wassen overtollig water af, houdt het scheerapparaat horizontaal en laat het drogen. Veeg het magnetische scheerkop gedeelte of elektrisch scheerapparaat niet af met tissue of doek, dit kan schade veroorzaken.
- Laat het scheerapparaat en de magnetische scheerkop drogen en bedek het vervolgens met de beschermkap om schade aan de scheerbladen en ophoping van stof te voorkomen.
- Plaats de magnetische scheerkop terug op het scheerapparaat als deze droog is (Fig. 15).

Vervanging van de scheerkop

De scheerkop moet minstens eens in de zes tot twaalf maanden worden vervangen om een goed resultaat te blijven behouden.

⚠ Ontkoppel het scheerapparaat van de USB-oplaadkabel voordat u het in water reinigt.

Trimmen

Gebruik voor het trimmen van haar.

- Druk de schuif naar achteren om de haartrimmer te openen en druk vervolgens op de aan/uit-knop om deze in of uit te schakelen (Fig. 16).

Gebruiksaanwijzing voor bevestiging van de haartrimmer

Druk op de aan/uit-knop om het scheerapparaat uit te schakelen, trek de scheerkop omhoog om deze eraf te halen en druk vervolgens het haartrimmer opzetstuk in de groef bovenop het scheerapparaat (totdat u een klik hoort) (Fig. 17).

8

NL

Haartrimmer

- Let op: Zorg ervoor dat je haar schoon en droog is, gebruik de haartrimmer niet op nat haar.
- Kam je haar in de groeirichting met een kam voordat je gaat trimmen.
- Schuif het haartrimmer opzetstuk in de opzetkam en duw de clip naar beneden (totdat u een klik hoort) en controleer of deze correct is gemonteerd (Fig. 18).
- De meegeleverde opzetkammen zijn optioneel te gebruiken voor verschillende kapsel lengtes, 3 mm, 5 mm en 7 mm, die naar wens kunnen worden gemonteerd. Als u een opzetkam wilt vervangen, duwt u de clip omhoog en verwijdt u de opzetkam (Fig. 19).
- Druk op de aan/uit-knop om het apparaat in te schakelen en beweeg de haartrimmer langzaam op je haar. Beweeg de haartrimmer tegen de groeirichting van je haar in om het beste effect te krijgen.

Haartrimmer reiniging

- Trek het haartrimmer opzetstuk van het scheerapparaat af en reinig het trimmende deel met het meegeleverde schoonmaakborstelje of was het opzetstuk met schoon water.
- Reinig de haartrimmer niet met zout water, heet water boven de 60 °C (140 °F), verdunners, benzine, alcohol, acetone of andere chemicaliën.
- Reinig de haartrimmer elke keer direct na gebruik.

Gebruiksaanwijzing voor de precisietrimmer

Druk op de aan/uit-knop om het scheerapparaat uit te schakelen, trek de scheerkop omhoog om deze eraf te halen en druk vervolgens het precisietrimmer opzetstuk in de groef bovenop het scheerapparaat (totdat u een klik hoort) (Fig. 20).

9

NL

Precisietrimmer reiniging

- Trek het precisietrimmer opzetstuk van het scheerapparaat af en reinig het trimmende deel met het meegeleverde schoonmaakborstelje of was het opzetstuk met schoon water.
- Reinig het precisietrimmer opzetstuk niet met zout water, heet water boven de 60 °C (140 °F), verdunners, benzine, schuurmiddelen, alcohol, benzine, acetone of andere chemicaliën.
- Reinig het precisietrimmer opzetstuk elke keer direct na gebruik.

Gebruiksaanwijzing voor neus- en oortrimmer

Druk op de aan/uit-knop om het scheerapparaat uit te schakelen, trek de scheerkop omhoog om deze eraf te halen en druk vervolgens het neus- en oortrimmer opzetstuk in de groef bovenop het scheerapparaat (totdat u een klik hoort) (Fig. 20).

Neushaar trimmen

- Zorg ervoor dat je neusholte schoon is.
- Druk op de aan/uit-knop om deze in te schakelen, steek de trimmerpunt langzaam in een van uw neusholtes en draai de punt om overmatig / te lang haar te verwijderen (Fig. 21).
- De inbrengdiepte van de trimmerpunt in uw neusholte mag niet dieper zijn dan 0,5 cm. Om jeuk te verminderen, moet u ervoor zorgen dat één kant van de trimmerpunt stevig tegen uw huid wordt gedrukt.

Oorhaar trimmen

- Reinig uw externe gehooropening om er zeker van te zijn dat er geen cerumen is.
- Druk op de aan/uit-knop om het apparaat in te schakelen en

10

NL

- maak vervolgens cirkelvormige bewegingen met de trimmerpunt in je oor om uitstekende haren op je oorschelp te verwijderen (Fig. 22).
- Steek de trimmerpunt voorzichtig in de uitwendige gehooropening. De inbrengdiepte van de trimmerpunt in uw gehooropening mag niet dieper zijn dan 0,5 cm, anders kan het uw trommelfolij beschadigen.

Neus- en oortrimmer reiniging

Druk op de aan/uit-knop om het scheerapparaat af te schakelen, trek de scheerkop omhoog om deze eraf te halen, steek vervolgens de extensie van de gezichtsreiniger in de groef bovenop het scheerapparaat en druk vervolgens het opzetstuk van de gezichtsreiniger bovenop de extensie (totdat u een klik hoort) (Fig. 23).

11

NL

- Was uw gezicht met schoon water en droog daarna uw gezicht voordat u de massageborstel gebruikt.

Massageborstel reiniging

- Trek de rubberen massagekop van de massageborstel, was de rubberen massagekop met schoon water en laat hem daarna drogen.
- Reinig de rubberen massagekop niet met zout water, heet water boven de 60 °C (140 °F), verdunners, benzine, schuurmiddelen, alcohol, benzine, acetone of andere chemicaliën.
- Reinig de rubberen massagekop onmiddellijk na gebruik.

Inhoud van de verpakking:

- Scheerapparaat
- Beschermkap
- Haartrimmer (3 / 5 / 7 mm)
- Precisietrimmer
- Neus- en oortrimmer
- Gezichtsreiniger
- Massageborstel
- Schoonmaakborstelje
- Haarkam
- USB-oplaadkabel
- USB-adapter
- Neus- en oortrimmer
- Meertalige gebruiksaanwijzing

Milieubescherming

- Om het product veilig te gooien, moet u het niet in een gewone vuilnisbak deponeren, maar overhandigen aan het officieel aangewezen recyclingcentrum voor milieubescherming (Fig. 24).
- De ingebouwde oplaadbare batterij bevat stoffen die het milieu kunnen vervuilen, dus het moet worden verwijderd van het product of worden verzonden worden naar het officieel aangewezen recyclingcentrum om gerecycled te worden voordat het product wordt weggegooid. De batterij mag niet worden gerecycled tenzij deze is opgelabeld.

a. Koppel de oplader los en trek ook de opladkabel uit het scheerapparaat.
 b. Ontlaad de batterij. Steek de stekker van het scheerapparaat niet meer in het stopcontact nadat u de batterij hebt ontladen.

12

ENGLISH

13


EN Warning

Separate the electric shaver from the USB charging cable before cleaning it in water.

- This product uses a USB charging cable.
- You can use the included USB adapter, mobile phone charger, or a USB interface of cars, computers and others for charging.
- If the USB charging cable is damaged, replace it with a new one to avoid danger.
- The electric shaver shall be charged and stored between 5°C (41°F) and 35°C (95°F).
- Make sure the charging station and USB charging cable are dry. Do not plug or unplug with wet hands to prevent electric shock.
- Please check if the foil is damaged or deformed before use to avoid damage to your skin.
- Wash the electric shaver with clean water, but do not soak it in water for a long time.
- Do not use salt water, hot water above 60°C (140°F), thinners, gasoline, alcohol or other chemicals to clean the electric shaver.
- It's necessary to cover the electric shaver with the protective cover when you travel to protect its foil.
- While using and charging, the electric shaver may be slightly heated. This is normal and safe.
- Do not charge the electric shaver for too long.
- Do not store the electric shaver in direct sunlight or near other sources of heat.

14

EN How to use



Charging


- When the LED-display shows '10' it indicates that the electric shaver is on low battery and needs charging (Fig. 1).
- Plug the USB charging cable end (1) into the electric shaver, then connect the USB cable (2) to the charger and plug it into the power socket (Fig. 2), or plug the other end of the USB cable into a USB port of computers, cars or others.
- When the electric shaver is charging, the LED-display will light up with the plug symbol and scrolling numbers which will increase as the charging time extends, indicating that it's charging (Fig. 3).
- Fully charging takes about 90 minutes. After fully charging, 100 will be displayed on the LED-display (Fig. 4), indicating that the electric shaver has been fully charged and can be used for about 60 minutes.

The LED-display of the electric shaver shows the battery level. A fully charged electric shaver can provide a shaving duration up to about 60 minutes, but the actual shaving duration may be less than expected due to differences in shaving habits, cleaning habits and beard types.

⚠ The electric shaver can be used while charging.

15

EN How to use



Shaving

- Press the on/off button to turn the electric shaver on or off (Fig. 5).
- Move the electric shaver foil against the growth direction of your hair on your skin and make straight and repetitive movements (Fig. 6).
- Lift your chin to shave your neck (Fig. 7).
- Before shaving your head, clean it with warm water and dry your hair. For the best usage effect, use the cleaning brush to clean the shaving head during the head-shaving process. Wash the shaving head with clean water after shaving is completed (Fig. 8).

When shaving and cleaning is completed, cover the shaving head with the protective cover to avoid damage to the foil.


⚠ Please do not use any damaged shaving head to avoid injury to your skin.

Safety Lock

- Press and hold the electric shaver on/off button, then the lock symbol will blink on the LED-display which indicates that the safety lock is on (Fig. 9).
- Press and hold the electric shaver on/off button to unlock the safety lock (Fig. 10).

16


EN How to use



Intelligent display of contents

- When the electric shaver is overloaded it will be automatically turned off and the LED-display will indicate stall protection. At this time it should be cleaned up before use (Fig. 11).
- When the faucet symbol shows up on the LED-display it indicates that the electric shaver needs to be cleaned (Fig. 12).

Maintenance



Wash and clean with water

- Before cleaning, separate the electric shaver from the USB charging cable and turn off the electric shaver. Wash the electric shaver with clean water, but do not soak it in water for a long time.
- Pull the magnetic shaving head of the electric shaver (Fig. 13).
- The electric shaver and magnetic shaving head can be washed directly under a running tap (Fig. 14), but do not soak it in water for

17

EN

- a long time.
- After washing, drain any excess water, put it horizontally and air-dry it. Do not wipe the magnetic shaving head part or electric shaver with tissue or cloth, this may cause damage.
- Let the electric shaver and magnetic shaving head dry, then cover it with the protective cover to prevent damage to the foil and avoid accumulation of dust.
- Put back the magnetic shaving head on the electric shaver when it is dry (Fig. 15).

Replace shaving head

The shaving head should be replaced at least once every six months to twelve months for a good experience.

⚠ Separate the electric shaver from the USB charging cable before cleaning it in water.

Trimming

Used for trimming hair.

- Push the slide back to open the hair trimmer, then press the on/off button to turn it on or off (Fig. 16).

Operating instructions for hair clipper attachment

Press the on/off button to turn off the electric shaver, pull it up (Don't screw it up) to take off the shaving head, then insert the extension of the message brush attachment on top of the extension (until you hear a click) (Fig. 17).

18

EN

Hair clipper

Note: Make sure your hair is clean and dry, don't use the hair clipper on wet hair.

- Comb your hair along its growth direction with a comb before trimming.
- Slide the hair clipper attachment into the attachment comb and push the clip down (Until you hear a click) then make sure it's mounted correctly (Fig. 18).
- The included attachment combs are optional for different haircut lengths, 3mm, 5mm and 7mm, which can be mounted as required. To replace an attachment comb, push up the clip and take off the attachment comb (Fig. 19).
- Press the on/off button to turn it on and move the hair clipper slowly on your hair. Move the hair clipper against the growth direction of your hair to get the best haircut effect.

Hair clipper cleaning

- Pull off the hair clipper attachment from the electric shaver and clean the trimming part with the included small cleaning brush or wash the hair clipper attachment with clean water.
- Don't clean the hair clipper attachment with salt water, hot water above 60°C (140°F), thinners, gasoline, alcohol, petrol, acetone or other chemicals.
- Clean the hair clipper immediately after use each time.

Operating instructions for the precision trimmer

Press the on/off button to turn off the electric shaver, pull it up (Don't screw it up) to take off the shaving head, then press the precision trimmer attachment into the groove on top of the electric shaver body (until you hear a click) (Fig. A).

19

EN Precision trimmer cleaning

- Pull off the precision trimmer attachment from the electric shaver and clean the trimming part with the included small cleaning brush or wash the precision trimmer attachment with clean water.
- Don't clean the precision trimmer attachment with salt water, hot water above 60°C (140°F), thinners, gasoline, abrasives, alcohol, petrol, acetone, or other chemicals.
- Clean the precision trimmer immediately after use each time.

Operating instructions for nose and ear trimmer

Press the on/off button to turn off the electric shaver, pull it up (Don't screw it up) to take off the shaving head, then press the nose and ear trimmer attachment into the groove on top of the electric shaver body (until you hear a click) (Fig. 20).

Nose hair trimming

- Make sure your nasal cavity is clean.
- Press the on/off button to turn it on, slowly insert the trimmer tip into one of your nasal cavities, then turn and twist the tip to remove excessive/overlong nasal hair (Fig. 21).

The insertion depth of the trimmer tip into your nasal cavity must not exceed 0.5cm. To reduce pruritus, make sure that one side of the trimmer tip is firmly pressed against your skin.

Ear hair trimming

- Clean your external auditory canal to ensure there is no cerumen.
- Press the on/off button to turn it on and then make the trimmer tip circle along your ear gently to remove protruding hair on your helix (Fig. 22).

20

EN

- Carefully insert the trimmer tip into the external auditory canal. The insertion depth of the trimmer tip into your auditory canal must not exceed 0.5 cm, or else your eardrum may get injured.

Nose and ear trimmer cleaning

- When the electric shaver is overloaded it will be automatically turned off and the LED-display will indicate stall protection. At this time it should be cleaned up before use (Fig. 11).
- When the faucet symbol shows up on the LED-display it indicates that the electric shaver needs to be cleaned (Fig. 12).

Facial cleanser

Cleanse your face with the facial cleanser. Remove sebum and dirt on your face with the facial cleanser every day, which helps to keep your skin clean and healthy.

Operating instructions for facial cleanser

- Press the on/off button to turn off the electric shaver, pull it up (Don't screw it up) to take off the shaving head, then insert the extension of the facial cleanser into the groove on top of the electric shaver body, and press the facial cleanser attachment on top of the extension (until you hear a click) (Fig. 23).
- Moisturize the facial cleanser with clean water.
- Do not cleanse your face directly with a dry facial cleanser, which may irritate your skin.

21

EN

Message brush

- Massage your face with the message brush.
- Massage your face with the message brush every day, which helps to stimulate blood flow and aid circulation.

Operating instructions for message brush

- Press the on/off button to turn off the electric shaver, pull it up (Don't screw it up) to take off the shaving head, then insert the extension of the message brush attachment on top of the extension (until you hear a click) (Fig. 23).
- Wash your face with clean water, then dry your face before using the message brush.

Message brush cleaning

- Pull off the rubber massager head from the message brush attachment and wash the rubber massager head with clean water, then let it dry.
- Don't clean the rubber massager head with salt water, hot water above 60°C (140°F), thinners, gasoline, alcohol, petrol, acetone, or other chemicals.
- Clean the rubber massager head immediately after use each time.

Package contents

- Electric shaver
- Protective cover
- Hair clipper (including attachment combs: 3 / 5 / 7 mm)
- Precision trimmer
- Nose and ear hair trimmer
- Facial cleanser
- Message brush
- Small cleaning brush
- Comb
- USB charging cable
- USB adapter
- Travel case
- multilingual user manual

Environmental protection

- To discard the product, please don't put it together with general domestic rubbish but send it to the officially designated recycling center for environmental protection (Fig. 24).
- The built-in rechargeable battery contains substances which may pollute the environment, so it must be separated from the product or sent to the officially designated recycling center to be disposed of before it is discarded. The battery should not be unsealed unless it has been used up.

22

EN

- Unplug the charger and also pull out the product's plug from the shaver.
- Unload the battery. Do not plug in the shaver again after unloading the battery.

23