

NL HANDLEIDING + EN MANUAL

BEIGE/BROWN/LIGHT/DARK SKIN PRIME VIBRATOR

LET OP: U VERLIEST HET RECHT OM TE RETOURNEREN WANNEER U DE SEAL HEEFT DOORBROKEN (SEAL: DOORZICHTIGE PLASTIC ZAK IN DOOS). DIT IS BEPAALD DOOR DE NEDERLANDSE WET: **ARTIKEL 6:230p F 3.**



NL) 1. Laad de SKIN PRIME VIBRATOR volledig op.

NL) 2. Doe eerst het apparaat aan (**NIET VIA DE AFSTANDBEDIENING**), de aan knop zit aan de onderkant van de vibrator (KANT VAN DE ZUIGNAP). Deze is te vinden net iets boven de CE markering. Na inschakeling gaat er een lichtje branden. (De afstandsbediening werkt pas als de vibrator handmatig is ingeschakeld).

NL) 3. De vibrator is erg makkelijk in gebruik. De SKIN PRIME heeft 3 knoppen op de afstandsbediening.

NL) 4. Houdt **de middelste knop** voor 2 secondes ingedrukt om de vibrator in te schakelen. Dezelfde knop kan gebruikt worden om door de 6 intense stootstanden te rouleren.

NL) 5. De **bovenste knop** bedient de vibrerende gedeelte van de vibrator. Je hebt keuze uit 10 verschillende vibratie standen.

NL) 6. De **onderste knop** bedient de verwarm gedeelte.

NL) 7. De SKIN PRIME komt met een usb-oplader en kan dus overal opgeladen worden.

NL) 8. Combineer de stotende bewegingen met de vibrerende bewegingen om tot een intense climax te komen. Geniet van je aankoop!

CAUTION: YOU LOSE YOUR RIGHT TO RETURN THE PRODUCT WHEN YOU HAVE BROKEN THE SEAL (SEAL: PLASTIC BAG IN THE PRODUCT BOX). THIS IS DETERMINED BY DUTCH LAW: **ARTICLE 6:230p F 3.**

EN) 1. Fully charge the SKIN PRIME VIBRATOR.

EN) 2. First turn on the device (**NOT VIA THE REMOTE CONTROL**), the on button is located at the bottom of the vibrator (**SIDE OF THE SUCTION CUP**). This can be found just above the CE marking. After switching on, a light will come on. (**The remote control will not work until the vibrator is turned on manually**).

EN) 3. The vibrator is very easy to use. The SKIN PRIME has 3 buttons on the remote control.

EN) 4. Press and hold **the middle button** for 2 seconds to turn on the vibrator. The same button can be used to cycle through the 6 intense thrusting modes.

EN) 5. **The top button** controls the vibrating part of the vibrator. You can choose from 10 different vibration modes.

EN) 6. **The bottom button** controls the heating part.

EN) 7. The SKIN PRIME comes with a USB charger and can therefore be charged anywhere.

EN) 8. Combine the thrusting movements with the vibrating movements to reach an intense climax. Enjoy your purchase!