

**Gebruiksaanwijzing:** Het snoer van deze verlichtingsset kan niet worden vervangen. Wanneer het snoer vernietigd. Sluit het snoer niet aan op het stroomnet wanneer die in de verpakking zit. De lampen verlichtingsset heeft 3 functies: 1. "ON" voor continu aan, 2. "TIMER" voor automatisch 8 uur aan.  
**d'emploi:** Le cordon de cet ensemble d'éclairage ne peut pas être remplacé ; si le cordon est cassé, ne pas brancher l'alimentation lorsque la guirlande est toujours dans l'emballage. Les lampes ont 3 fonctions : 1. "ON" pour allumé en continu, 2. "TIMER" pour allumé pendant 8 heures automatiquement.

**Verbindwijze:** Das flexible Kabel dieses Beleuchtungssets kann nicht ausgetauscht werden; wenn es zerstört wird, darf das Stromnetz nicht angeschlossen werden, solange sich die Verpackung befindet. Dieses Beleuchtungsset hat 3 Einstellungen:

1. "ON" = Dauerbetrieb, 2. "TIMER" = automatisch 8 St. an und 16 St. aus, 3. "OFF" = dauerhaft aus.

**Instructions:** The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, do not connect the chain to the supply while it is in the packing. The lamps are not replaced automatically (8 hours on and 16 hours off).



Itemnr.: 240206

Input: 220-240V - 50-60 Hz.

Output: 31V - 116mA - 3,6VA

CBD - P.O.BOX 16

1738 ZG - WAARLAND (NL)

& buiten

Inter- & exterieur

Innen & at