

# LYVION

INSTRUCTIONS FOR SAFE STYLING

CERAMISCH

POWER: 85W/50-60HZ

VOLTAGE: 100-240V

# LYVION KRULTANG INSTRUCTIES

## **LEES ALLE INSTRUCTIES VOOR HET GEBRUIK;**

Bij gebruik van de LYVION krultang, pas op met gebruik bij aanwezigheid van kinderen.

## **HOUD DE KRULTANG UIT DE BUURT VAN WATER.**

Zoals bij alle elektrische producten zijn delen elektrisch en steeds verbonden wanneer de schakelaar uitstaat.

Ontkoppel de krultang altijd na gebruik.

Gebruik geen vloeistoffen bij de krultang.

Bewaar of plaats het product waar het niet kan vallen of worden getrokken in vloeistoffen.

Niet in water of andere vloeistof plaatsen of laten vallen. Als het toestel in het water valt, ontkoppel het product direct en laat de vloeistof weglopen zonder hiermee in contact te komen.

Dit toestel heeft een gepolariseerde stekker als veiligheidsvoorziening. Als deze niet past neem dan contact op met de servicedesk

## **VERWISSELEN VAN OPZETSTUKKEN:**

### 1. Afkoppelen

Wacht totdat de opzet stukken afgekoeld zijn. Druk de twee knoppen aan de voorkant van het handvat in, en trek aan het opzet stuk om deze te vervangen.

### 2. Opzet stuk plaatsen

Wacht tot dat de opzet stukken afgekoeld zijn. Pak het gewenste opzetstuk, klik deze doormiddel van de 2 knoppen ingedrukt te houden in het toestel en duw deze aan. Deze zal dan gesloten worden.

## **WAARSCHUWING**

Om het risico van brandwonden, elektrocutie, brand of schade aan andere personen te voorkomen wordt het volgende aanbevolen.

Het toestel niet achterlaten zonder toezicht na aansluiting op stroom. Nauwe supervisie is nodig wanneer de LYVION krultang wordt gebruikt door, op of in de buurt van kinderen of personen met bepaalde handicaps.

Gebruik dit apparaat alleen voor de degene die hiervoor gevoegd is zoals beschreven staat. Gebruik geen bijlagen die niet door de fabrikant zijn aanbevolen.

Houd de snoer uit de buurt van andere warme objecten.

Wikkel de snoer NIET om of rond de verhitte delen.

Gebruik nooit tijdens het slapen.

Nooit laten vallen, bij oprapen nooit het verhitte deel vast houden.

Laat geen ogen en blote huid aanraken aan de verwarmde oppervlakken. Gebruik de hengel Gebruik geen verlengsnoer met dit toestel

Zet het verwarmde toestel niet direct op elk oppervlak terwijl deze verhit is of aangesloten. Probeer het toestel niet zelf te repareren als er een storing optreed.

Laat dit toestel nooit werken als er een beschadiging in de netsnoer of stekker is, als de LYVION krultang in aanraking is gekomen met water of de aansluiting kabel is beschadigd, kan deze worden terug gestuurd naar ons service centrum voor reparatie.

## **KRULTANG INSTRUCTIES**

Kies jou favoriete opzet stuk. Selecteer een deel van het haar om een krul in te plaatsen. Plaats het begin van de krultang bij het begin van de haar grens met de punt naar beneden. Begin met het wikkelen van het haar op het breedste stuk van het opzet stuk. Draai het haar om de krultang in een neerwaartse spiraal naar beneden. Houd het haar rond de krultang voor 2 a 5 seconden. Draai de krultang los van het haar zonder hieraan te trekken. Schuif de krultang uit het haar. Doe dit met de gewenste plukken en krijg in een oogwenk de perfecte bos krullen.

## **ONDERHOUDSINSTRUCTIES**

Het toestel is vrijwel onderhoudsvrij. Er is geen smering nodig. Hou de hete oppervlakken schoon van stof, vuil, haarlak. Als reiniging nodig is laat de opzet stukken dan eerst afkoelen. Hierna kan het gezuiverd worden met een vochtige doek.

## **OPSLAG**

Wanneer niet in gebruik. Laat het toestel eerst afkoelen en bewaar buiten bereik van kinderen in een veilige, droge locatie. Wikkel de snoer nooit om het toestel. Voor een lange levensduur de opzet stukken apart van het toestel bewaren.

# LYVION CURLING IRON INSTRUCTIONS

## **IMPORTANT SAFETY INSTRUCTIONS**

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

### **READ ALL INSTRUCTIONS BEFORE USING.**

### **KEEP ELECTRICAL PRODUCTS AWAY FROM WATER.**

As with all electrical products parts are electrically live when switch is off as still connected to a live electricity supply, hence to avoid danger.

Always unplug after use.

Do not use around liquids.

Do not store or place the product where it can fall or be pulled into liquids (i.e. near sink or tub).

Do not place in or drop in water or any other liquid.

If appliance falls into water, "unplug it" immediately. Do not reach into water.

## **HOW TO CHANGE THE DIFFERENT TUBES?**

1. Take down, wait until it comes not heat, press down the two buttons in front of the handle, punt the tube, then pull down.

2. Put on

Wait until it comes not heat . Let both sides at the same level, hold the handle and push it in directly, then it will be locked.

## **WARNING**

To reduce the risk of burns , electrocution, fire, or injury to other people:

An appliance should never be left unattended when plugged in. Close supervision is necessary when this appliance is used by , on , or near

children or individuals with certain disabilities. Use this appliance only for its intended use as described in this manual. DO NOT use attachments not recommended by the manufacturer. Never operate this appliance if it has a damaged cord or plug, if it is working properly, or if it has been dropped, damaged, or dropped into water. Return the appliance to a service centre for examination and repair. Keep the cord away from heated surfaces. DO NOT wrap the cord around the appliance. Never use while sleeping. Never drop or insert any object into any opening or hose. DO NOT use outdoors or operate where aerosol ( spray ) products are being used or where oxygen is being administered. This curling iron is hot when in use. DO NOT let eyes and bare skin touch heated surface. Use the handle. DO NOT use an extension cord with this appliance. DO NOT place the heated appliance directly on any surface while it is hot or plugged in.

### **CURLING IRON INSTRUCTIONS**

Step 1. Select a small even strand of hair to place in a curl.(Note. for full head curls prior to curling, section your hair and curl from your neckline to forehead.)

Step 2. Place the base of the curling iron handle near the scalp or your head with the tip facing down.

Step 3. Wrap the hair from the base of the curling iron to the tip in a downward direction ( using the heat protective glove to protect your hands ).

Step 4. Hold the hair around the curler for 2 to 5 seconds.

Step 5. Without pulling the curling iron down, release the hair from the tip allowing the hair to slide out.

Step 6. Slide the curling iron out of the hair. DO NOT PULL IT DOWN ; IT WILL MAKE THE CURL TANGLE.

It is preferable that prior to curling that the hair is not covered in too much hair styling products as these may weigh down or damage the hair (i.e. too much gel, mousse etc. )

Save The Instructions and refer back to them as necessary.

### **MAINTENANCE INSTRUCTIONS**

Your appliance is virtually maintenance free. No lubrication is needed. Keep heated surfaces clean and free of dust,dirt and hair spray. If cleaning becomes necessary,disconnect the appliance from the power source allow to cool. Wipe the exterior with a damp cloth. If the cord becomes twisted, untwist prior to use.

### **STORAGE**

When not in use, "unplug it". Allow the appliance to cool and store out of reach of children in a safe, dry location. Never wrap the cord around the appliance since this will cause the cord to wear prematurely and break. Handle cord carefully for longer life and avoid jerking,bending sharply, twisting ,or straining cord, especially

### **OPERATING INSTRUCTIONS**

This appliance has a polarized plug ( one blade is wider than the other ). As a safety feature,this plug. If it still does not fit, contact a qualified electrician. DO NOT attempt to defeat the safety feature.