

NL HANDLEIDING + EN MANUAL

SKIN PRIME BUTTPLUG



LET OP: U VERLIEST HET RECHT OM TE RETOURNEREN WANNEER U DE SEAL HEEFT DOORBROKEN (SEAL: DOORZICHTIGE PLASTIC ZAK IN DOOS). DIT IS BEPAALD DOOR DE NEDERLANDSE WET: **ARTIKEL 6:230p F 3.**

NL) 1. Laad de SKIN PRIME BUTTPLUG volledig op.

NL) 2. Doe eerst de buttplug aan (**NIET VIA DE AFSTANDSBEDIENING**), de aan knop zit aan de onderkant van de buttplug. Na inschakeling gaat er een lichtje branden. (De afstandsbediening werkt pas als de buttplug handmatig is ingeschakeld).

NL) 3. De buttplug is erg makkelijk in gebruik. De SKIN PRIME heeft 3 knoppen op de afstandsbediening.

NL) 4. Houdt **de middelste knop** voor 2 secondes ingedrukt om de buttplug in te schakelen. Deze knop kan ook meteen gebruikt worden om door de 5 intense stootstanden te rouleren.

NL) 5. **De bovenste knop** bedient de vibrerende gedeelte van de buttplug. Je hebt keuze uit 10 verschillende vibratie standen.

NL) 6. **De onderste knop** bedient de verwarm gedeelte.

NL) 7. De SKIN PRIME BUTTPLUG komt met een usb-oplader en kan dus overal opgeladen worden.

NL) 8. Combineer de stotende bewegingen met de vibrerende bewegingen om tot een intense climax te komen. Geniet van je aankoop!

CAUTION: YOU LOSE YOUR RIGHT TO RETURN THE PRODUCT WHEN YOU HAVE BROKEN THE SEAL (SEAL: PLASTIC BAG IN THE PRODUCT BOX). THIS IS DETERMINED BY DUTCH LAW: **ARTICLE 6:230p F 3.**

EN) 1. Fully charge the SKIN PRIME BUTTPLUG.

EN) 2. First turn on the butt plug (**NOT VIA THE REMOTE CONTROL**), the on button is located at the bottom of the butt plug. After switching on, a light will shine. (The remote will not work until the butt plug is manually activated).

EN) 3. The butt plug is very easy to use. The SKIN PRIME has 3 buttons on the remote control.

EN) 4. Press and hold **the middle button** for 2 seconds to turn on the butt plug. This button can also be used directly to cycle through the 5 intense thrusting modes.

EN) 5. The **top button** controls the vibrating part of the butt plug. You can choose from 10 different vibration modes.

EN) 6. **The lower button** controls the heating part.

EN) 7. The SKIN PRIME BUTTPLUG comes with a USB charger and can therefore be charged anywhere.

EN) 8. Combine the thrusting movements with the vibrating movements to reach an intense climax. Enjoy your purchase!