



# MANUAL

Materials: ABS + Silicone

Working time: 1 hour

Charging time: 2 hours

Charging method: Magnetic

Modes:  
7 G-spot vibrations  
7 Clitoris vibrations  
7 Flap positions

## PACKAGE CONTENTS

1 Driesa Sensation Vibrator  
1 Charging cable  
1 Manual



### ON/OFF BUTTON

Long press for 3 seconds to turn on / off. Short press to adjust the G-spot vibration frequencies.



### VIBRATION BUTTON

Short press to adjust the clit vibration frequencies. Long press to turn off the clit vibration mode.



### FLAPPING / PATTING BUTTON

Short press to adjust the patting frequencies. Long press to turn off the patting mode.

### Important!

Please charge for 2 hours before use. When fully charged, the indicator light stops flashing.

You can not turn on the power during charging because of the battery protection.

It is recommended to use water-based lubricants.

### CLEANING

The product is waterproof and can be cleaned with warm water and soap. Then dry with a clean towel.



If the product does not work from the first use, please contact the seller. No warranty after incorrect use or accidental fall.



# DRIESA

## SENSATION

MANUAL • HANDLEIDING



# HANDLEIDING

Materialen: ABS + Siliconen

Werktijd: 1 uur

Laadtijd: 2 uur

Oplaad methode: Magnetisch

Standen: 7 G-spot vibraties  
7 Clitoris vibraties  
7 Flap standen

## INHOUD VERPAKKING

1 Driesa Sensation Vibrator

1 Oplaadkabel

1 Handleiding



### AAN/UIT KNOP

Houd 3 seconden lang ingedrukt om aan / uit te schakelen. Druk kort om de trillingsfrequenties van de G-spot aan te passen



### VIBRATIE KNOP

Lang indrukken om het clit vibratie aan / uit te schakelen. Druk kort om de trillingsfrequenties van de clit aan te passen.



### FLAPPING / PATTING KNOP

Lang indrukken om het flapping / patting aan / uit te schakelen. Druk kort om de flapping frequenties aan te passen.

### Belangrijk!

Gelieve voor gebruik 2 uur opladen. Wanneer het apparaat volledig is opgeladen, stopt het indicatielampje met knipperen. U kunt het apparaat tijdens het opladen niet inschakelen vanwege de batterijbescherming.

Het is aan te raden om glijmiddel op water basis te gebruiken indien wenselijk.

### REINIGEN

Het product is waterproof en kan schoon gemaakt worden met warm water en zeep. Vervolgens met een schone handdoek drogen.



Als het product vanaf het eerste gebruik niet werkt, neem contact met de verkoper. Geen garantie na onjuist gebruik of onbedoelde val.



**Techlik**  
Boshdijk 36e  
5612AM Eindhoven

CE RoHS