

# GEBRUIKSAANWIJZING CINETEX B.V.

BOBBI EDEN COLLECTION / IT COLLECTION / IVY / FETISH STORE

## HOE GAAT HET PRODUCT AAN?

Onze producten gaan aan door op de aanknop te drukken, beide knoppen ingedrukt te houden of de aanknop en + knop ingedrukt te houden.

## WELKE BATTERIJEN HEB IK NODIG?

Onze producten hebben knoopcel, AA of AAA batterijen nodig. Het kan ook zijn dat jouw speeltje USB oplaadbaar is, hier dien je zelf een stekker voor aan te schaffen.

## HOE MAAK IK HET PRODUCT SCHOON?

### Controleer of jouw product waterproof is

Ga als eerst na of jouw seksspeeltje wel of niet waterproof is. Indien dit het geval is kun jouw seksspeeltje schoonmaken onder de kraan. Mits deze is gemaakt van materialen zoals (hard) plastic, siliconen, elastomeer, metaal of glas.

Meestal zijn de oplaadbare vibrators waterbestendig ([m.u.v. luchtdruk toys!](#)) en mogen onder water en degene die op batterij werken absoluut niet. Ga dit altijd eerst even na voor dat je aan de slag gaat.

### Seksspeeltjes schoonmaken met een toycleaner

Het beste is om je speeltje schoon te maken met een toycleaner zoals [Lovegel Toycleaner](#).

Een toycleaner is een speciaal samengesteld schoonmaakmiddel voor seksspeeltjes. Het bevat een anti-bacteriële werking zonder dat deze agressieve chemicaliën bevat.

Toycleaners reinigen, verfrissen en verlengen de levensduur van je vibrator. De meeste hebben een sprayflacon voor een eenvoudige dosering en zijn alcohol -en parfumvrij. Je kunt met toycleaner ook prima een dildo, buttplug of cockring schoonmaken.

## VRAGEN?

Heb je een vraag over een product van Cinetex B.V. en je komt er niet uit? Stuur een e-mail naar [info@cinetex.nl](mailto:info@cinetex.nl).

# MANUAL CINETEX B.V.

BOBBI EDEN COLLECTION / IT COLLECTION / IVY / FETISH STORE

## HOW DOES THE PRODUCT TURN ON?

Our products turn on by pressing the power button, holding down both buttons or holding down the power button and + button.

## WHICH BATTERIES DO I NEED?

Our products require button cell, AA or AAA batteries. It is also possible that your toy USB is rechargeable, you have to purchase a plug for this yourself.

## HOW DO I CLEAN THE PRODUCT?

Check if your product is waterproof

First check whether or not your sex toy is waterproof. If this is the case, you can clean your sex toy under the tap. Provided it is made of materials such as (hard) plastic, silicone, elastomer, metal or glass.

Usually the rechargeable vibrators are water resistant (with the exception of air pressure toys!) and can be used under water and the ones that run on battery definitely don't. Always check this before you get started.

Cleaning sex toys with a toy cleaner

It is best to clean your toy with a toy cleaner such as Lovegel Toycleaner.

A toy cleaner is a specially formulated cleaning agent for sex toys. It contains an anti-bacterial effect without containing harsh chemicals.

Toy cleaners clean, refresh and extend the life of your vibrator. Most have a spray bottle for easy dosing and are alcohol and perfume free. You can also easily clean a dildo, butt plug or cock ring with toy cleaner.

## QUESTIONS?

Do you have a question about a Cinetex B.V. product? and you can't figure it out? Send an email to [info@cinetex.nl](mailto:info@cinetex.nl).