

MI-X420 Enigma Lite User Manual

Unboxing

- MI-X420 Enigma Lite Speaker
- Remote Control
- Microphone
- DC5V 1.6A Charger
- 3.5mm Audio Cable
- Apple Audio Cable
- Android Audio Cable
- User's Manual

Product Specifications

Model Number: MI-X420 Enigma Lite
 BT Version: V5.0
 RMS Output: 100W
 Frequency Response: 50-15kHz
 SN Ratio: >70dB
 Distortion: THD < 10%
 Sensitivity: 95dB ± 3dB
 Supports: TF Card, USB
 Supported Profiles: MP3, WAV, APE, FLAC, WMA
 Transmission Distance (Estimated): 10 Meters (No Obstacles)
 Battery Capacity: 18000mAh
 Playback Time: 3-8 Hours (Depends on Volume)
 Charging Time: 3-4 Hours

Product Overview

Product Overview

Product Overview

Product Overview

Product Usage Guide

Power ON/OFF:
Long press power button

MUSIC CONTROL:
Play/Pause: Click **▶** once (|)
Next Song: Click **▶▶** once (|)
Previous Song: Click **◀◀** once (|)

Assorted Functions:
Record: Insert Micro SD card/USB into the designated port. Please make sure microphone is connected. Short press the record button to start/stop recording. (Supports recording accompaniment soundtrack + Microphone input)
Play Recorded Tracks: Long press **▶**
Delete Recorded Files: Long press **⏏** during selected music playback (Deletes current music playback from recorded files)
Change Playback Mode: Short press power button to switch between BT/AUX/USB/Micro SD card playback
AUX Playback Mode: Insert AUX cable and connect it to audio source to start
Micro SD Card Playback Mode: Insert Micro SD card into Micro SD port.
USB: Insert USB into the USB port.
Sound Field switch: Click to cycle between Original-Professional-Popular-Echo sound field profile.
Microphone Delay: Works with all sound field modes except original mode.
Microphone Echo: Works with all sound field modes except original mode.

Connecting the Product

- Turn on Bluetooth (BT) on your mobile device.
- Turn on the speaker.
- Search and connect to "AIWA Enigma Lite" from your mobile device.

TWS Function

Power ON/OFF:

- Turn on both speakers. "LED Screen flashes on both units"
- Choose one of the units to function as the "Main unit"; long press "Play" button on this unit and it will enter TWS pairing mode. "LED Screen flashes"
- "Main unit" LED screen flashing slowly + "LED screen lights up without flashing" indicates successful pairing of both speakers.
- Turn on Bluetooth (BT) on your mobile device
- Search and connect to "AIWA Enigma Lite" from your mobile device
- Playback should now commence via both speaker units at the same time
- Long press "Play" button to disable TWS pairing. "LED Screen Flashes"

Battery & Charging

Charging the speaker:
Insert DC 5V adapter
*Red LED lights up
*Red LED light extinguishes upon full charge
Approximate charging time: 3-4 Hours

MI-X420 Enigma Lite

Unboxing

- MI-X420 Enigma Lite Speaker
- Remote Control
- Microphone
- DC5V 1.6A Charger
- 3.5mm Audio Cable
- Apple Audio Cable
- Android Audio Cable
- User's Manual

Product Specifications

Model Number: MI-X420 Enigma Lite
 BT Version: V5.0
 RMS Output: 100W
 Frequency Response: 50-15kHz
 SN Ratio: >70dB
 Distortion: THD < 10%
 Sensitivity: 95dB ± 3dB
 Supports: TF Card, USB
 Supported Profiles: MP3, WAV, APE, FLAC, WMA
 Transmission Distance (Estimated): 10 Meters (No Obstacles)
 Battery Capacity: 18000mAh
 Playback Time: 3-8 Hours (Depends on Volume)
 Charging Time: 3-4 Hours

Product Overview

Product Overview

Product Overview

Product Overview

Product Usage Guide

Power ON/OFF:
Long press power button

MUSIC CONTROL:
Play/Pause: Click **▶** once (|)
Next Song: Click **▶▶** once (|)
Previous Song: Click **◀◀** once (|)

Assorted Functions:
Record: Insert Micro SD card/USB into the designated port. Please make sure microphone is connected. Short press the record button to start/stop recording. (Supports recording accompaniment soundtrack + Microphone input)
Play Recorded Tracks: Long press **▶**
Delete Recorded Files: Long press **⏏** during selected music playback (Deletes current music playback from recorded files)
Change Playback Mode: Short press power button to switch between BT/AUX/USB/Micro SD card playback
AUX Playback Mode: Insert AUX cable and connect it to audio source to start
Micro SD Card Playback Mode: Insert Micro SD card into Micro SD port.
USB: Insert USB into the USB port.
Sound Field switch: Click to cycle between Original-Professional-Popular-Echo sound field profile.
Microphone Delay: Works with all sound field modes except original mode.
Microphone Echo: Works with all sound field modes except original mode.

Connecting the Product

- Turn on Bluetooth (BT) on your mobile device.
- Turn on the speaker.
- Search and connect to "AIWA Enigma Lite" from your mobile device.

TWS Function

Power ON/OFF:

- Turn on both speakers. "LED Screen flashes on both units"
- Choose one of the units to function as the "Main unit"; long press "Play" button on this unit and it will enter TWS pairing mode. "LED Screen flashes"
- "Main unit" LED screen flashing slowly + "LED screen lights up without flashing" indicates successful pairing of both speakers.
- Turn on Bluetooth (BT) on your mobile device
- Search and connect to "AIWA Enigma Lite" from your mobile device
- Playback should now commence via both speaker units at the same time
- Long press "Play" button to disable TWS pairing. "LED Screen Flashes"

Battery & Charging

Charging the speaker:
Insert DC 5V adapter
*Red LED lights up
*Red LED light extinguishes upon full charge
Approximate charging time: 3-4 Hours

MI-X420 Enigma Lite

Unboxing

- MI-X420 Enigma Lite Speaker
- Remote Control
- Microphone
- DC5V 1.6A Charger
- 3.5mm Audio Cable
- Apple Audio Cable
- Android Audio Cable
- User's Manual

Product Specifications

Model Number: MI-X420 Enigma Lite
 BT Version: V5.0
 RMS Output: 100W
 Frequency Response: 50-15 kHz
 SN Ratio: >70 dB
 Distortion: THD < 10%
 Sensitivity: 95dB ± 3dB
 Supports: Micro SD Karte, USB
 Unterstützte Profile: MP3, WAV, APE, FLAC, WMA
 Unterstützte Entfernungen (geschätzt): 10 Meter (keine Hindernisse)
 Batteriekapazität: 18000mAh
 Wiedergabezeit: 3-8 Stunden (abhängig von der Lautstärke)
 Ladezeit: 3-4 Stunden

Produktübersicht

Produkt Übersicht

Fernbedienung

Mikrofon

Gebrauchsanweisung

Power Ein/Aus:
Drücken Sie lange den Netzschalter

Musiksteuerung:
Wiedergabe / Pause: Einmal drücken (|)
Nächster Titel: Einmal drücken (|)
Vorheriger Titel: Einmal drücken (|)

Diverse Funktionen:
Aufnehmen: Stecken Sie die Micro-SD Karte/USB in den dafür vorgesehenen Anschluss. Bitte stellen Sie sicher, dass das Mikrofon angeschlossen ist. Drücken Sie kurz die Aufnahme-Taste, um die Aufnahme zu starten/stoppen. (Unterstützt die Aufnahme von Begleitstücken + Mikrofoneingang)

Aufgenommene Tracks abspielen: Langes Drücken von **▶**

EQ Drücken: Sie kurz die Modustaste am Lautsprecher/lang die Modustaste auf der Fernbedienung, um zwischen verschiedenen EQ-Modi zu wechseln.

Monitor-/Earphone-Funktion: Schließen Sie an Ihren Ohrhörer/Kopfhörer an den Monitoranschluss an. Drücken Sie kurz die Mikrofon-Anschlüsse an. Drücken Sie lange auf die Sound Field Taste, um die Stummfunktion des Lautsprechers aufzuheben. (Die Wiedergabe erfolgt sowohl über den Lautsprecher als auch über die Ohr-/Kopfhörer)

Wiedergabemodus wechseln: Drücken Sie kurz die Modustaste, um zwischen BT/AUX/USB/Micro-SD-Karten Wiedergabe zu wechseln

AUX-Wiedergabemodus: Stecken Sie das AUX-Kabel ein und verbinden Sie es mit der Audioquelle, um zu starten.

Micro-SD-Karten-Wiedergabemodus: Stecken Sie eine Micro-SD-Karte in den Micro-SD-Anschluss.

USB: Stecken Sie USB in den USB-Anschluss.

Klingelbildschirm: Klicken Sie hier, um zwischen dem Sound Field Original-Professional-Popular-Echo zu wechseln.

Mikrofonverzögerung: Funktioniert mit allen Sound Field Optionen außer dem Originalmodus.

Mikrofon-Echo: Funktionierte mit allen Sound Field außer dem Originalmodus.

Bluetooth Verbindung herstellen

- Schalten Sie Bluetooth (BT) auf Ihrem Mobilgerät ein.
- Schalten Sie den Lautsprecher ein.
- Suchen Sie von Ihrem Mobilgerät aus nach "AIWA Enigma Lite" und drücken Sie lange.
- Drücken Sie die Taste "Play" an diesem Gerät, um den TWS-Pairing-Modus zu gelangen. "LED Bildschirm blinkt"
- "LED Bildschirm des Hauptgeräts blinkt langsam + LED-Bildschirm leuchtet auf ohne Blinken zeigt an, dass beide Lautsprecher erfolgreich gekoppelt sind"
- Schalten Sie Bluetooth (BT) auf Ihrem Mobilgerät ein, suchen Sie von Ihrem Mobilgerät aus nach "Bildschirmblinkung" und stellen Sie eine Verbindung her
- Die Wiedergabe sollte jetzt über beide Lautsprecherbereichen am beginnenden gleichen Zeit.
- Drücken Sie lange die Wiedergabetaaste, um die TWS-Kopplung zu deaktivieren. "LED Bildschirm"

TWS Funktion

Einschalten/Ausschalten:

- Schalten Sie beide Lautsprecher ein. "LED-Bildschirm blinkt an beiden Geräten"
- Wählen Sie eine der Einheiten, um als "Haupteinheit" zu fungieren, und drücken Sie lange
- Drücken Sie die Taste "Play" an diesem Gerät, um in den TWS-Pairing-Modus zu gelangen. "LED Bildschirm blinkt"
- "LED-Bildschirm des Hauptgeräts blinkt langsam + LED-Bildschirm leuchtet auf ohne Blinken zeigt an, dass beide Lautsprecher erfolgreich gekoppelt sind"
- Schalten Sie Bluetooth (BT) auf Ihrem Mobilgerät ein, suchen Sie von Ihrem Mobilgerät aus nach "Bildschirmblinkung" und stellen Sie eine Verbindung her
- Die Wiedergabe sollte jetzt über beide Lautsprecherbereichen am beginnenden gleichen Zeit.
- Drücken Sie lange die Wiedergabetaaste, um die TWS-Kopplung zu deaktivieren. "LED Bildschirm"

Akku & Laden

Laden des Lautsprechers:
Stecken Sie den DC 5V-Adapter ein
* Rotes LED-Licht auf
* Rotes LED-Licht erlischt bei voller Ladung
Ungefähre Ladezeit: 4-5 Stunden