

Specifications/Specificaties



Belangrijk!

De Tekentablet wordt geleverd met een transparant overtrekvel. Gebruikt u de tablet voor de 3D Pen? Zorg dan dat het overtrekvel over het scherm ligt. U kunt niet direct op het scherm tekenen met de 3D Pen. De tablet zal dan kapot gaan!

Hoe te gebruiken?

1. Ontgrendel het scherm met de vergrendelknop. (Achterkant tablet)
2. Begin met tekenen met de bijgeleverde stylus.
3. (Deze stap overslaan als u geen 3D Pen gebruikt) Leg het overtrekvel over de tablet. Je kunt nu jouw tekening overtekenen met de 3D Pen.
4. Druk op de wisknop om de tekening te verwijderen wanneer je opnieuw wil beginnen.
5. Gebruik enkel de pen (stylus) die is meegeleverd.

Waarschuwing:

- Niet geschikt voor kinderen jonger dan 3 jaar.
- Uitsluitend gebruiken onder toezicht van een ouder.
- Niet te gebruiken in vochtige of stoffige ruimten. Laat de tablet niet in aanraking komen met water.
- Oefen geen extreme druk uit op het beeldscherm. De maximale druk van het beeldscherm is <math><300\text{gr}</math>.
- Verstikkingsgevaar: Het product bevat kleine onderdelen!
- Gebruik enkel een droge doek tijdens het reinigen.
- Gebruik enkel dezelfde batterij wanneer u deze wilt vervangen.

Bij vragen raden wij u aan om contact met onze klantenservice op te nemen.

Important!

The drawing tablet comes with a transparent overlay sheet. If you are using the tablet for the 3D pen, make sure that the overlay sheet is placed over the screen. You cannot directly draw on the screen with the 3D pen. Doing so will damage the tablet.

How to use?

1. Unlock the screen using the lock button. (Back of the tablet)
2. Start drawing with the included stylus.
3. (Skip this step if you are not using a 3D Pen) Place the overlay sheet over the tablet. You can now trace your drawing using the 3D Pen.
4. Press the eraser button to clear the drawing if you want to start again.
5. Only use the pen (stylus) provided.

Warning:

- Not suitable for children under 3 years old.
- Only use under the supervision of an adult.
- Do not use in damp or dusty areas. Do not place the tablet in direct sunlight. Do not let the tablet come into contact with water.
- Do not apply excessive pressure to the screen. The maximum pressure the screen can withstand is <math><300\text{gr}</math>.
- Choking hazard: Product contains small parts!
- Only use a dry cloth for cleaning.
- Use only the same type of battery when replacing the battery.

If you have any questions, we recommend that you contact our customer service.



MADE IN CHINA

