

## SPECIAL KEYS FUNCTIONS

# DAYTONA GAMING KEYBOARD PRO



## FUNCTION DESCRIPTION OF FN + COMBINATION KEYS

FN+F1	Computer	FN+F12	E-mail
FN+F2	Search	FN+ESC	Reset 3S
FN+F3	Calculator	FN+ Ins	RGB Light switching, including 3 lighting effects
FN+F4	Music	FN+ HM	RGB Light switching, including 3 lighting effects
FN+F5	Prev Track	FN+ PU	RGB Light switching, including 3 lighting effects
FN+F6	Next Track	FN+ Del	RGB Light switching, including 3 lighting effects
FN+F7	Play/Pause	FN+ End	RGB Light switching, including 3 lighting effects
FN+F8	Music Stop	FN+ PD	RGB Light switching, including 3 lighting effects
FN+F9	Mute	FN+ ←	light speed reduction
FN+F10	Volume-	FN+ →	light speed plus
FN+F11	Volume+		

MECHANICAL  
KEY SWITCHES

AZERTY

1.8M  
USB CABLE

RGB



## SPECIAL KEYS FUNCTIONS

### **MULTI FUNCTION BUTTON**

The default setting is normal mode: the scroll wheel indicator light is on. Scroll wheel is on, press briefly to switch to light mode, the brightness of the light can be dimmed by turning left and brightened by turning right (the indicator light will flash when the light is off and the light is brightest). Press and hold the button for 5 seconds to enter the multimedia mode: the indicator light of the scroll wheel is off, press briefly to mute, turning the button counterclockwise reduces the volume, and turning the button clockwise increases the volume.

### **M1**

The default is the normal mode: the indicator light is on, press briefly in the standard game light mode, press and hold the button, the indicator light will flash. When the light recording is completed, press the button again to end the recording. Press and hold the button for 5 seconds for multimedia mode: the indicator light is off, use the key function to go to previous tracks.

### **M2**

The default is the normal mode: the indicator light is on, briefly press the default game light mode 2, long press the button to light, the indicator light will flash. When the light recording is complete, press the button to end the recording. Press and hold the button for 5 seconds for multimedia mode: the indicator light is off, use the key function to play/pause tracks.

### **M3**

The default setting is the normal mode: the indicator light is on, press briefly on the standard game light mode 3, press the button long to light, the indicator light blinks. When the light recording is completed, press the button to end the recording. Press and hold the button for 5 seconds for multimedia mode: the indicator light is off, use the key to skip tracks.



## FEATURES

### 1. BLUE SWITCH MECHANICAL

Provides the highest tactical feedback and the clearer “Click” sound than normal keys.

### 2. MAGNETIC DETACHABLE UPPER CASE

The upper covers can be changed according to personal preferences.

### 3. ALL KEYS ANTI-GHOSTING

N-Key rollover means any number of buttons can be pressed at once without missing keystrokes or input.

### 4. 18 MODES LIGHT EFFECTS WITH CUSTOMIZED FUNCTIONS

18 modes light effects provide a pleasant feel and provide bright, crystal clear back lighting.

### 5. MULTI FUNCTION KNOB

The multi function knob adjusts the light modes and volume.

## SPECIFICATION

Switch type:	Mechanical
Key type:	Mechanical Blue Switch
Key number:	108 keys (QWERTY 107 keys)
Backlight effects:	18 modes RGB light effects
Interface:	USB 2.0
Rating voltage/current:	5V/300mA max
Cable length:	Detachable Type-C cable 1.8M
Dimension:	436x128x34mm

## SYSTEM REQUIREMENT

Windows 10/8/7/Vista/XP, Mac OS



FUNCTIES SPECIALE TOETSEN

# DAYTONA GAMING KEYBOARD PRO



UITLEG TOETSCOMBINATIES FN + COMBINATIETOETS

FN+F1	Computer	FN+F12	E-mail
FN+F2	Zoeken	FN+ESC	Reset 3S
FN+F3	Rekenmachine	FN+ Ins	RGB Licht schakelen, inclusief 3 lichteffecten
FN+F4	Muziek	FN+ HM	RGB Licht schakelen, inclusief 3 lichteffecten
FN+F5	Vorig nummer	FN+ PU	RGB Licht schakelen, inclusief 3 lichteffecten
FN+F6	Volgend nummer	FN+ Del	RGB Licht schakelen, inclusief 3 lichteffecten
FN+F7	Afspelen/Pauze	FN+ End	RGB Licht schakelen, inclusief 3 lichteffecten
FN+F8	Muziek stoppen	FN+ PD	RGB Licht schakelen, inclusief 3 lichteffecten
FN+F9	Dempen	FN+ ←	Lichtsnelheid verlagen
FN+F10	Volume-	FN+ →	Lichtsnelheid verhogen
FN+F11	Volume+		



MECHANISCHE  
TOETSEN



AZERTY



1.8M  
USB CABEL



RGB



## FUNCTIES SPECIALE TOETSEN

### **MULTIFUNCTIONELE KNOP**

De standaardinstelling is de normale modus: het controlelampje van het scrollwiel is aan, kort indrukken om de lichtmodus om te schakelen. Dim de helderheid van het licht door linksom te draaien en draai rechtsom om weer lichter te stellen (het indicatorlampje knippert wanneer het licht uit is/het licht het helderst is). Houd de knop 5 seconden ingedrukt om de multimedia modus in te schakelen: het indicatielampje is uit, kort indrukken om te dempen. Draai de knop linksom om het volume te verlagen, draai rechtsom om het volume te verhogen.

#### **M1**

De standaardinstelling is de normale modus: het controlelampje is aan, druk kort op de standaard *game light* modus, houd ingedrukt om licht op te nemen, het lampje knippert. Druk nogmaals op de knop om de lichtopname te beëindigen. Houd de knop 5 seconden ingedrukt om de multimedia modus in te schakelen: het lampje is uit, met deze toets kunt u naar het vorige nummer.

#### **M2**

De standaardinstelling is de normale modus: het controlelampje is aan, druk kort op de standaard *game light mode 2*, houd ingedrukt om licht op te nemen, het lampje knippert. Druk op de knop om de opname weer te beëindigen. Houd de knop 5 seconden ingedrukt om de multimedia modus in te schakelen: het indicatielampje is uit, met deze toets kunt u nu afspelen/pauzeren.

#### **M3**

De standaardinstelling is de normale modus: het indicatielampje is aan, druk kort op de standaard *game light mode 3*, houd ingedrukt om licht op te nemen, het lampje knippert. Druk op de knop om de opname te beëindigen. Houd gedurende 5 seconden de knop ingedrukt om de multimedia modus in te schakelen: het indicatielampje is uit, met deze toets kunt u nu naar het volgende nummer.



## KENMERKEN

### 1. BLAUWE MECHANISCHE SWITCH

Biedt de hoogst accurate feedback en een duidelijker "klik"-geluid dan normale toetsen.

### 2. MAGNETISCH AFNEEMBAAR FRAME

Het magnetische frame kan naar eigen voorkeur worden bevestigd of worden afgelaten.

### 3. ANTI-GHOSTING-TOETSENBORDFUNCTIE

*N-Key rollover* betekent dat een willekeurig aantal toetsen tegelijk kan worden ingedrukt zonder toetsaanlagen of invoer te missen.

### 4. 18 MODI LICHEFFECTEN MET AANGEPASTE FUNCTIES

18 modi lichteffecten zorgen voor een aangenaam gevoel en bieden kristalheldere achtergrondverlichting.

### 5. MULTIFUNCTIONELE KNOP

Met deze knop verstel je het licht en het volume.

## SPECIFICATIE

Type schakelaar:	Mechanisch
Type toets:	Blauwe Mechanise Switch
Toetsaantal:	108 toetsen (QWERTY 107 toetsen)
Achtergrond- verlichting effecten:	18 modi RGB lichteffecten
Interface:	USB 2.0
Schattingsvoltage- /stroom:	5V/300mA maximum
Kabellengte:	Afneembare Type-C kabel 1.8M
Afmeting:	436x128x34mm

## SYSTEEMVEREISTE

Windows 10/8/7/Vista/XP, Mac OS

