

Descriptions and Instructions for CHT BT Pro Controller

Button Descriptions:

1. Direction Pad (D-pad)
2. Action Buttons
3. Left Analog Stick (L2)
4. Right Analog Stick (R2)
5. HOME Button(Power on/off)
6. LED Indicator 1,2,3,4,
7. Turbo Button
8. Capture
9. Menu selection -
10. Menu selection +
11. Left triggers
12. Right triggers
13. Reset(Power off)



Main Features:

1. Use with Nintendo Switch console
2. Dual Shock
3. With turbo function, Capture function, Home function.
4. With 0.7m charging cable
5. Two high quality analogue sticks come without any dead zone
6. Bluetooth version: 2.1+EDR
7. Built-in 5V/500mAh Li-ion battery, support 6 hours working time.
8. With sensor, no NFC, no awake-up function

Turbo Feature:

- 1). Press and hold one action button, then press the Turbo button, Turbo feature will be valid. For an example, Press and hold A, then press T, action order of A will keep going.
- 2). Based on above 1) state, press T to stop Turbo function.

Pairing Methods:

1. 1st time to connect: Press and hold the HOME button 5 seconds on "Change Grip/Order" page, and 4 indicators blinks fast.
2. 2nd time to connect: Press the HOME button on any page, and 4 indicators blinks slowly.



Functions of LED indicators:

1. Corresponding Indication for the connected controller :

- 1). The 1st LED indicator is on as soon as the 1st controller is connected.
- 2). The 2nd LED indicator is on as soon as the 2nd controller is connected.
- 3). The 3rd LED indicator is on as soon as the 3rd controller is connected.
- 4). The 4th LED indicator is on as soon as the 4th controller is connected.

2. Charging Indication:

- 1). 4 LED indicators blink slowly during charging under unconnected state with console.
- 2). Matched LED indicator blinks slowly during charging under connected state with console.

3. Low voltage indication:

- 1). Matched LED indicator blinks slowly at low voltage under connected state with console.

4. Pairing indication:

- 1). Press and hold HOME button 5 seconds, 4 LED indicators blink fast during pairing. Matched LED indicator keeps ON after successful pairing.
- 2). Press and hold HOME button 5 seconds, 4 LED indicators blink slowly if unsuccessful pairing.

- 1) 1台目のコントローラが接続されると1番目のLEDインジケータが点灯します。
- 2) 2台目のコントローラが接続されると2番目のLEDインジケータが点灯します。

LEDインジケータの機能:



1. 1回目の接続: 「クランプ/順序の変更」ページでHOMEボタンを5秒間押し続けます。
2. 2回目の接続: 任意のページでHOMEボタンを押すと、4つのインジケータが速く点滅します。
- 4つのインジケータがゆっくり点滅します。

ペアリング方法:

1. Aボタンを長押ししてからTurboボタンを押すと、Turbo機能が有効になります。たとえば、Aを長押ししてからTを押すと、Aの行動命令は進み続けます。
2. 上記1)の状態ではTを押すとTurbo機能が停止します。

Turbo機能:

1. ニンテンドースイッチコントローラで使用します
2. フェアルシヨック
3. 機能付き、キャプチャー機能付き、ホーム機能付き
4. 0.7m充電ケーブル付き
5. フラッシュメモリー2本付き
6. Bluetoothバージョン: 2.1 + EDR
7. 5V / 500mAh リチウムイオン電池を内蔵して、6時間連続使用できます
8. センサー付き、NFCなし、ワイヤレス機能なし

特徴:



1. 方向ボタン(D-パッド)
2. Aボタン
3. 左スティック (L2)
4. 右スティック (R2)
5. ホームボタン(オン/オフ)
6. LEDインジケータ1、2、3、4、
7. Turboボタン
8. キャプチャー
9. メニュー選択+
10. メニュー選択-
11. 左トリガー
12. 右トリガー
13. リセット (電源を切る)

ボタンの説明:

本商品は1年の保証期間付きですので、商品に何かございましたら、お気軽に zenglixian0129@outlook.com にお問合わせてください。

保証期間:

・ワイヤレス機能なし

- ・NFC機能なし
- 6. 以下の機能を搭載しておりません:
 5. 長時間遊ばないで、目を保護するように注意してください。
 4. 長期間使用しなかった場合、または他の操作による異常があった場合、正常なスイッチ操作はできません。製品はリセットでき、リセットボタンは製品の背面にある小さい穴に配置されています。鋭利なもので操作できます。
- 3. スムーズなBluetooth接続を確保するために、製品を接続する前にBluetoothデバイスに表示されている他のデバイスを取り外してください。
- 4. 長期間使用しなかった場合、または他の操作による異常があった場合、正常なスイッチ操作はできません。製品はリセットでき、リセットボタンは製品の背面にある小さい穴に配置されています。鋭利なもので操作できます。
- 5. 長時間遊ばないで、目を保護するように注意してください。
- 6. 以下の機能を搭載しておりません:
 - ・NFC機能なし

注意:

1. 本製品を正しく使用するために、使用する前に製品を充電してください。
2. この製品を個人的に分解しないでください。
3. スムーズなBluetooth接続を確保するために、製品を接続する前にBluetoothデバイスに表示されている他のデバイスを取り外してください。
4. 長期間使用しなかった場合、または他の操作による異常があった場合、正常なスイッチ操作はできません。製品はリセットでき、リセットボタンは製品の背面にある小さい穴に配置されています。鋭利なもので操作できます。
5. 長時間遊ばないで、目を保護するように注意してください。
6. 以下の機能を搭載しておりません:
 - ・NFC機能なし

ご接続の注意事項:

1. HOMEボタンを5秒間押し続け、ペアリング中は4つのLEDインジケータが速く点滅します。
2. ボタンを5秒間押し続け、ペアリングに失敗した場合は、4つのLEDインジケータがゆっくり点滅します。

4.ペアリング表示:

- 1). HOMEボタンを5秒間押し続け、ペアリング中は4つのLEDインジケータが速く点滅します。
- 2). ペアリングが成功すると、対応するLEDインジケータが点灯します。

3.低電圧表示:

- 1). 接続されている状態では、対応するLED表示灯は低電圧の場合でゆっくり点滅します。
- 2) コントロールとの接続状態で充電中、一致したLEDインジケータがゆっくり点滅します。
- 1) 充電中コントロールとの未接続状態では、4つのLEDインジケータがゆっくり点滅します。

2.充電方法:

- 3) 3台目のコントローラが接続されると3番目のLEDインジケータが点灯します。
- 4) 4台目のコントローラが接続されると4番目のLEDインジケータが点灯します。