

...verwijzen de gebruiker verzinkt. Dit licht
... "TIMER" voor automatisch 6 uur aan en 18 uur uit. 3. "OFF" voor
... "ON" voor continu aan.

remplacement de la pile ne peut être remplacé, si le cordon est endommagé,
pas être remplacés. Cette guirlande n'est pas un jouet - s'il est
de portée des enfants. Cet ensemble d'éclairage a 3 fonctions: 1.

"TIMER" pour allumé pendant 6 heures et éteint pendant 18 heures,
2. "ON" pour allumé en continu, 3. "OFF" pour éteint en continu.



DE - Nur für den Einsatz im Innenbereich. Das flexible Kabel dieses
Beleuchtungssets kann nicht ausgetauscht werden; wenn das
Kabel beschädigt ist, ist das Beleuchtungsset zu beseitigen. Die
Lampen können nicht ausgetauscht werden. Diese Lichtkette ist kein
Kinderspielzeug - Bitte für Kinder unzugänglich anbringen. Dieses
Beleuchtungsset hat 3 Einstellungen: 1. „ON“ = Dauerbetrieb,
2. „TIMER“ = automatisch 6 St. an und 18 St. aus, 3. „OFF“ =
dauerhaft aus.



EN - For indoor use only. The external flexible cable or cord of this
luminaire cannot be replaced; if the cord is damaged, the luminaire
shall be destroyed. The lamps are not replaceable. This lighting
chain is no toy - please keep it inaccessible for children. This light set
has 3 functions: 1. "ON" for continuously switched on; 2. "TIMER" for
switching the light on/off automatically (6 hours on and 18 hours
off); 3. "OFF" for continuously switched off.

10cm



Itemnr.: 231319

2 x AA (Not included)



8 713619 366802
1230 ZG WAARLAND (NL) 21