

Handleiding voor SMARTIFY Nintendo Switch controller

1. Direction Pad (D-pad)
2. Action Buttons
3. Left Analog Stick (L2)
4. Right Analog Stick (R2)
5. HOME Button(Power on/off)
6. LED Indicator 1,2,3,4,
7. Turbo Button
8. Capture
9. Menu selection -
10. Menu selection +
11. Left triggers
12. Right triggers



Verschillende functies van de controller:

1. Compatibel met Nintendo Switch, PC, Android en Nintendo Switch Lite
2. Twee elektro motoren voor optimale trilfunctie
3. Turbo functie, schermopname functie en Home functie
4. Met 0.7m USB oplaadkabel
5. Twee hoge kwaliteit analoge sticks zonder deadzone
6. Draadloze besturing met versie 2.1+ EDR
7. Oplaadbare accu van 550 mAh Li-ion batterij voor 10 uur lang speeltijd
8. Met sensor, zonder NFC en zonder Wake up functie



Turbo functie & Verbinden

Turbo Functie

- 1). Houdt een knop naar keuze ingedrukt en druk op de Turbo knop.
- 2). Bijvoorbeeld: houd knop A ingedrukt en druk de Turbo knop in. Nu wordt knop A constant ingedrukt door de Turbo functie.

Hoe verbind je de controller?

1. Zet de Switch in het Switch station. Verbind vervolgens de Smartify controller via USB met het Switch Station.
2. Druk op de H toets op de Smartify controller.
3. Ga naar systeem instellingen en ga naar controllers en sensoren. Verbreek verbinding met alle controllers.
4. Wacht totdat de controller gepaired is.
5. Verwijder de USB uit de Smartify controller.
6. De controller hoort nu verbonden te zijn.

Let op: op de achterkant van de controller zit een reset knop. Gebruik een naald om deze in te drukken. Gebruik deze indien de controller niet meer kan verbinden.

LED functie indicatoren

1. De LED indicatie is als volgt:

- 1). Het 1ste led lampje indiceert dat hij of zij speler 1 is.
- 2). Het 2de led lampje indiceert dat hij of zij speler 2 is.
- 3). Het 3de led lampje indiceert dat hij of zij speler 3 is.
- 4). Het 4de led lampje indiceert dat hij of zij speler 4 is.

2. Oplaad indicatie

- 1). 4 LED lampjes die langzaam knipperen indiceert dat de controller bijna leeg is.
- 2). Als je de controller oplaad via USB zal hij ook langzaam knipperen. Dit betekend dat de controller correct geladen wordt.

User manual for SMARTIFY Nintendo Switch controller

1. Direction Pad (D-pad)
2. Action Buttons
3. Left Analog Stick (L2)
4. Right Analog Stick (R2)
5. HOME Button(Power on/off)
6. LED Indicator 1,2,3,4,
7. Turbo Button
8. Capture
9. Menu selection -
10. Menu selection +
11. Left triggers
12. Right triggers



Functions of the controller

1. Compatible with Nintendo Switch, Windows, Android and Nintendo Switch Lite
2. Two double shock motors for optimal vibration function
3. Turbo function, screen capture function and home function
4. Comes with 0.7m USB charging cable
5. Two high quality analogue sticks, without deadzone
6. Wireless controller firmware 2.1 EDR
7. Built-in 550 mAh Li-ion battery, supports up to 10 hours of play time.
8. With Sensor, no NFC and no wake-up function



Turbo function and connecting

Turbo function

- 1). Press a button of choice and press the Turbo button respectively.
- 2). For example: hold button A pressed and press the Turbo button. Button A will keep going as if it is continuously pressed. Button A is now being spammed without the user actually pressing it.

How do I connect the controller?

1. Place the Switch in the Switch station. Connect the Smartify controller using the USB cable to the Switch Station.
2. Press the H button on the Smartify controller.
3. Go to system settings and go to controllers and sensors. Next press disconnect all controllers.
4. Wait until the controller is paired.
5. Disconnect USB from Smartify controller.
6. The controller is now connected.

Attention: a reset button is located on the bottom of the controller. Use a needle to press the button. Use this button when the controller is unable to connect.

LED function indicators

1. The LED light indicates the following meaning:

- 1). The first led light indicates that he or she is player 1.
- 2). The second led light indicates that he or she is player 2.
- 3). The third led light indicates that he or she is player 3.
- 4). The fourth led light indicates that he or she is player 4.

2. Charging led indicator:

- 1). 4 LED light that blink slowly indicate that the controller is empty, and needs to be charged.
- 2). 4 LED lights that blink slowly indicate the controller is charging correctly.