尺寸：90x125mm　材质：超感米100g　折页方式：骑马钉

英语

ProtoArc EN

XK01
Foldable Full-Size
Wireless Keyboard

User Manual

www.protoarc.com

US
support@protoarc.com
(+1) 866-287-6168
Monday-Friday, 10am-6pm, 2pm-7pm (Eastern Time)
*Closed during Holidays

UK
support-uk@protoarc.com

Contents

English 01-12

Deutsch 13-25

Packing List

Product Features

Bluetooth Connection

Single press (1) / (2) / (3) channel button, and the indicator light flashes once to enter the Bluetooth channel.

Long press this Bluetooth channel button for 3~5 seconds again, the indicator light flashes quickly, then the keyboard enters into the Bluetooth pairing mode.

Turn on the Bluetooth settings on your device, search or select "ProtoArc XK01" and start Bluetooth pairing until the connection is completed.

Note for UK Users

For Samsung tablet or mobile phone, please set the keyboard language to English (UK) on your device first before using the keyboard for the first time.

Samsung tablet setup steps as follows: Settings > General management > Samsung Keyboard settings > Languages and types > Manage input languages > Choose English (UK)

OPPO mobile phones setup steps as follows: Setting > More setting > Language & input > Physical Keyboard > ProtoArc XK01 keyboard > Set keyboard layouts > Choose English (UK)

Mode Switch Method

(1) / (2) / (3) After are connected, short press the channel key on the keyboard easily switch between multiple devices.

Charging Guide

1. When the battery is low, the low battery indicator light on the keyboard will rapidly flash to indicate low power.

2. Insert the Type-C port into the keyboard and the USB-A port into the computer to charge, the red light stays on while charging.

3. The indicator light turns in green when fully charged.

Notice:
If the keyboard is low battery, there will be delays, freezes and other problems. Please connect to the power supply for charging in a timely manner to ensure that the keyboard has sufficient battery power to get normal performance.

Multimedia Function Keys

Keys	Windows OS	Android OS	IOS	Mac OS
☀	Light +	Light +	Light +	Light +
☀	Light -	Light -	Light -	Light -
⧉	Window Switch	Window Switch	/	Window Switch
⊞	Application Switch	Application Switch	Open Siderl Switch	Open Siderl Switch
⊟	Display Desktop	Go Home	Go Home	Go Home
🔍	Search	Search	Search	/
⏮	Previous Track	Previous Track	Previous Track	Previous Track
⏯	Play & Pause	Play & Pause	Play & Pause	Play & Pause
⏭	Next Track	Next Track	Next Track	Next Track
🔇	Mute	Mute	Mute	Mute
🔉	Volume -	Volume -	Volume -	Volume -
🔊	Volume +	Volume +	Volume +	Volume +
⚙	Setup	/	/	/
🔒	Lock Screen	Lock Screen	Lock Screen	/
📷	Screenshot	Screenshot	Screenshot	Screenshot
Fn	Fn+ESC (Fn lock) button to turn on or turn off the Fn function			

Note: The Fn function is a cyclic mode (F1-F12 and multimedia functions are cyclically used).

How to Use Special Characters in British English

On MacOS/iPadOS/IOS system:

Press the key and you can type the symbol shown in the right square frame.

Press and hold the key [Option], then press the corresponding key, you can type the symbol shown in the right square frame.



Press and hold the key [Shift], then press the corresponding key, you can type the symbol shown in the right square frame.

On Android/Windows:

Press the key and you can type the symbol shown in the right square frame.

Press and hold the key [Shift], then press the corresponding key, you can type the symbol shown in the right square frame.

Press and hold the key [Alt] the key on the right side of the keyboard), then press the corresponding key, you can type the symbol shown in the right square frame.

Product Parameters

Battery Capacity	210 mAh
Working Current	< 3.5 mA
Sleep Current	31 uA
Charging Current	150 mA (+20mA)
Standby Current	< 0.3 mA
Input	5V⎓250mA
Standby Time	≥ 150 Days
Charging Time	≈ 2 Hours
Wake Up Way	Press any key
Weight	297 g
Keyboard Dimension	386.4x116.7x14.4mm(Unfolded) 215.5x116.7x20.8mm(Folded)

Sleep Mode

1. When the keyboard is not used for more than 30 minutes, it will automatically enter the sleep mode and the indicator light will be off.

2. When you use the keyboard again, you only need to press any key, and the keyboard will wake up within 3 seconds. The indicator will light up again and starts to work.

Tips

1. If Bluetooth connection is not working properly, fold the keyboard to turn off, then unfold the keyboard to turn on and re-connect to the device's Bluetooth and attempt to reconnect. Or delete the same Bluetooth option name in the Bluetooth connection list of the device and reconnect.

2. To switch to a successfully connected channel, press the channel button and wait for 3 seconds before continuing to use.

3. The keyboard have a memory function. When the are connected on specific channel, turn off the keyboard and turn on again, the will automatically connect to the default channel and this channel indicator is on.

4. For UK users, Why is the keyboard English US (QWERTY) layout when first use?

Before using the keyboard, please set the keyboard language to English (UK) first.

Samsung tablet for example/ Settings > General management > Samsung Keyboard settings > Languages and types > Manage input languages > Choose English (UK)

OPPO mobile phones for example/ Setting > More setting > Language & input > Physical Keyboard > ProtoArc XK01 keyboard > Set keyboard layouts > Choose English (UK)

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

⚠ Charging Safety: Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.

⚠ Battery Handling: Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.

⚠ Avoid Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.

⚠ Liquid Exposure: Keep the item away from water and liquids. Do not use it wet until thoroughly dried.

⚠ Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.

⚠ Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.

⚠ Radio-frequency interference: This device may cause interference with other electronics. Keep a safe distance from sensitive devices.

⚠ Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.

For further assistance or information, please contact our customer service.
Emergency Contact: +1 866-287-6168 (United States)

EU Declaration of Conformity

Declared Object	Foldable Full-Size Wireless Keyboard
Model	XK01
Rating	3.7V⎓150mA
Frequency	2402-2480MHz
Place of Production	Made in China
Manufacturer	Shenzhen Hongjin Electronic Technology Co., LTD
Email	cheri.zhu@protoarc.cn
Address	Floor 2, Building 24, Area 3, Gaoxinqi(Ai West Industrial Zone, Dalang Street, Longhua District, Shenzhen City, Guangdong Province, China, 518109
European representative	UK CH Shenzhen Hongjin Electronic Technology Co., LTD Floor 2, Building 24, Area 3, Gaoxinqi(Ai West Industrial Zone, Dalang Street, Longhua District, Shenzhen City, Guangdong Province, China, 518109 Email: cheri.zhu@protoarc.cn EC REP Shenzhen Hongjin Electronic Technology Co., LTD Floor 2, Building 24, Area 3, Gaoxinqi(Ai West Industrial Zone, Dalang Street, Longhua District, Shenzhen City, Guangdong Province, China, 518109 Email: cheri.zhu@protoarc.cn

It is our sole responsibility to declare that the above products are in full compliance with Directive 2014/53/EU, 2011/65/EU (as amended)

Position: Managing Director
Signature:
Date of Sign: 2022.11
Declaration Date: 2022.11

德语

ProtoArc DE

XK01
Faltbare Kabellose
Tastatur Full-Size

Benutzerhandbuch

www.protoarc.com
support-u@protoarc.com

Im Lieferumfang

Produktfunktionen

Bluetooth Verbindung

Klappen der Tastatur schaltet sich automatisch ein.

Drücken Sie einmal die Kombitaste (1) / (2) / (3) und die Kombibeschte blinkt einmal, um den Bluetooth-Kanal auszuwählen. Warten Sie dann 3 Sekunden, bevor Sie mit der Arbeit weiter. Wenn die ausgewählte Taste schnell und die Tastatur wechselt dann in den Bluetooth-Kopplung-Modus.

Schalten Sie die Bluetooth-Einstellungen auf Ihrem Gerät ein, suchen oder wählen Sie „ProtoArc XK01" und starten Sie die Bluetooth-Kopplung, bis die Verbindung hergestellt ist.

Anmerkung

Für Samsung Tablet oder Handy stellen Sie die Tastatursprache auf Ihrem Gerät auf Englisch (UK) ein bevor Sie die Tastatur verwenden.

(Samsung-Tablet zum Beispiel) Einstellungen > Allgemeine Verwaltung > Samsung-Tastatur Einstellungen > Sprachen und Typen > Eingabesprachen verwalten > Deutsch auswählen

(OPPO-Handys zum Beispiel) Einstellungen > Weitere Einstellungen > Sprache und Eingabemethoden > Physikalische Tastatur > ProtoArc XK01 > Tastaturlayout einstellen > Deutsch auswählen (QWERTZ)

Methode zum Umschalten des modus

Nachdem die Verbindung (1) / (2) / (3) hergestellt wurden, drücken Sie kurz die Kanaltaste auf der Tastatur, um problemlos zwischen mehreren Geräten zu wechseln.

Ladeanzeitung

1. Wenn der Akku leer ist, blinkt die Anzeige für niedrigen Batteriestand auf der Tastatur schnell, um einen niedrigen Stromverbrauch anzuzeigen.

2. Stecken Sie zum Laden den Typ-C-Anschluss in die Tastatur und den USB-A-Anschluss in den Computer. Das rote Licht bleibt während des Ladevorgangs an.

3. Die Kontrollleuchte leuchtet grün, wenn der Akku vollständig aufgeladen ist.

Hinweis:
Wenn die Batterie der Tastatur schwach ist, kann es zu Verzögerungen, Einfrieren und anderen Problemen kommen. Achte zeitlichen Sie zum Aufladen rechtzeitig die Stromversorgung an, um sicherzustellen, dass die Tastatur über ausreichend Akkuleistung verfügt, um eine normale Leistung zu erzielen.

Multimedia-Funktionstaste

Tasten	Windows OS	Android OS	IOS	Mac OS
☀	Helligkeit +	Helligkeit +	Helligkeit +	Helligkeit +
☀	Helligkeit +	Helligkeit +	Helligkeit +	Helligkeit +
⧉	Fensteraufschaltung	Fensteraufschaltung	/	Fensteraufschaltung
⊞	Anwendungsauswahl	Anwendungsauswahl	Letztes Fenster öffnen	Letztes Fenster öffnen
⊟	Desktop anzeigen	Home	Home	Home
🔍	Suchen	Suchen	Suchen	/
⏮	Rückwärts	Rückwärts	Rückwärts	Rückwärts
⏯	Play/Pause	Play/Pause	Play/Pause	Play/Pause
⏭	Vorwärts	Vorwärts	Vorwärts	Vorwärts
🔇	Stumm	Stumm	Stumm	Stumm
🔉	Leiser	Leiser	Leiser	Leiser
🔊	Lauter	Lauter	Lauter	Lauter
⚙	Einstellen	/	/	/
🔒	Sperren	Sperren	Sperren	/
📷	Screenshot	Screenshot	Screenshot	Screenshot
Fn	Taste Fn+ESC (Fn-Sperre) zum Ein- oder Ausschalten der Fn-Funktion			

Hinweis: Die Fn-Funktion ist ein zyklischer Modus (F1-F12 und Multimedia-Funktionen werden zyklisch verwendet).

Anweisung der Sonderzeichen

Anweisung der Sonderzeichen unter MacOS/iPadOS/iOS:

Drücken Sie [Option] und die entsprechende Taste zusammen, ergeben sich die Sonderzeichen.

Anweisung der Sonderzeichen unter Android/Windows:

Drücken Sie [Alt] die Taste auf der rechten Seite der Tastatur) und die entsprechende Taste zusammen, ergeben sich die Sonderzeichen.

Sprachauswahl in drei Systemen:

IOS/Mac: Strg + Leertaste
Windows: Alt + Umschalttaste
Android: Umschalttaste + Leertaste

Hinweis: Bevor Sie die Sprache wechseln, müssen Sie die entsprechende Sprachtastatur heruntergeladen (wenn Ihr Gerät bereits eine entsprechende Sprachtastatur hat, ignorieren Sie sie)

Produktspezifikation

Batteriekapazität	210 mAh
Arbeitsstrom	≤3.5 mA
Ruhestrom	31 uA
Ladestrom	150 mA (+20mA)
Standby-Strom	≤0.3 mA
Eingang	5V⎓250mA
Standby-Zeit	>150 Tage
Aufladezeit	≈ 2 Stunden
Aufwachen	Drücken einer beliebigen Taste
Gewicht	297 g
Tastaturabmessungen	386.4 x 116.7 x 12.4 mm (aufgeklappt) 215.5 x 116.7 x 20.8 mm (gefaltet)

Schlafmodus

1. Wenn die Tastatur länger als 30 Minuten nicht verwendet wird, wechselt sie automatisch in den Schlafmodus und die Kontrollleuchte erlischt.

2. Wenn Sie die Tastatur wieder verwenden, müssen Sie nur eine beliebige Taste drücken, und die Tastatur wird innerhalb von 3 Sekunden aktiviert. Die Anzeige leuchtet wieder auf und beginnt zu arbeiten.

Tipps

1. Wenn die Bluetooth-Verbindung nicht ordnungsgemäß funktioniert, klappen Sie die Tastatur zusammen, um sie auszuschalten. Klappen Sie die Tastatur dann wieder auf, um die Bluetooth-Verbindung des Geräts neu zu starten, und versuchen Sie, die Verbindung wiederherzustellen. Oder löschen Sie den zusätzlichen Bluetooth-Optionsnamen in der Bluetooth-Verbindungsliste des Geräts und stellen Sie die Verbindung erneut her.

2. Um zu einem erfolgreich verbundenen Kanal zu wechseln, drücken Sie die Kanaltaste und warten Sie 3 Sekunden, bevor Sie die Verwendung fortsetzen.

3. Die Tastatur verfügen über eine Speicherfunktion. Wenn sie mit bestimmten Kanälen verbunden sind, schalten Sie die Tastatur aus und wieder ein. Sie verbinden sich automatisch mit dem Standardkanal und diese Kanalanzeige leuchtet.

4. Warum ist das Layout US (QWERTZ) der Tastatur beim Typen? Bevor Sie die Tastatur zum ersten Mal verwenden, stellen Sie die Tastatursprache auf Deutsch auf Ihrem Gerät ein.

(Samsung-Tablet zum Beispiel)Einstellungen > Allgemeine Verwaltung > Samsung-Tastatur Einstellungen > Sprachen und Typen > Eingabesprachen verwalten > Deutsch auswählen

(OPPO-Handys zum Beispiel) Einstellungen > Weitere Einstellungen > Sprache und Eingabemethoden > Physikalische Tastatur > ProtoArc XK01 > Tastaturlayout einstellen > Deutsch auswählen (QWERTZ)

Sicherheitswarnung

WICHTIG: Um das Risiko von Feuer, elektrischem Schlag oder Verletzungen zu verringern, befolgen Sie diese Sicherheitsanweisungen.

⚠ Sicheres Laden: Verwenden Sie ausschließlich das mitgelieferte Kabel. Laden Sie das Gerät in einem gut belüfteten, trockenen Bereich fern von brennbaren Materialien auf.

⚠ Akku-Handhabung: Versuchen Sie nicht, den Lithium-Akku des Geräts zu ersetzen. Der Akku sollte von qualifiziertem Personal durchgeführt werden, um Gefahren zu vermeiden.

⚠ Vermeidung: Vermeiden Sie es, das Gerät in umgebungen mit hohen Temperaturen oder direktem Sonnenlicht zu lassen, da dies ein Brandrisiko darstellen könnte.

⚠ Flüssigkeitseinwirkung: Halten Sie das Gerät von Wasser und Flüssigkeiten fern. Verwenden Sie es nicht, wenn es nass ist bis es gründlich getrocknet ist.

⚠ Beschädigung und Leckage: Stoppen Sie die Nutzung und konsultieren Sie den Kundenservice, wenn das Gerät beschädigt ist oder der Akku ausläuft.

⚠ Korrekte Entsorgung: Befolgen Sie örtliche Vorschriften zur Entsorgung von elektronischen Geräten und Batterien. Entsorgen Sie diese nicht mit dem Hausmüll.

⚠ Kindersicherheit: Halten Sie das Gerät und seine Komponenten außer Reichweite von Kindern, um Erstickungs- oder Verschluckungsgefahren durch Batterien zu vermeiden. Lassen Sie Kinder niemals unbeaufsichtigt mit dem Gerät umgehen.

VORSICHT: Die Nichtbeachtung der obigen Warnhinweise kann zu schweren Verletzungen oder Sachschäden führen.

Für weitere Unterstützung oder Informationen wenden Sie sich bitte an unseren Kundenservice.
Notfallkontakt: +1 866-287-6168 (USA)

EU KONFORMITÄTSERKLÄRUNG

Produktname	Faltbare kabellose Tastatur Full-Size
Modell	XK01
Nennwert	3.7V⎓150mA
Kopplung	2402-2480MHz
Produktionsort	Made in China
Hersteller	Shenzhen Hongjin Electronic Technology Co., LTD
Email	cheri.zhu@protoarc.cn
Adresse	Floor 2, Building 24, Area 3, Gaoxinqi(Ai West Industrial Zone, Dalang Street, Longhua District, Shenzhen City, Guangdong Province, China, 518109
Europäischer Vertreter	UK CH Shenzhen Hongjin Electronic Technology Co., LTD Floor 2, Building 24, Area 3, Gaoxinqi(Ai West Industrial Zone, Dalang Street, Longhua District, Shenzhen City, Guangdong Province, China, 518109 Email: cheri.zhu@protoarc.cn EC REP Shenzhen Hongjin Electronic Technology Co., LTD Floor 2, Building 24, Area 3, Gaoxinqi(Ai West Industrial Zone, Dalang Street, Longhua District, Shenzhen City, Guangdong Province, China, 518109 Email: cheri.zhu@protoarc.cn

Es liegt in unserer alleinigen Verantwortung zu erklären, dass die oben genannten Produkte der Richtlinie 2014/53/EU, 2011/65/EU (in der zuletzt geltenden Fassung) in vollständig entsprechen.

Position: Geschäftsführer
Unterschrift:
Datum der Unterzeichnung: 2022.11
Name des Ort legenden:
Datum der Unterzeichnung: 2022.11