

User Manual (6080A)



1. Normal Time Mode

To see the time; press "MODE" until "TIME" appears in the upper right corner.
Time mode displays: *Hours, Minutes, Months, Days*

To switch between 12-hour and 24-hour indication; press 'ADJ'
To switch between °Celsius and °Fahrenheit; press 'C/F'.

2. Set Time

To set the time; press 'MODE' until 'TIME' shows up in the right upper corner.

After pressing 'SET' you can adjust the time in this particular order by pressing the 'UP' and 'DOWN' buttons: *Hours, Minutes, Years, Months, Days*

3. Set Alarm

To set the alarm; press 'MODE' until a bell icon appears.

After pressing 'SET' you can adjust the alarm in this particular order by pressing the 'UP' and 'DOWN' buttons: *Hours, Minutes, Snooze timer, Desired alarm sound*

Attention: Snooze timer is in minutes.

Once the alarm is set, you can activate the alarm by pressing 'UP' or 'DOWN'.
By doing so you can also activate 'SNZ' (snooze).

Click 'UP' or 'DOWN' once: To set a regular alarm

Click 'UP' or 'DOWN' twice: To set alarm with snooze

4. Set Timer





To set your timer; press 'TIMER'. After pressing 'SET' you can adjust the timer in this particular order:
Hours, Minutes, Seconds

Press 'TIMER' again to start/pause the timer.

5. LED: To activate the LED backlight, push the clock backwards gently

Attention:

1. Do not press the LCD screen
2. If there is no display when you activate the new clock. Please insert the battery again.

TIME	SET Time
	SET Alarm
	SET Timer
	Alarm ON
	Snooze ON

Gebruikershandleiding (6080A)



1. Normale Tijdmodus

Om de tijd te zien; druk op 'MODE' tot 'TIME' verschijnt in de rechter bovenhoek.
Tijdmodus geeft weer: *Uren, Minuten, Maanden, Dagen*

Om te wisselen tussen 12-uurs en 24-uurs indicatie; druk op 'ADJ'
Om te wisselen tussen °Celsius en °Fahrenheit; druk op 'C/F'.

2. Tijd Instellen

Om de tijd in te stellen; druk op 'MODE' tot 'TIME' verschijnt in de rechter bovenhoek.

Nadat je op 'SET' hebt gedrukt, kun je de tijd in deze volgorde instellen met de 'UP' en 'DOWN' knoppen: *Uren, Minuten, Jaren, Maanden, Dagen*

3. Alarm Instellen

Om het alarm in te stellen; druk op 'MODE' tot een bel-icoon verschijnt.

Nadat je op 'SET' hebt gedrukt, kun je de wekker in deze volgorde instellen met de 'UP' en 'DOWN' knoppen: *Uren, Minuten, Snooze-timer, Gewenst alarmgeluid*

Let op: Snooze-timer is in minuten.

Zodra het alarm is ingesteld, kun je het activeren door op 'UP' of 'DOWN' te drukken. Door dit te doen kun je ook 'SNZ' (snooze) activeren.

Klik eenmaal op 'UP' of 'DOWN':
Om een normaal alarm in te stellen.

Klik tweemaal op 'UP' of 'DOWN':
Om een alarm met snooze-functie in te stellen.

4. Timer Instellen





Om je timer in te stellen; druk op 'TIMER'. Nadat je op 'SET' hebt gedrukt, kun je de timer in deze volgorde instellen:
Uren, Minuten, Seconden

Druk nogmaals op 'TIMER' om de timer te starten/pauzeren.

5. LED: Om LED achtergrondlicht te activeren, druk zachtjes op de bovenkant van de klok

Let op:

1. Druk niet op het LCD-scherm
2. Als er geen beeld verschijnt wanneer je de nieuwe klok activeert, plaats de batterij dan opnieuw.

TIME	SET Time
	SET Alarm
	SET Timer
	Alarm ON
	Snooze ON