

...verwijzen de gebruiker verzinkt. Dit licht  
... "TIMER" voor automatisch 6 uur aan en 18 uur uit. 3. "OFF" voor  
... "ON" voor continu aan.

...remplaceable d'éclairage doit être détruit. Les lampes ne peuvent  
pas être remplacées. Cette guirlande n'est pas un jouet - elle doit  
de portée des enfants. Cet ensemble d'éclairage a 3 fonctions: 1.

"TIMER" pour allumé pendant 6 heures et éteint pendant 18 heures,  
2. "ON" pour allumé en continu, 3. "OFF" pour éteint en continu.



**DE** - Nur für den Einsatz im Innenbereich. Das flexible Kabel dieses  
Beleuchtungssets kann nicht ausgetauscht werden; wenn das  
Kabel beschädigt ist, ist das Beleuchtungsset zu beseitigen. Die  
Lampen können nicht ausgetauscht werden. Diese Lichtkette ist kein  
Kinderspielzeug - Bitte für Kinder unzugänglich anbringen. Dieses  
Beleuchtungsset hat 3 Einstellungen: 1. „ON“ = Dauerbetrieb,  
2. „TIMER“ = automatisch 6 St. an und 18 St. aus, 3. „OFF“ =  
dauerhaft aus.



**EN** - For indoor use only. The external flexible cable or cord of this  
luminaire cannot be replaced; if the cord is damaged, the luminaire  
shall be destroyed. The lamps are not replaceable. This lighting  
chain is no toy - please keep it inaccessible for children. This light set  
has 3 functions: 1. "ON" for continuously switched on; 2. "TIMER" for  
switching the light on/off automatically (6 hours on and 18 hours  
off); 3. "OFF" for continuously switched off.

10cm



Itemnr.: 231319

2 x AA (Not included)



1230 ZG WAARLAND (NL) 21