

SpiderCatcher - De makkelijke en snelle manier om spinnen te verwijderen

De **SpiderCatcher** laat geen hinderlijke sporen achter zoals bij andere gangbare apparaten. De **SpiderCatcher** is zeer gebruiksvriendelijk en lang genoeg om insecten vanaf een comfortabele afstand in hoeken of onder meubelen te vangen.

Vorbereiding

Verpakking verwijderen, bijgeleverd haakje aan de wand bevestigen, beschermkap van de borstel verwijderen, oefenen met de meegeleverde kunststof spin.

Inhoud van de verpakking

Spinnenvanger, ophanghaakje, plastic spin, gebruiksaanwijzing

Gebruiksaanwijzing

1. Plaats de **SpiderCatcher** recht boven of schuin boven de spin, knijp in de drukknop van het handvat om de spinnenvanger onderaan te openen en houd de knop ingedrukt.
2. Plaats de spinnenvanger over de spin en laat de knop weer los.
3. De spin wordt nu ingekapseld tussen de nylon haren van de borstel en kan geen kant op.
4. Loop naar buiten en laat de spin op veilige afstand weer vrij.

Bij het apparaat is een haakje meegeleverd. Maak de ondergrond vet en stofvrij en bevestig het op een geschikte plek binnen handbereik.

Spinnen op een gladde ondergrond vangen

Plaats de **SpiderCatcher** direct boven het insect en open de borstel door de knop in het handvat ingedrukt te houden. Plaats de **SpiderCatcher** over het insect, laat de knop weer los waardoor de spin wordt gevangen.

Spinnen in hoeken vangen

Plaats de **SpiderCatcher** in een hoek van 45 graden boven de spin. Druk de knop in het handvat voor 50% in zodat de borstel onderaan maar voor de helft wordt geopend. De **SpiderCatcher** daarna over de spin plaatsen en de knop weer loslaten.

Spinnen onder meubels vangen

Plaats de **SpiderCatcher** boven de grond richting de spin en open de borstel door de knop in het handvat ingedrukt te houden. Positioneer de **SpiderCatcher** zijdelings over de spin en vang deze door de drukknop weer los te laten.

Zo houdt u lang plezier van de SpiderCatcher

- Plaats de **SpiderCatcher** nooit op de borstelharen om schade daaraan te voorkomen.
- Plaats na gebruik de plastic beschermkap om de borstel.
- Gebruik het bijgeleverde haakje om de **SpiderCatcher** na gebruik aan op te hangen.
- Bij gebruik in een hoek de borstel nooit helemaal openen
- Niet met de geopende borstel op een harde ondergrond drukken

Als de borstel is beschadigd

Als de borstelharen niet meer automatisch terug buigen naar de originele stand kunt u een stevig elastiek om de borstelharen bevestigen. Na ongeveer 15 minuten het elastiek weer verwijderen. De borstelharen zullen daarna weer in de juiste positie staan. Mocht een borstelhaar beschadigd zijn dan deze er gewoon afknippen.

Reiniging

De geopende borstelharen simpel met warm water afspoelen.



De **SpiderCatcher** niet op mensen richten en gebruiken.
Gebruik door kinderen uitsluitend onder toezicht van ouders.



www.spidercatcher.eu

SpiderCatcher - The easy and fast way to remove spiders



The **SpiderCatcher** doesn't leave a mess like other conventional devices. The **SpiderCatcher** is very user-friendly and long enough to catch spiders at a comfortable distance in corners or under furniture.

Preparation

Remove package, secure included hanger to the wall, remove protection cap from the bristle, practice with the included synthetic spider.

Contents of the package

Spidercatcher, hanger, plastic spider, instructions

Instructions

1. Place the **SpiderCatcher** right above or diagonally above the spider, grasp the handle to open the bristles by squeezing the trigger.
2. Place the bristle over the spider and let go of the trigger.
3. The spider is now captured between the bristles.
4. Release the spider outside at a safe distance.

A hanger is included with the gadget. Remove the grease and dust on the surface and secure it at a suitable place within your reach.

Catching spiders on a slippery surface

Position the **SpiderCatcher** directly above the bug and open the bristles by squeezing in the trigger and hold it. Position the **SpiderCatcher** over the bug, release the trigger and the spider will be captured.

Catching spiders in corners

Position the **SpiderCatcher** above the spider in an angle of 45 degrees. Squeeze the trigger for only 50% so the bristles are only half opened. Then, position the **SpiderCatcher** around the spider and release the trigger.

Catching spiders under furniture

Position the **SpiderCatcher** above the surface facing the spider and open the bristles by squeezing the trigger. Position the **SpiderCatcher** diagonally over the spider and capture the spider by releasing the trigger again.

How to ensure a long life for your SpiderCatcher

- Do not rest the **SpiderCatcher** on its bristles to prevent damage.
- Place the plastic protection cap around the bristles after usage.
- Use the included hanger to hang the **SpiderCatcher** on a wall after usage.
- Do not fully open the bristles when catching a spider in a corner.
- Never push sharply down onto a solid surface with the bristles open

In case the bristles are damaged

If the bristles don't automatically go back to their original position you can secure a strong rubber band around the bristles. Remove the rubber band again after approximately 15 minutes. The bristles will be in the right position again. In case a bristle is damaged then simply cut off the badly bent bristle.

Cleaning

Simply clean the opened bristles with warm water.



Don't point or use the **SpiderCatcher** on people.
Usage by children only under parental supervision.