VOTIQ™

Thank you
for purchase!

Designed in The Netherlands
Made in China
VOTIQ B.V.

Type-C

Type-C connector

🚀 **Fast** Charging

100 **LED** Digital display

Support Four lines

⏱ **Long** Endurance

VOTIQ™

Powerbank 10 000mAh

⚙ User manual

Powerbank

10 000 mAh

16mm
66mm
141mm

VOTIQ™

PD22.5W
Support 22.5W   QC3.0
Support fast charge   &PD

100

How to Charge:

To charge the Powerbank 10000mAh, use the included micro-USB cable to connect it to a power source such as a laptop, desktop computer, or USB wall charger. The LED digital display will show the current battery level. When the battery level is low, the LED display will flash. The LED display will show the current charging status while charging. The power bank can be fully charged in about 6 hours.

How to Use:

To use the Powerbank 10000mAh to charge your device, connect one end of the appropriate cable (lightning, micro, USB or type-C) to the Powerbank and the other end to your device. The LED digital display will show the current battery level of the Powerbank. To start charging your device, press the power button on the power bank. The LED digital display will show the current charging status of the device.

Maintenance:

To ensure the longevity of your Powerbank 10000mAh, please follow these maintenance instructions:

Keep the Powerbank away from extreme heat, moisture, and direct sunlight.

Do not expose the Powerbank to water or other liquids.

Do not disassemble, modify, or repair the Powerbank on your own.

Keep the Powerbank clean and dust-free.

Use the Powerbank regularly to keep the battery from fully discharging.

Do not store the Powerbank for extended periods of time without use.

Precautions:

To prevent damage or injury, please follow these precautions:

Do not drop or expose the Powerbank to impact.

Do not use the Powerbank if it appears damaged or has been dropped.

Do not allow children to play with the Powerbank.

Do not store the Powerbank in high-temperature environments.

Do not use the Powerbank near flammable materials.

Disconnect the Powerbank from the charging source when fully charged.

Do not store the powerbank in your cargo luggage when travelling.