



#### PRODUCT DESCRIPTION

- One button to control the motor.
- The very strong vibration motor and health silicone cover outside.

#### FEATURES

- Materials: Silicone outside and ABS inside.
- Width: 1.57"4cm.
- Total length: 3.35" / 8.5cm.
- Charging Time: 2hrs.
- Working Time: 1-2hrs.
- Max Noise Level: <50dB.
- Vibration Patterns: 7 speeds/locking+7 suction.

#### FUNCTIONS

- On/Off button (2): Power On/Off.
- Button (1): after turning the toy on, short press to strengthen suction and locking.
- Button (3): after turning the toy on, short press to weaken suction and locking.
- Two functions work concurrently.
- Recharging hole(4): when charging, the red light is flashing, when full charging, the red light stops flashing.

#### Maintenance

- Wash the product with normal temperature water and shower gel after use.
- Wipe dry with a towel after washing, and then store in a ventilated, cool and dry place.
- Full charge storage at the normal temperature, avoid high temperature and dirt. Do not place direct sunlight.
- Please charge once every three months to avoid aging of battery if not used for long time.

#### Warning:

- Please charge the toy before use.
- Please only use the water-soluble lubricants if need during use. Hand cream or silicone soluble lubricant may damage vibrator surface permanently. Please clean vibrator thoroughly after using, especially using lubricants.
- Before use, please do read the instruction first.
- Keep away from children, keep out reach of children.
- Pregnant woman need to consult doctor before use.
- Do not use if the silicone layer broken.

**Attention:** Do not share a same toy with others, since toy is belong to the personal hygiene product.

#### FAQ

- Toy's vibrator can not work when long press the button but the toy can not turn on? Normally, it is power shortage, please recharge.
  - The blue LED light can not turn on when vibrator is changing?
- Make sure to connect vibrator and charging device correctly, check/reconnect power supply and DC plug, or make sure if vibrator is fully charged.
- Please shut down and restart when the program error occurs.

#### Cleaning, Storage, Safety

- Please thoroughly clean vibrator every time before and after use. Using massager special cleaner to clean is the best choice, also you can use warm water and antibacterial soap. (do not use the hot water, its temperature is over 80°C), then rinse residues using clear water, finally gently pat it with a dry towel or non-woven paper until vibrator dry.
- Please do not use cleaner including alcohol, gasoline, acetone.
- To avoid vibrator directly exposed to high temperature or sunshine.
- Please keep vibrator in clean, dry place, and separate it from other vibrators.

#### Warranty

- One year warranty from the date of purchase, including product quality issues caused by product material, manufacturing process and product function. Please contact merchant (who you purchased the toy from), the merchant is responsible for the free replacement of new products for you.
- Warranty is not including incorrect operation, accidental fall, long-term wear or issues caused by dismounting products.

#### Remarks:

Please read all the following safety information before using, or it may result in fire, electric shock, injury, or damage to products or other property.

- This product is only suitable for adults and it is intended for medical use.
- Please stop using this product if there is any discomfort, if there is any damage.
- Regular inspection is necessary. Please stop using if there is any damage.
- This product contains sensitive electronic components. If the battery is dropped, burned, pierced or squeezed, it may be damaged. If you suspect that the product or battery is damaged, please stop using it. Because it can cause overheating or injury.
- Do not attempt to replace the battery by yourself. The lithium battery of the product should be replaced by manufacturer or an authorized service provider. Improper replacement or repair may damage the battery, causing overheating or injury. The battery needs to be removed before the product is discarded. The battery should be powered off before removing, and the battery needs to be disposed of safely, and please recycling it or disposed of separately from household waste. Do not incinerate the battery.
- To charge the product, using the included cable in a power adapter that complies with applicable national regulations or one or more of the following: EN 30146-34, IEC 62884, TD-T 1591-2009, CNS 15285, ITU-T 1000. Or other applicable mobile phone power adapter inter operability standards. Charge only with adapters that comply with applicable international and regional safety standards, including IEC 60950-1, use damage cables, chargers, or charging in a humid environment can result in the electric shock, injury person or something others. Please be sure fully plugged into adapter when using USB charging.
- The product must fulfill applicable surface heat standards and limits. Even if these standards are met, prolonged exposure to hot surfaces can also cause discomfort or injury. Be especially careful if your body has conditions that affect your body's ability to sense heat. Must be careful when using it for people who are not sensitive to heat.

#### Packaging Details:

Gift box, User Manual, Device, USB Data Cable.



#### 製品解説

このボタンは、モードを制御する。非常に強い吸盤モーターと健康シリコンカバーが付いています。

#### 機能

- 材質: シリコン外殻ABS内蔵。
- 幅: 1.57"4cm。
- 全長インチ: 8.5cm。
- 充電時間: 2時間。
- 作動時間: 1-2時間。
- 最大ノイズレベル: <50dB。
- 振動パターン: 7段階锁定+7の吸盤をなめること。

#### 機能

- オン/オフボタン(2): 電源オン/オフ。
- ボタン(1): おもちゃを起動した後、震動モードを強めたり弱めたりするため。
- ボタン(3): おもちゃを起動した後、震動モードを強めたり弱めたりするため。
- ロゴ表示の同時に強めます。
- 震動再充電穴(4): 充電するとき、赤い光が点滅し、完全充電。赤い光が点滅します。

#### メンテナンス

- 温湯で洗浄する比較的の水・シャンプー等。
- 洗浄後はタオルで拭いてから
- 換気され、涼しい、乾いた場所に置く。
- 温湯での温湯温湯・汚れを落としてください。
- 構造を直す。
- 月に2回は強めけてください。
- 当時間使用しない場合は電池の劣化。

#### 注意

- ご使用前におもちゃを用意してください。
  - 柔軟性の潤滑剤を使用してください。
- 中に必要使用するクリーミンまたはシリコーン潤滑剤はハイブリード潤滑を液体に塗りつけることをおすすめします。完全に液体潤滑剤をあわにしてください特に潤滑剤を使用。
- 推奨液は専用に設計されています。
  - おもちゃを落とした後、おもちゃを落とした後。
  - おもちゃを落とした後、おもちゃを落とした後。
  - おもちゃを落とした後、おもちゃを落とした後。

注意:他の人と同じおもちゃを共有しないでください。おもちゃは個人衛生製品に属しているので。

#### よくある質問

- (1) ロゴ表示時は既に他のハイブリードモードではないオーバンがおもちゃをオンにすることはできますか?  
通常は電源不足ですので、充電してください。
- (2) 背面の充電端子をどうやってハイブリードモードで充電できるか?  
詳しくは、電源: DCの背面端子、チャージまたはハイブリードモード完全に充電されるかどうか確認してください。  
(3) ハイブリードモードで再充電してください。
- (4) リモコンを落とした場合?

#### クリーニング、衛生、安全

- (1) 洗浄液を温湯で洗浄するときに弱めにしてください。  
洗浄の範囲に、ハイブリードモード専用の潤滑剤、クリーミングリードに専用の潤滑剤などと、その二つができます。温湯と温湯温湯・汚れを落としてください。
- (2) 洗浄後はタオルで拭いてください。
- (3) おもちゃを落とした後、おもちゃを落とした後。
- (4) おもちゃを落とした後、おもちゃを落とした後。
- (5) おもちゃを落とした後、おもちゃを落とした後。

#### 機能

- (1) 購入日から1年間保証。
- 製品品質の問題を含む製品材料、製造工程及び製品構造、日々に連絡してくださるあなたは、おもちゃを購入する新しい製品や交換料を担当するあなたのための製品。
- (2) 保証は不適切な操作を含みません。  
誤りの落とし、汚染にわたる看板または複数製品を取り替えることによって。

#### 規格

以下のすべての安全規格を満足して下さい。規格は以下のことを満足する製品または他の機器への規格。

- 本品は大人に適したものを子供が触る危険を最小限に抑えるために、子供が触れる場合にご用意をお求めください。
- 充電端子が付いています。ご用意をお求めください。
- 充電端子が付いています。ご用意をお求めください。
- この製品は感度を電子機器を含んでいます。
- 感度を落として、残った後、洗浄してくださり。
- あなたがこの製品またはそれを購入する際は、他の機器に接続する機器を修理してくださり。また、ハイブリードモードで充電する必要があります。
- お自分でハイブリードモードによりしてください。
- 製品のリモコン端子を充電してください。
- ハイブリードモードによりしてください。
- 手洗い用ケータイを充電。充電用ケーブルをAC充電器の端子に接続する際は、アダプターを必ずお使いください。規格: EN 30146-34、IEC 62884、TD-T 1591-2009、CNS 15285、ITU-T 1000。
- おもちゃの端子は他の機器と接続する際はアダプターを必ずお使いください。規格: EN 30146-34、IEC 62884、TD-T 1591-2009、CNS 15285、ITU-T 1000。

#### パッケージの詳細

ギフトボックス、ユーザーマニュアル、デバイス、USBデータケーブル。