145MM
210MM
江心2020.11.4新诺2020. 11. 6

## USE MAINTENANCE INSTRUCTIONS

- This appliance requires little maintenance. It contains no user serviceable parts.
- Do not try to repair it yourself. Any servicing requiring disassembly other than cleaning must be performed by a qualified appliance repair technician.

## CARE AND CLEANING

**CAUTION:** Never immerse the popcorn maker base, cord or plug in water or other liquid.

1. Unplug popcorn maker and allow to cool before cleaning.
2. The popcorn maker should be cleaned after every use.
3. Wash the clear popcorn maker lid, plastic lid cap in warm, soapy water. Use a soft cloth or kitchen sponge, rinse and dry thoroughly.

   **WARNING:** To prevent scratching, never use abrasive scouring pads, steel wool or scouring powders.
4. After considerable use, the non-stick finish may discolor. To remove discoloration, use a soft cloth saturated with lemon juice or vinegar and apply to the finish.

   **CAUTION!** Never place the Popcorn Maker's clear lid, plastic lid cap, in the dishwasher.

## STORAGE

1. Unplug unit and allow it to cool.
2. Store the clear popcorn maker fully assembled.
3. Snap the lid cap in place.
4. Place the clear popcorn maker lid over the base. Make sure the lid handles and the base handles are aligned. Store the popcorn maker in its box or in a clean, dry place.



# SOKANY®

## INSTRUCTION MANUAL
## POPCORN MAKER

**MODEL: SK-905**

**INDOOR HOUSEHOLD USE ONLY**

Please save and read this instruction manual carefully before use.



## INTRODUCTION

Thank you for purchasing our Popcorn Maker. Each unit has been manufactured to ensure safety, reliability, and ease of use. Before use, please read these instructions carefully and save them for future reference.

## IMPORTANT SAFEGUARDS

When using your Popcorn Maker, basic precautions should always be followed, including the following:

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge concerning the use of this product, unless they are supervised or have been given instruction concerning use of the appliance by a person responsible for their safety.
- Children should always be supervised to ensure that they do not play with the appliance.
- Always ensure that the voltage on the rating label corresponds to the voltage in your home.
- Check the power cord and plug regularly for any damage. If the cord or the plug is damaged, it must be replaced by manufacturer or a qualified person in order to avoid an electrical hazard.
- This product is intended for household use only. Industrial or commercial use will void the warranty, and the supplier will not be held responsible for injury or damage caused when using the appliance for any other purpose than that intended.
- Incorrect operation and improper use can damage the appliance and cause injury to the user.
- The manufacturer does not accept responsibility for any damage or injury caused by the improper or incorrect use of the appliance, or for repairs carried out by unauthorized personnel.
- Do not use the appliance if it has been dropped or damaged in any way. In case of damage, take the unit in for examination and/or repair by an authorized service agent.
- To reduce the risk of electric shock, do not immerse or expose the motor assembly, plug or cord in water or any other liquid.
- Never immerse the unit in water or any other liquid for cleaning purposes.
- Remove the plug from the socket by gripping the plug. Do not pull on the cord to disconnect the appliance. Always unplug the unit when not in use, before cleaning or when adding or removing parts.
- The use of accessory attachments that are not recommended or supplied by the manufacturer may result in injuries, fire or electric shock.
- Do not let the cord hang over the edge of a table or counter. Ensure that the cord is not in a position where it can be pulled or inadvertently
- Do not allow the cord to touch hot surfaces and do not place on or near a hot gas or electric burner or in a heated oven.



**CAUTION:** Do not place Bowl Cap onto Butter Reservoir until after corn has popped and the unit is turned off and unplugged.

6. Plug cord into a working 220-240 Volt 50/60 Hz AC-only outlet. Turn the power switch to "ON" (I). The On/Off switch will illuminate.

**NOTE:** The stirring rod will start to rotate and will continue to rotate as long as the switch is in the "ON" (I) position. Do not shake or move the unit during the popping cycle. **Kernels take a few minutes to heat before popping begins.**

7. The popping cycle is complete when the popping sound becomes infrequent or less intense (Approximately 3-4 seconds between pops). To avoid burning any unpopped kernels, immediately press the On/Off Switch to the Off (0) position.
   Unplug the unit from the wall outlet.

8. Grasp the Bowl Cap securely onto the Butter Reservoir. Using oven mitts, grasp the handles and flip the Popcorn Popper upside down, turning the popper away from you. Refer to fig.3. Lift the Base away from the Cover and always ensure to place the Popping Base with the Feet on the table or countertop and away from anything or anyone touching it. Allow to cool down completely before storing.

**CAUTION! Hot steam or oil may escape. Use caution when removing the Base from the Cover. Allow nonstick popping surface to cool completely before handling to clean and store.**

9. Popcorn is now ready to serve. If desired, sprinkle salt or seasonings over the popcorn.

**ADDITIONAL BATCHES**

If additional batches of popcorn are desired, unplug the unit, transfer popcorn into another serving bowl and allow the Popcorn Popper to cool. Carefully wipe the popping surface clean with a wet cloth. The Popcorn Popper is now ready to use again.

**NOTE:** After two batches the unit must cool down completely for at least 20 minutes.



**Using Your Popcorn Popper**

1. Place your Popcorn Popper on a flat surface, such as a table or countertop. Be sure the unit is unplugged.
2. Remove the Cover from the Popcorn Popper. Ensure that the center knob is tightened to secure the stirring rod in place on the center post. Refer to the chart below for recommended oil and kernel measurements.

| VEGETABLE OIL | KERNELS | POPCORN |
|---|---|---|
| 2 tbsp. (30 ml) | 1/3 cup (65 ml) | Approx. 12 Cups(3 quarts)less |
| 3 tbsp. (45 ml) | 2/3 cup (130 ml) | Approx. 25 Cups(6 quarts)less |

**IMPORTANT:** Do not add more corn kernels or oil than what is recommended. Do not substitute butter, margarine, shortening or lard for vegetable oil as they will burn or smoke excessively.

**KERNELS WILL NOT POP WITHOUT OIL ON POPPING SURFACE.**

3. Place the measured oil onto the Popping Surface. Add the corresponding measure of kernels by evenly spreading over the Popping Surface.

**IMPORTANT:** This popcorn popper is designed to be used with regular or premium kernels. Never use microwave popcorn in this popcorn popper.

4. Place the Cover on the Base making sure the handles of the Cover fit into the handles of the Base. Ensure the Bowl Cap is removed from the Cover. Refer to fig.1
5. If buttered popcorn is desired, divide 1 1/2 Tablespoons of butter into 4 equal pieces, over the butter holes in the Butter Reservoir. Refer to fig.2.

- Use of an extension cord with this appliance is not recommended. However, if it is necessary to use an extension lead, ensure that the lead is suited to the power consumption of the appliance to avoid overheating of the extension cord, appliance or plug point. Do not place the extension cord in a position where it can be pulled on by children or animals or tripped over.
- This appliance is not suitable for outdoor use. Do not use this appliance for anything other than its intended use.
- Do not carry the appliance by the power cord.
- Never use this unit near bathtubs, showers, basins or other vessels containing water.
- Do not leave the appliance unattended during use. Always unplug the unit when not in use. Allow it to cool before putting on or taking off parts, and before cleaning the appliance.
- Always operate the appliance on a smooth, even and stable surface. Do not place the unit on a hot surface.
- Do not touch hot surfaces. Use handles, always wear oven mitts or use potholders.
- Never leave the popcorn maker unattended when it is plugged into an outlet.
- After pressing the "ON/OFF" switch, this popcorn maker heats immediately. To avoid overheating add raw popcorn before turning ON.
- This popcorn maker will NOT shut off automatically. To turn the popcorn maker OFF, press the "ON/OFF" switch to OFF. Then remove plug from wall outlet.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Extreme caution must exist when removing popped popcorn. Always flip the unit away from you and over a countertop.
- Allow unit to cool completely before popping a second batch.
- Never place the popcorn maker's clear lid, plastic lid cap, or stirring rod in a microwave oven.
- In case of technical problems, switch off the machine and do not attempt to repair it yourself. Return the appliance to an authorized service facility for examination, adjustment or repair. Always insist on the use of original spare parts. Failure to comply with the above mentioned precautions and instructions, could affect the safe operation of this machine.
- **CAUTION HOT SURFACES:** This appliance generates heat and escaping steam during use. Proper precautions must be taken to prevent the risk of burns, fires or other injury to persons or damage to property.
- **CAUTION!** This popcorn maker is hot during operation and retains heat for some time after turning OFF. Always use oven mitts when handling hot base and allow it to cool before cleaning. Do not place anything on top of the appliance while it is operation or while it is hot.





## KNOW YOUR POPCORN MAKER

1. Lid cap
2. Clear popcorn maker lid
3. Lid handles
4. Popping Plate
5. Center Knob
6. Rotating Rod
7. Base handles
8. Popcorn maker base
9. ON/OFF switch

## SPECIFICATIONS

Capacity: 6/8 Cups / 240ml per cup)

Voltage: 220-240V 50/60HZ

Wattage: 800W

## USING YOUR POPCORN MAKER

**You must read all instructions carefully before using this appliance.**

- Remove all packing material and please check carefully, making sure that your popcorn maker is in good condition. It must have no cracks on the unit and no damage to the cord/plug. Do not discard any packaging until all accessories have been found.
- You must confirm that the voltage indicated on the popcorn maker corresponds with the voltage in your home.
- Remove any adhesive labels or stickers before use.





**Before using for the first time**

1. Carefully unpack the popcorn maker and remove all packaging materials.
2. Wash lid cap, popcorn maker lid in warm of soapy water, rinse and dry thoroughly.
3. Place the base on a clean, flat, heat-resistant working surface.

   **CAUTION!** During popping, the base gets hot. Make sure the surface is able to withstand heat or use a trivet to protect the working surface.
4. Grasp the bowl by handles and place it on the popping plate. Be sure that the handles on the popping bowl rest comfortable on the popping plate.
5. The popcorn maker is now ready for use.

   **NOTE:** When your popcorn maker is heated for the first time, it may emit slight some smoke or odor. This is normal and should disappear after 1 or 2 uses. This does not affect the safety of the appliance. However, as it may affect the flavor of the first batch or popcorn, it is recommended that these be discarded.