Dr.pen
Auto Microneedle System

ULTIMA A6

User Manual

Introduction



Parts Name

PARTS



MTS

Different Cartridges suitable for Device



PMS

How to Operate

-Battery Mode

How to interchange the battery

1 2

(1):unscrew the cover of plug (picture 1)
(2):replace the battery (picture2)

How to charge the battery

3 4

(1):put the battery into the charger (picture3)
(2):Plug in DC adaptor to the jack and then connect power supply (picture 4)



Indicator light
- The indicator light is red while charging.
- The indicator light is green after fully charged

Charger

How to Operate

-Adapter Mode

(1)Assemble the cover of plug. (picture 5)
(2)Plug DC adaptor to the jack.(picture 6)
(3)Plug in DC adaptor to AC outlet.

5 6

How to install a cartridges

(1)Take out needle cartridges in the sterilized packing.
(2)Fitting round slots 1 into 2 of machine,push needle cartridges horizontally up to the end.
(3)Lock the cartridge by turning it to the counter clockwise.
(4)Adjustment of needle length should be done after turn on the machine.
(5)If you want to remove the needle cartridge, turn it to the clockwise and push out horizontally, fittting round slots(slot1.slot2)together.



How to Operate

(3)Adjustment of needle length

You can adjust the length of needle by turning the adjustment ring clockwise or counter clockwise. Turning it clockwise. Turning it clockwise, length of it will be longer. Turning it counter clockwise, length of it will be shorter.

Needle length adjusting point

Counter Clockwise
Length of it will be shorter

Clockwise
Length of it will be longer

How to Operate

3.Adjustment of speed and needle length
(1)Adjustment of Speed and ON/OFF

Power switch
Press 2 seconds to open the device

(2) 5 speed level control

Pressing the switch 2 seconds to open the device. It starts from the lowest speed to highest speed when you turn on the power firstly. The speed cycles low to high. Please press the switch 2 seconds when you need to stop the device.

The flicker frequence of light faster, the speed is higher

Specification

1.Object

Apparatus for applying a Micro-needle Therapy by vibration

2.Performance

A device for puncturing skin-penetrating drugs or cosmetics supports with a micro-needle guided between extended and retracted positions

3.Specification

1)Product name: Auto-stamp Motorizedmeso Machine
2)Model name: Ultima A6
3)Adapter: 5V,1000mA
4)Weight: Main body 62g
5)Size: 126*23(mm)

4.Packing list

Host	1 pcs
Battery	2 pcs
Adapter	1 pcs
Charger	1 pcs
Cartridges	2 pcs 12 pins
Manual	1 pcs

Maintenance

1. General maintenance

-Keep it with its power off. Wipes its surface out with a dry cloth.
-Keep it away from directly sunlight or high temperature and humidity.
-Do not leave the measurement,repair or alter of the device to non-professional staff.
2. Routine Inspection
-Make sure to inspect the device and adapter before use.
-When you use the device which has not been used for a long time,make sure to check if it works properly with safety.

⊘	Please be sure to read instructions before use and follow as described.
⊘	**Do not apply it to the man as follow:** 1.Who has acute disease or bodily disease over 38℃ 2.Who has allergy and hemophilia 3.Who has the implantation of the box 4.Who has high immune fever 5.Who regularly visits hospital 6.Who takes medicines 7.Who is under 12 years old
⊘	Do not use it on the power other than AC 220V.
⊘	It may cause fire or malfunction
⊘	Do not repair, disassemble or alter the controller and the body. (Wear the furniture) It may cause malfunction.
⊘	Do not use it near the place with temperature, dust or humidity. It may cause electric shock.
⊘	Do not touch the device or detach the power cords with wet hands. It may cause electric shock.
⊘	Do not use the damaged cord or prepared cord. Do not use the prepared cord which has cracks or scratch. It may cause scares on the skin.
⊘	When you don't use it for a long time, unplug it from the outlet. It may cause electric fire or malfunction.
⊘	Be sure to have an inspection for test. If any troubles are found, get it repaired.
⊘	No one other than the operator can touch it. It may cause accidents or malfunction.

Precaution

∼	Alternating current	SN	Serial No
⎓	Direct current	EC REP	EU Representative
⧈	Class II equipment	CE	CE mark
⚠	Attention, consult accompanying documents		Manufacturer
	Date of manufacture	F	Floating applied part

Warranty

1. We guarantee the products as follow.
2. We offer free repair to our products within 6 months basis(warranty) from the day they are purchased. If any of our products has damages or natural trouble,we offer repairs or replacements.
3.If they are included in the following problems, you have to pay for the repair even during warranty period.
-Troubles due to a user's careless treatment, voluntary repair or alteration
-Trouble due to the repairs by a man other than technician from a dealer shop or the customer center appointed by manufacturer
-Troubles or damages due to shocks while in movement
-Trouble due to the accessories or options not approinted by manufacturer
-Trouble due to other natural disaster(fires,salt or water,etc)