型号：LP80 pro

尺寸：73*93

材质：80g铜版纸（折页）

联想 thinkplus LivePods LP80 pro
真无线蓝牙耳机

thinkplus

使用说明书
使用前请阅读使用说明书

Lenovo

物品清单

多功能智能充电盒 / 充电口 / 充电线

设备专用说明书

产品使用简介

(1) 除说明书有特殊标示的操作方式以外，请按壳式机制或更换产品内的任何零件。
(2) 请勿将产品放入水或其他任何液体中，此产品非防水设计。
(3) 如果有任何液体不小心进入产品内时，请立即断开连接并拆开此产品。
(4) 为避免触电，请在安装或拆解产品时，确保非上没有达水。
(5) 请勿将此产品放置于热源附近或直接暴露在火源附近。
(6) 请勿将此产品放置在有强电场或力的环境中，否则会导致产品故障。

产品规格

蓝牙版本：V5.3
传输距离：≥10m
电池容量：25mAh
使用时长：约4小时（耳机）
充电时长：约1.5小时
额定输入：5V ⎓ 25mA

充电盒规格

电池容量：180mAh
充电时间：约1.5小时
额定输入：5V ⎓ 200mA
（所有技术规格以实际性能为准）

给充电盒充电
用Type-C充电线连接充电盒到5V电源适配器
（温馨提示：当耳机放入充电盒，充电盒指示灯状态为红灯4次常灭时，请及时给充电盒充电）

额定输入：5V ⎓ 25mA(耳机)

5V ⎓ 200mA(充电盒)

操作灯光指示

充电	充电盒给耳机充电	白灯常亮+呼吸模式
	充电盒给电池管	充电仓给三六灯灯闪烁呼吸灯
	给充电盒充电	充电过程中红灯常亮,充满后灯灭常亮

产品操作说明

① 开机
方法一：长按耳机触摸区域3秒
方法二：将耳机充电盒进行开充电盒上盖，取出耳机自动开机

② 关机
耳机放入充电盒，关闭充电盒盖子自动关机充电

③ 配对
步骤一：开机后自动进入蓝牙配对
步骤二：打开智能设备的蓝牙列表，搜索“联想thinkplus-LP80 pro”并连接

耳机左、右耳配对

触摸区域的操作

音乐播放模式

单击耳机操作

- 播放/暂停 — 双击任意耳机触摸区域
- 上一曲 — 三击左耳机（L）触摸区域
- 下一曲 — 三击右耳机（R）触摸区域

语音助手

- 唤醒语音助手，长按任意耳机触摸区域3秒后出现语音助手功能（需要环连接智能设备支持）

音量设置

单击耳机操作

- 加音量 — 单击右耳机（R）触摸区域（最大音量“嘟”提示音）
- 减音量 — 单击左耳机（L）触摸区域

长按任意耳机触摸区域3秒听到“滴滴”后松手

恢复出厂设置

单个耳机开机进长连接状态下，连接单击耳机触摸区域3次，双耳耳机开机未连接状态下左右同时单击耳机触摸区域3次，（提示音：嘟嘟嘟）

产品中有害物质名称及含量

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。
×：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。
惠普拉公 “X” 的部件，被欧盟绿技术豁免手限制而无法实现有害物质的替代。

印刷电路板组件 *，包括印刷电路板及其零部件，电子元器件等。
恢复产品型号不同，您所购买的产品可能不会含有以上所有部件

10 在中华人民共和国境内销售的电子电气产品必须标志此标志，标志内的数字代表在正常的使用状态下的产品的环保使用期限。

保修声明

免责声明
本使用手册没有任何形式的担保，立场表达或其他暗示。本使用手册所提到的产品，规格及信息仅供参考，内容存会随时更新于网页，恕不另行通知。

保修声明
就本文所提的产品做如下保证：如产品在官网买日起十二（12）个月（“保修期”）内，在正常使用情况下因质量原因发生损坏，能修理的，免费修理；经厂家确认无修理的，免费更换。修理或更换后的产品，在剩余保修期（最短不少于30天）内继续享有保修。购买日以销售发票日期为准。如无法确定购买日期，则保修期自产品生产日期起算十二（13）个月计算。如申请换修，请先取电产品服务热线，并按规们指示的方式执行。申请保修时，您需要提供身份、完整无损保修卡的有效凭证。

以上保证不适用于下列情况：
1.超过三年有效期的；
2.因改装修本，产品编码与产品本体不符；
3.因滥用，滥用或不适当的运输、使用、维护或保管所导致的故障或损坏；
4.因不可抗力（如地震，战争，火灾等）或意外导致的故障或损坏；
5.拍摄、录或因受力过大而损坏；
6.因承担过重负荷而导致的故障或损坏；
7.任何因以往物体造成的损坏；
8.有毒物或水渗透进产品；
9.因擅自拆改等导致的损坏；
10.产品正常使用过程中发生的变化，颜色、磨损、褪色和其他损耗；
11.如产品序号行向您被更改或损毁，本保证将失效。

保修声明

产品及服务物料的序号和外观可能因不属于保证范围，但应在接收产品时告诉经销商并付任何不符合之处。

以上保证是我们就产品做出的全部保证。自在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。

服务监督热线：400-812-0102

售后邮箱：frank@szeysian.cn

“Lenovo”、“thinkplus” 是联想集团所属企业的商标。提及的其他公司、产品或服务名称可能属其他公司的商标。
版权所有© 2022联想集团所属企业和其许可方保留所有权利。

thinkplus

Lenovo thinkplus LivePods LP80 pro

thinkplus

Manual
Please read this manual carefully before using the earbuds

Lenovo

Packing list

Type-C charging port / Type-C cable / Manual&warranty card

Product idtroduction

①Except for the operation methods specifically marked in the manual,please do not try to disassemble or replace any parts in the earbuds.
②Don't put the earbuds in the water or any others liquid.The earbuds are not waterproof.
③If any liquid enters the product by accidentally,please disconnect and turn off the product immediately.
④Please make sure that there is no water on your hands when installing or uninstalling the product to avoid electroshock.
⑤Do not put the product near by the heat source or expose it to the fire source directly.
⑥Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product specifications

BT Version：V5.3
Transmission distance：≥10m
Battery capacity：25mAh
Playing time：About 4 hours（headphone）
Charging time：About 1.5 hours（headphone）
Rated input：5V ⎓ 25mA

Charging case specifications

Battery capacity：180mAh
Charging time：About 1.5 hours
Rated input：5V ⎓ 200mA
(All technical data are subject to actual performance)

Charge the charging case
Connect the charging case to the 5V power adapter with the Type-C charging cable
(Tips: When the earphones are put into the charging case and the indicator status of the charging case is white and off for four times, please charge the charging case in time)

Rated input：5V ⎓ 25mA(earphones)

Rated input：5V ⎓ 200mA(Charging case)

Operation light indication

Charge	The charging case charges the earphones	The white light is on for 4 seconds and then off
	Low power alarm of charging case	When the voltage of charging case is 4 times, the red light flashes, 4 times and goes out
	Charge the charging case	During the charging process, the red light flashes, and the red light is always on when the battery is fully charged

Product operation instructions

① Power on
Option 1: Long press the MFB button for 3 seconds.
Option 2: The earbuds automatically turn on when they are taken out from the charging case.
② Power off
Put the earbuds back in the charging case and they will automatically shut down and charge.
③ pairing
Step 1: Automatically enter bluetooth pairing mode after power on.
Step 2: Open the list of bluetooth devices, search "联想thinkplus-LP80 pro" and connect it

Paired success("Ding")

The operation of the touch button

Music Play Mode

Left/right earphone operation

- Play/pause — Double-click the touch area of earphone
- Previous song — Three strikes the touch area of left earphone
- Next song — Three strikes the touch area of right earphone

Volume set

Left/right earphone operation

- Increase volume — Click the the touch area of earphone R (maximum volume will prompt "du" voice)
- Reduce volume — Click the the touch area of earphone L

Call mode

Left/right earphone operation

- Answer a call — Double-click the touch area of any earphone
- Hang up a call — Double-click the touch area of any earphone
- Reject a call — Long press the touch area of any earphone

Voice assistant

In addition to the call state,long press touch area of any earphone for 3 seconds to start voice assistant function（need the equipment support）

- Long press the touch area of any earphone for 3 seconds

Reset

Single earphone: When the earphone is powered on and not connected to the device, touch the MFB for five consecutive times
TWS: When the device is not connected and the earphones are powered on, touch the MFB of earphone L and R for five consecutive times at the same time

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
○:Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.
X:Indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.
The parts marked with "X" on the form are all harmful due to the technical limitations of the current development, Substitution of substances.
Printed circuit board components
Including printed circuit boards and their partsi.electronic components, etc.and depending on the product model,the earbuds you purchased may not contain all the above components.

10 Electronic and electrical products sold in the People’s Republic of China must mark this LOGO,the number in the logo represents the product under normal use Environmental protection use period.

Warranty statement

Disclaimer
This user manual does not have any form of guarantee,position expression or other implication.The mentioned products,specifications and information are for reference only,and the content will also be updated on the web at any time without additional separate notice

Warranty statement
The product attached to this document is guaranteed as follows:If the product is twelve (12) months from the date of purchase(“Warranty Period”)under normal conditions of use due to quality defects damaged,can be repaired.Free repair.free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product.Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days).Purchased by sale the ticket date shall prevail.If the purchase date cannot be determined,the warranty period shall be 13 (12) months
If you apply for a warranty,please call the product service hotline first and execute it in the manner instructed by us.When applying for warranty,you need to provide an accurate,complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1.Exceeding the validity period of the three packs;
2.Altering the warranty card and product code does not match the product body;
3.Failure or damage caused by misuse,abuse or improper transportation,use,maintenance or storage obstacles or damage;
4.Failure or damage caused by force majeure (such as earthquake,war,disaster,etc.) or accident bad;
5.The zipper and tower buckle are damaged due to excessive force;

Warranty statement

6.Disconnection or tearing caused by excessive load;
7.Any damage caused by sharp objects;
8.Products with signs of burning of flooding;
9.Damage caused by unauthorized disassembly;
10.Aging,discoloration,abrasion,rusture and other losses that occur during the normal use of the product;
11.If the original identification label of the product is changed or damaged,this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee.You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products,and are only applicable in mainland China.Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

Service supervision hotline: 400-812-0102
After-sales mailbox:frank@szeysian.cn

“Lenovo”、“thinkplus” is a trademark of a company owned by Lenovo Group.
The names of other companies, products and services mentioned may be trademarks of other companies.
Copyright ©2022 Lenovo Group and its licensors. All rights reserved.

thinkplus