Ultrasonic Cleaner

User Manual



To prevent injury to users and others, and to avoid property damage, please strictly adhere to the following guidelines:

- Keep out of reach of children and do not allow children to use this product, as it may pose a safety risk.
- Individuals with implanted pacemakers should not use this product, as it may cause physical discomfort.
- Before use, fill the cleaning tank with water. Failure to do so may cause overheating, leading to malfunction and posing a safety risk.
- Do not place flammable liquids inside, as this may cause a fire.
- Do not rinse the main unit or cleaning tank, as this may cause water to enter the interior. That could result in machine malfunction and pose a safety hazard.
- Do not fill the unit directly under a faucet. Water exposure at the connection between the main unit and power supply may cause malfunction.
- Do not use near water sources such as sinks, as this may cause electric shock, fire, or malfunction.
- Do not touch the power connection with metal objects, as this may cause electric shock, fire, or malfunction.
- Do not disassemble, repair, or modify this product, as this may result in electric shock or injury.
- Do not use wet hands to unplug or plug the host power adapter into an outlet, as this may cause fire, electric shock, or other safety hazards.
- When not in use, unplug the host power adapter from the power outlet to prevent fire, electric shock, and malfunction.
- Do not add disinfectants, sterilizing agents, or acidic solvents to the cleaning tank, as this may cause deterioration of the resin components and damage to the stainless steel parts.
- Do not clean items with low surface hardness (Mohs hardness below 8), such as pearls, as this may cause damage, discoloration, or loss of luster.
- Do not wash rings or necklaces with gemstones or diamonds for extended periods, as this may cause the gemstones or diamonds to fall out.
- Prevent the host from falling or being subjected to strong shaking, as this may cause damage, deformation, or malfunction.
- If the cord is damaged, it must be replaced with a replacement cord or a replacement assembly purchased from the manufacturer or service department.

Product Structure

