材质：157g 铜版纸
尺寸：140X140MM
装订方式:鞍形折
颜色:四色印刷

User Manual

Wi-Fi Pet Feeder

FOTW

Please read this manual careful before using.

IMPORTANT SAFETY INFORMATION

Thank you for choosing FOTW Pet Feeder. We brand dedicated to using technology to create a better life for your loved pets.

WARNING

- Dispose of all packaging materials properly (e.g. plastic bag) not needed in plastic bags. These bags could cause suffocation keep away from children and pets.
- Do not place the feeder in a dishwasher, oven, or near heat sources.
- To reduce the risk of injury, please keep close supervision when an appliance is used near children.
- Do NOT use the feeder with pets not able to reach the food tray or with any physical disability.
- Do NOT immerse the base part in water at any time or in the charge electronic components like the control unit.
- Do NOT place any foreign object in the pet feeder.
- Do NOT use the feeder for anything other than its intended use.
- Do NOT use any accessory or cause it to block feeds.
- Do NOT disassemble the unit other than as instructed in the User Guide.
- Do NOT use the feeder outdoors or near any heat source.
- Only use attachments recommended or sold by the manufacturer. The use of attachments not recommended or sold by the manufacturer may cause an unsafe condition. Do not modify the pet feeder.
- Do NOT use the feeder if it has been dropped or damaged in any manner. Return the feeder for repairs on the pet feeder yourself. Contact our customer service immediately for further instructions.
- Examine the feeder after installation.Do not plug it if there is water on the power cord or plug.
- To avoid tripping, always position power cord out of the way of foot traffic.

CAUTION

- Do NOT allow pets to chew on or swallow any parts.If you are concerned about the power cord purchase a cord (circuit or hardware)to protection or any hardware store to protect the power cord.
- Do NOT use the feeder if the power cord or plug is damaged.
- Do NOT install or store the pet feeder where it will be exposed to weather or temperatures below 4°C/40°F.
- Use alkaline D batteries to power.Do NOT use rechargeable batteries.
- Remove batteries when the unit is not in use for a long period of time. Do not replace batteries with new ones.
- Do NOT Fill the pet feeder to top.Food takes up float bowl,Lift and spin to 2 using both hand and then to the feeding the unit in an upright position.
- Do NOT use food that is too large or too small.Kibble ranging from 5.08mm(0.20 in) in diameter. Larger kibble may get stuck at the feed outlet.
- Do not put your fingers into the food outlet or let your fingers touch the knob.
- Read and follow all safety and notice listed on the pet feeder and in the packaging.

Product Overview

Product Specifications

Product Model	FOTW
Input	DC5V
Dimensions	141*141*44 inches/ 6.45 Pounds
Dual Power	Type-C 5 cell 2 batteries
Capacity	4.0 Litre/135 oz. Food
Programmable	1-50 portions, 15s per portion, 10 meals per day

Prepare for setting

1.Assemble the bowl, Plug in power adapter, make sure the Power Switch at "1" location



2. Recommended to install batteries to ensure that the feeder works properly when the power is off.

3. Press round button for 3 seconds to open the lid
Recommended to add food to the bowl 2 inch to attainer

Operation Interface

Indicator/Button Quick Guide

Icon	Meaning
	Power on
	Once setup is time is 00:00, automatically synchronize network time when connected to the network
	White blinking: Waiting to connect to network
	White solid: Connected to Wi-Fi
	Red blinking: Offline
	Red blinking: Mechanical error
	White solid: Button locked
	White solid: Connected external power
	White blinking: No battery
	Red blinking: Low battery
	Log press one second, Enter pairing mode
	Long press to record or cancel audio
	Press and hold 3s to enter setting to unlock/lock the feeder

Note: The screen will be locked automatically without operation for 60s.

Connect to APP

System Requirements:
- Phone or tablet (iOS or Android) with an compatible Android smartphone(5.0 Or later)
- Not suitable for iPad
- Wireless router (2.4GHz)

Install the APP and Log in

Search "Smart Life" on your phone's app store or scan the QR code to download the app.

1. Create an account and password

Add the Device

A. Add the feeder via Bluetooth mode:

1. Add device and click **Add Device**

2. Add Bluetooth device

3. Enter 2.4GHz Wi-Fi name and password

4. Pairing for connecting

B. Add the feeder Manually

1. Choose "**Add Manually**"

2. Go to the Wi-Fi connection interface of the phone, the device name **SmartLife-xxxx** and tap to connect

3. Back to APP and waiting for connecting

4. Enter 2.4GHz Wi-Fi name and password

5. Pairing for connecting

Manual Feeding

Choose "**Feed Portion**" → "**Manual Feed**" then adjust the portion amount (1-50 cups)

Set Meal Schedule

"**Meal Schedule**" → "**Add**" (Start feeding time, feeding date, feeding portion)

1. Loop the screen to choose **feeding time**
2. Highlight days to feed
3. Click to set feed portion
4. Save the setting, it shows on the schedule

Feeding Time
Feeding Amount
Repeat
Save

Battery Level

Battery level, wait, low battery, and no battery

Reboot the feeder

Reset the feeder, feeding setting that have been set will not be changed.

Feeding Record & Alarm Notification

After feeding, there will be feeding record in the APP. The feeding record in the last 7 days will be shown. When as time comes, the number of portions will show. If You can click "**NO**" / "**Message Center**" to view the alarm notification.

Setting Page Guide

Device Name Disabled

Click to edit, all feeder features are disabled, the screen displays "Edit" when button is pressed.

Sound Prompt (enable/disable)

Control the feeder's keypad sound prompt.

Display Light

Control the indicators on the display

(If the power supplied by the adapter only, the display will be off after 30 seconds of inactivity. If the power supplied by batteries for 2 min, the screen will turn off automatically. Press any button (an audio 3)

Battery Status

Battery level, low battery, and no battery

Reboot the feeder

Reset the feeder, feeding setting that have been set will not be changed.

About Cleaning

The base unit cannot be submerged in water

Food bowl, stainless steel bowl, hopper and lid can be washed in the sink.

(1) Open the lid and take out the desiccant.
(2) Remove the feeding bowl and empty the pet's in the hopper.
(3) Counterclockwise rotate the hopper to separate the hopper from the base.

Troubleshooting

Question	Solution
Fail to connect to the network	1. Please use USB power adapter to supply power 2. Please keep the router and the feeder as close as possible 3. Please select 2.4GHz network or dual-band network 4. Please make sure the Wi-Fi name and password are correct and try rest
How to check the Wi-Fi status of the feeder?	Check the Wi-Fi status on the feeder 1. Long press button ( ), "Device Information" is shown Wi-Fi address 2. When the master signal is disconnected, red Wi-Fi indicator flashing fast 3. Power by batteries only, feeder will automatically disconnect from the network to save power. Red Wi-Fi indicator solid
My feeder is offline? Red Wi-Fi indicator flashing?	1. Check the network status on the display and make sure the network is connected 2. Check if your password is correct and the feeder is within the range of the router
Offline status, does feeder dispense food on schedule?	1. Yes, feeder will dispense food according to the saved schedule 2. Feeder is not dispense food on schedule
The food indicator is light on	1. Food outlet is blocking 2. Food is too small or too large, please use food size 5.08-10.0 mm
How to factory reset the feeder?	Unplug power, press and hold the setting button for 6 seconds until you hear the beep
The display time is not correct?	1. Check network connect status, automatically synchronize network time when connected to the network 2. Check time zone, Time zone setting please in "Time Zone"
Display screen dimmed	1. Long press the button to wake up the screen manually 2. Low battery status, the display screen will dimmed

FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body. Use only the supplied antenna.

Made in China