

← Overall Size

Topmount installation

Installation Instructions Topmount Sinks

NO	Description	Picture	Qty
A	Kitchen Sink		1
B	Topmount Sink Accessories Box		1
C	Cut-out Template		1

Step 1: Create A Template

Counter Dotted Line

Step 2: Put the sink into the hole

Position right on

Step 3: Install The Kitchen Sink

Undermount installation

Installation Instructions Undermount Sinks

NO	Description	Picture	Qty
A	Kitchen Sink		1
B	Accessories Box		1
C	Cut-out Template		1

Step 1: Create A Template

Counter Dotted Line

Step 2: Fix Nuts Holes According To Instructions Below

Hole Size: $\varnothing 11\text{mm}$ with Depth 15mm

<700mm 700mm-1000mm >1000mm

Step 3: Install The Nuts

Step 4: Install The Kitchen Sink

For undermount
Please use the inner dimensions of
the sink as reference

← Topmount
Dotted Line Model