



OEM LINE

Ultimate High Quality Car Parts & Accessories

Installation Instructions



1. Open the package and confirm that the product is not damaged



2. Loosen the nut



3. The base is connected to the board body, and the sound is heard to be stuck.



4. Lock nut



5. Fasten the retractable part of the base buckle to the side of the headrest



6. Open the elastic telescopic clip and put it into the mobile phone