

INSTALLTION

— Product Parameter —

① Clear exposed steel sheet



② Fix the rubber of the entire door



③ Use the tool to press the strip into place



④ Finish

