

# Easy to Install and Remove

No tools needed



← Loosen the screw and install it on your bike.



← Unlock the nut-a.  
Rotate nut-b to extend the arms.



← After putting the phone:  
Rotate the nut--b to retract the arms.  
Lock the nut-a.

# SIMPELE INSTALLATIEMETHODE



GESCHIKT VOOR STANGEN 15MM-35MM



1. MAAK DE SCHROEF  
LOS



2. KLEM DE HOUDER  
OM DE STANG



3. DRAAI DE SCHROEF  
AAN



4. KIES DE IDEALE  
HOEK EN DRAAI VAST