

Installation method



1

Attach the double-sided 3M sticker to the back of the iron sheet



2

Suck the iron sheet to the back of the light bar



3

Tear the adhesive tape, stick the light bar to a right place



4

Stick the adhesive firmly to the iron sheets and remove the light bar, put on the light after half an hour