

1. Take out the license plate lamp cover



2. Remove the original halogen lamp from the base



3. Insert directly the Audew T10 LED 4. Put the base of license plate back to into the base(Non-Polarity)



the car then open the knob to test