

Installation Tips



① Test location and marking



② Attach double-sided tape



③ Tear off the tape



④ Alignment mark position



⑤ Lightly press



⑥ Scotch tape for further fixing



It is recommended to use paper as the bottom and then stick the tape to facilitate subsequent cleaning.