

Application

- Thoroughly clean surface to remove all grease, dust and polish residues (e.g. with a silicon remover) and dry with a cotton cloth.
- Match **decorative stripes** to the part of the **vehicle** to be covered and trim to size with scissors.
- Insert the tape into the **assembly aid** with the protective paper up.
- Divide the adhesive from the protective paper and then let it slide below the **assembly aid**.
- Lay the **assembly aid** on the selected zone and gently press down. Steadily and lightly push applying the **stripes** all around the surface.