



### 1. DASHBOARD/WINDOW MOUNT.

A.

CLEAN THE SURFACE, REMOVE THE PROTECTIVE FILM.

B.

STICK THE MOUNT AND PUSH THE LOCK BUTTON.

C.

CONNECT THE MAGNETIC HEAD ON THE DASHBOARD MOUNT.

YOU ARE GOOD TO GO!



### 2. AIR VENT MOUNT.

A. ATTACH THE MAGNETIC HEAD AND ROTATE TO LOCK IT.

B. INSERT THE MOUNT TO A FLAT AIR VENT, VOILA!