

1. Handheld bidet

2. Bidet holder

3. Flexible hose

4. T-adapter

INSTALLATION STEPS:

- ①. Turn off water feed
- ②. Disconnect toilet hose from flush tank
- ③. Connect T-adapter to flush tank
- ④. Connect toilet hose to T-adapter
- ⑤. Connect other end of shower hose to sprayer
- ⑥. Turn water feed back on
- ⑦. Screw bracket to wall or screw bracket to hook then mount on the tank.

