

G10 Installation Diagram



G10-9005 and 9005 light housing



Fold the copper strips if needed



Insert the headlight and screw tight to clockwise direction



Insert the copper strips



Put the driver inside



Put on the dust cover