

Nivå 0 knäskydd som endast lämpas till användning vid inget skydd mot genomträngning.

Nivå 1 knäskydd som lämpar sig att använda på plana eller ojämna ytor och skyddar mot genomträngning vid kraft på minst (100±5) N.

Nivå 2 knäskydd som lämpar sig att använda på plana och ojämna ytor i svåra förhållanden och skyddar mot genomträngning vid en kraft på minst (250±10) N.



EN

CE EN 14404:2004 + A1:2010

Art. no 9943, 9944, 9945

Knee protectors for work in kneeling position. Certificated according to EN14404:2004 + A1:2010, type 2, level 1. This type of personal protective equipment conforms to the requirements in the PPE regulation (EU) 2016/425 and the aforementioned standard. These knee protectors are certified by notified body no. 0121, IFA - Institut fuer Arbeitsschutz der Deutschen Gesetzlichen Unfallversicherung, Alte Heerstr. 111, 53757 Sankt Augustin, Germany.

The knee pads must be used together with Jobman's trousers art.

2129, 2130, 2133, 2134, 2164, 2167, 2174, NP2174, 2179, 2181, 2191, 2200, 2201, 2217, 2221, 2222, 2236, 2240, 2262, 2263, 2272, 2281, 2290, 2291, 2297, 2358, 2362, 2391, 2431, 2432, 2697, 2731, 2732, 2734, 2872, 2972, 3231 which are certificated according to EN14404:2004 + A1:2010.

Level 0 knee protectors suitable only for use on flat floor surfaces and providing no protection against penetration.

Level 1 knee protectors suitable for use on flat or non-flat floor surfaces and providing protection against penetration at a force of at least (100 ±5) N.

Level 2 knee protectors suitable for use on flat or non-flat floor surfaces in severe conditions and providing protection against penetration at a force of at least (250±10) N.



NO

CE EN 14404:2004 + A1:2010

Artikkelnr. 9943, 9944, 9945

Knebeskyttere for arbeid sittende på kne. Godkjent i henhold til EN14404:2004 + A1:2010, type 2, nivå 1. Denne typen personlig verneutstyr er i overensstemmelse med kravene i PVU-forordningen (EU) 2016/425 og den tidligere nevnte standarden. Disse knebeskytterne er godkjent av teknisk kontrollorgan nr. 0121, IFA - Institut fuer Arbeitsschutz der Deutschen Gesetzlichen Unfallversicherung, Alte Heerstr. 111, 53757 Sankt Augustin, Tyskland.

Knebeskytterne må brukes sammen med Jobmans bukser med artikkelnr. 2129, 2130, 2133, 2134, 2164, 2167, 2174, NP2174, 2179, 2181, 2191, 2200, 2201, 2217, 2221, 2222, 2236, 2240, 2262, 2263, 2272, 2281, 2290, 2291, 2297, 2358, 2362, 2391, 2431, 2432, 2697, 2731, 2732, 2734, 2872, 2972, 3231 som er godkjent ifølge EN14404:2004 + A1:2010.