

INSTALLATION



① Attach PC frame to phone



② Insert bottom edge of phone into bottom edge of case



③ Push upper corners of phone into case

REMOVAL



④ Use gap in bottom-right corner to pry case from phone



⑤ Remove phone from case



⑥ Detach PC frame from phone