KQLD01-24 - Probe D KQLD01-68 KOLDO1-VE C G

System wiring diagram

Installation instructions

- Prepare tools such as drills, tapes, scissors, screwdrivers, electricians rubber, multimeter, test lamp, marker, knife, crowbar, etc.
- Conncet the line refer to the diagram, plug in the probe to test, if ok, start to install.
- 3. Drill hole in the proper position of the bumper to install the probe.
 The distance between probe and ground is 50~60cm, "UP" must be upward, probe should not be oblique to the ground. No spare tyres or bumpers are allowed on the outside. Rear probe can not be installed in front as front probe.
- 4. Connect display and probe to control box, test on road.
- Testing is OK. System wiring diagram, away the disturbing objects.
- 6. Fix the control box and display well, away high temperature, high current line, speaker, motor, electric generator etc, and waterproof. Don't place the control box in engine compartment, advise to glove box or under the trunk pad.
- Surface unevenness, porous, soft, rain and snow will affect the effect of probe.