



① Insert two stripped wires in one solder wire connector.

② Apply heat to the connector with a heat gun or small torch. At the same time, rotate the connector to make it evenly heated.



③ Operation done after tubing reduces in size and solder melts.