Assembly instruction | Slim metal cross base





























★ ATTENTION! For upholsterd shell use different parts C -> M6*18 screws









