


Force 8



FOCUS
FITNESS

Force 8

Index

EN

1 Parts list.....	3
2 Overview drawing.....	4
3 Assembly.....	5

NL

1 Onderdelenlijst.....	8
2 Overzichtstekening.....	9
3 Montage	10


Force 8

1 Parts list

NUMBER	DESCRIPTION	QUANTITY
1	MAIN FRAME	1
2	FRONT BASE	1
3	REAR BASE	1
4	SEAT ADJUSTMENT	1
5	BACKREST ADJUSTMENT	1
6	BACKREST SUPPORT	2
7	SEAT SUPPORT	2
8	JOINT PLATE	1
9	SEAT CUSHION	1
10	BACK CUSHION	1
11	BOLT M6*60 + WASHER	8
12	SQUARE NECK BOLT M10*60 + WASHER + NUT	2
13	BOLT M10*75 + WASHERS + NUT	2
14	BOLT M10*120 + WASHERS + LOCK NUT	1
15	BOLT M10*170 + WASHERS + LOCK NUT	2

Force 8


2 Overview drawing



Force 8

3 Assembly


STEP 1



1. Attach front base (2) to main frame (1) with square neck bolt M10*60 + washer + nut (12).
2. Attach rear base (3) and joint plate (8) to main frame (1) with bolt M10*75 + washers + nut (13).

Force 8


STEP 2



1. Attach seat support (7) and backrest support (6) to main frame (1) with bolt M10*170 + washers + lock nut (15).
2. Attach backrest adjustment (5) to backrest support (6) with bolt M10*170 + washers + lock nut (15).
3. Attach seat adjustment (4) to seat support (7) with bolt M10*120 + washers + lock nut (14).

Force 8

STEP 3




1. Attach seat cushion (9) to seat support (7) with bolt M6*60 + washer (11).
2. Attach back cushion (10) to backrest support (6) with bolt M6*60 + washer (11).

1 Onderdelenlijst

NUMMER	BESCHRIJVING	AANTAL
1	HOOFDFRAME	1
2	VOORSTE BASIS	1
3	ACHTERSTE BASIS	1
4	ZITAANPASSING	1
5	RUGLEUNINGVERSTELLING	1
6	RUGLEUNINGSTEUN	2
7	ZITSTEUN	2
8	VERBINDINGSPLAAT	1
9	ZITKUSSEN	1
10	RUGKUSSEN	1
11	BOUT M6*60 + SLUITRING	8
12	BOUT MET VIERKANTE HALS M10*60 + SLUITRING + BOUT	2
13	BOUT M10*75 + SLUITRINGEN + MOER	2
14	BOUT M10*120 + SLUITRINGEN + BORGMOER	1
15	BOUT M10*170 + SLUITRINGEN + BORGMOER	2

Force 8


2 Overzichtstekening



Force 8

3 Montage


STAP 1



1. Bevestig de voorste basis (2) aan het hoofdframe (1) met de vierkante halsbout M10*60 + sluitring + moer (12).
2. Bevestig de achterste basis (3) en verbindingsplaat (8) aan het hoofdframe (1) met bout M10*75 + sluitringen + moer (13).

Force 8


STAP 2



1. Bevestig de zitsteun (7) en de rugleuningsteun (6) aan het hoofdframe (1) met de bout M10*170 + sluitringen + borgmoer (15).
2. Bevestig de rugleuningverstelling (5) aan de rugleuningsteun (6) met bout M10*170 + sluitringen + borgmoer (15).
3. Bevestig de stoelverstelling (4) aan de stoelsteun (7) met bout M10*120 + sluitringen + borgmoer (14).

Force 8

STAP 3



1. Bevestig zitkussen (9) aan zitsteun (7) met bout M6*60 + sluitring (11).
2. Bevestig rugkussen (10) aan rugleuningsteun (6) met bout M6*60 + sluitring (11).