



① Clean the wall



② Tear off the strong film



③ Align the position horizontally



④ Click into the card slot
from top to bottom



⑤ Installed



⑥ Just put in a tissue

