

**Installation Instructions:**

1. As shown in the figure, put the base cover "5" onto the floor pipe "6" from the lower end, make sure the rubber washer on the center hole of the base cover is in proper position when sliding the base cover upward.
2. Fix the base fixing kit "2" onto the lower end of the floor pipe "6" and tighten the screw which has been pre-fixed in the hole on the side of base fixing kit - using the Allen key "4" supplied.
3. Put the pair of flexi tails "1" through the floor pipe from the lower end to the top end, and connect to the two inlet holes on bottom of the tap body "9", note the hot and cold identification, and make sure the flexi tails are connected tighten enough to the tap body using tool when applicable.
4. Put the tap body "9" on top of the floor pipe, make it align and lock it from the two screw holes on the back of floor pipe using the two grub screws and Allen key "11" supplied.
5. Position the tap on the ground where it is to install, make markings through the three fixing holes on the base fixing kit "2", drill three holes on the ground as per the markings, and fix the tap to ground using the three fixing bolts supplied.
6. Connect the lower ends of the flexi tails - 3/4" hex nuts - to hot and cold water supply, make sure the hot and cold water is connected correctly to the tap. And then slide the base cover downward to ground and cover the base fixing kit.
7. Connect the shower kit - shower hose "7", rubber washer "8" and handset "10" accordingly.
8. Turn on water to check leaks.

